

# **KITAGAWA**

## **NC ROTARY TABLES OPERATION MANUAL**

MODEL : RS200RAF10

### **IMPORTANT**

Please ensure that these instructions are read and understood by machine operators before using the NC Rotary Indexing Table.

Please Read and Save This Manual

**KITAGAWA IRON WORKS CO.,LTD.**

Thank you for choosing the Kitagawa NC Rotary Table.

Kitagawa, a world-renowned precision equipment manufacturer, has developed the finest quality NC Rotary Table with emphasis in high precision and rigidity as its basic principals in design.

This NC Rotary Table has been designed to provide years of high precision performance. To ensure optimum and trouble-free performance, please read this operation manual carefully before using the unit and retain this copy for your future reference.

Please pay close attention to the procedures with the following warning marks(1) to avoid severe injury and/or accident.



### **SAFETY ALERT SYMBOL**

This is the industry "Safety Alert Symbol". This symbol is used to call your attention to items or operations that could be dangerous to you or other persons using this equipment. Please read these messages and follow these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.

## **WARNING**



### **DANGER**

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



### **WARNING**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



### **CAUTION**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

## **IMPORTANT**

### **IMPORTANT**

Instructions for table performance and avoiding errors or mistakes.

---

## TABLE OF CONTENTS

---

	Page
1. For Your Safety-----	1
2. Specifications-----	6
3. Accuracies-----	7
4. Prepare for operation-----	8
4-1 Carry and mounting onto the machine tool	
4-2 Lubrication	
4-3 Air supply for clamp	
4-4 Referring to Air-purge	
5. Table Clamping-----	10
5-1 Precautions of table clamp	
5-2 Clamp/unclamp check device	
5-3 Solenoid Valve for Clamp/unclamp	
6. Workpiece clamping-----	11
7. Daily Inspection-----	11
8. Backlash adjustment of worm gear-----	11
8-1 Measuring method of backlash	
8-2 Adjustment method of backlash	
9. Built-in zero return device-----	14
9-1 Dog position of zero return reduction	
9-2 Adjustment method of dog position	
10. Motor Case-----	15
10-1 Removing	
10-2 Waterproof	
11. Storage-----	16
12. Conversion of circumference length and angle-----	16

# 1. For Your Safety

## Basic Safety Tips

Please read this manual and follow instructions carefully.


We cannot assume responsibility for damage or accidents caused by misuse of the NC Rotary indexing tables, through non-compliance with the safety instructions.



**DANGER**



**SWITCH OFF power before setting, inspecting and repairing NC rotary indexing table.**




Failing to do so could cause bodily harm to the operator.



**WARNING**



**Secure clamp bolts to correct torque.**



There is a danger of disturbance of NC rotary table and release of work piece.


**Tighten to correct torque**

Bolt size	Clamping torque [N·m(kgf·m)]
M8	38(3.9)
M10	73(7.4)
M12	108(11.0)
M16	250(25.5)




**When rotating the table, ensure your hand is out of the rotating area.**

Failing to do so could cause injury.



**Never apply excessive cutting force.**

Failing to do so could result in damage to the NC rotary table, which could cause release of the workpiece.






**WARNING**




**Do not attempt to modify the NC rotary indexing table.**

Failing to do so could result in damage to the NC rotary table, which could cause release of the workpiece.




**When lifting the NC rotary table, use an eye bolt and wire. (See page 8)**

Leash or Wire      Eye bolt



**Avoid interference between NC rotary indexing table and surrounding equipment. (See page 8)**



Interference and extreme bending of cable and hose should be avoided.

There is a possibility that you receive an electric shock in case of damaging the cable.

Minimum bending radius of the cable (CB1)

Fixed portion: R65

Movable portion: R150




## CAUTION



**Air must be supplied through air control unit  
(Air filter.Mist separater.Regulator)+ Drain catch.  
(See page 9)**

There is a danger of release of the workpiece when the clamping force of NC rotary table is reduced and also there is the possibility of ingress of dirt.




Periodically drain water collected in the air filter section.




**When clamping or unclamping workpieces ensure the table is properly clamped to the machine table.**

Failing to do so could result in damage to the NC rotary table, which could cause release of the workpiece and also there is a possibility of deterioration of accuracy.



**The cover plate should be sealed with a silicon rubber compound.(See page 15)**

Failing to do so could cause release of the workpiece and miss-operation of the table by ingress of oils.






**CAUTION**



**Never use a hammer on the NC rotary indexing table or the clamped workpiece.**


Failing to do so could result in damage to the NC rotary table, which could cause release of the workpiece.

**NO!**




**When machining a long or heavy workpiece, support with a tallstock or steady rest. (See page 6)**

In case that workpiece is too long or too heavy, it is dangerous as the workpiece may release.



**Replace lubricating oil every 6 months. (see page 8)**





## 2. Specifications

NC Rotary Table is dividing unit for workpiece, usually operating machines. [ Machining Center.(NC) milling machine, (NC)drilling machine, etc. ]

Specifications are as follows.

MODEL		RS200	
Table Diameter	(mm)	φ200	
Table Height In vertical	(mm)	185	
Center height	(mm)	140	
Center hole	(mm)	φ40	
Thru. Hole Diameter	(mm)	φ40	
Width of T-Slot	(mm)	12	
Guide block width	(mm)	18h7	
Clamping torque (Air Press at 0.5 Mpa (5.1kgf/cm <sup>2</sup> ))	N·m(kgf·m)	150(15.3)	
Allowable work diameter	(mm)	φ200	
Allowable work weight	In vertical position	kg	80
	In vertical position with tailstock	kg	160
	In horizontal position	kg	160
Allowable workpiece inertia	kg·m <sup>2</sup> (kgf·cm·sec <sup>2</sup> )	0.81(8.2)	
Total reduction ratio		1/90	
Maximum table speed	min <sup>-1</sup>	33.3	
Body weight	kg	61	
Tailstock weight	(kg)	16	

### IMPORTANT

Max. Table Revolution is at 3000min<sup>-1</sup>(rpm) of motor rotation.

### CAUTION

Be sure to remain within Allowable workpiece Inertia even though workpiece weight is within the maximum quoted.

### CAUTION

A tailstock may be required according to the weight, shape and cutting conditions or the workpiece.


### CAUTION

See above specification and precautions for operation. Set each machining condition so as not to exceed allowable value.

### 3. Accuracies

(Unit: mm)

Inspection items			Allowable value
1	Parallelism Between Table Face and Base	Per 150mm	0.015
2	Parallelism Between Center of Face and Base	Per 150mm	0.02
3	Run-out of Table Face In Rotation		0.02
4	Concentricity of Center Hole		0.01
5	Parallelism Between Center of Table and Center of Guide Blocks	Per 150mm	0.02
6	Indexing accuracy	Accumulation	40sec
7	Repeatability		±2sec




## 4. Prepare for operation

The following procedures are recommended for preparing the NC rotary indexing table and for the trial run.

### 4-1 Carry and mounting onto the machine tool

- 1) Carefully carry the table with a strong wire rope through the attached eye bolt.
- 2) Ensure mounting surface of machine tool is clean and free of burrs. If burrs or flaws are found, repair them with oil stone, etc., before mounting.
- 3) Install the table to the optimum position for work. Fit the guide block bottom face into T-groove on the machine tool table. If the clearance between T-groove and the guide block is large, move the table aside before installing.
- 4) Securely fix the NC rotary indexing table onto the machining tool with the attached clamp device.



Check mounting space before mounting NC rotary indexing table on the machine tool. Take care so that the NC rotary indexing table body, cable and air hose do not interfere with the splash guard or ATC device, spindle head, etc., of the machine tool when the machine tool table, spindle head, etc., are moved.



Do not scratch nor give stress nor load a heavy matter nor pinch a cable. There is a possibility that you may receive an electric shock in case of damaging the cable.



Use the mounting seat effectively and tighten the bolts of clamp equipment to correct torque. (See page 2)

### 4-2 Lubrication

The NC rotary indexing table has already been filled with lubrication before shipping. Check that the lubricant is filled to center level of the oil gauge.



Normally the lubricant should be replaced every six months. Drain the old oil thoroughly before replacing with clean oil. Clean the oil supply port so that no swarf or foreign matter can enter during re-filling. Should any foreign matter enter, the unit may seize or be severely damaged. The following lubricants are recommended.

## Recommended lubricant(viscosity grade ISO VG32)

Maker	Brand	Maker	Brand
MOBILE OIL	BACTRA OIL NO.1	COSMO OIL	DAINAWAY 32
NIPPON OIL	UNIWAY 32	IDEMITSU KOSAN	DAFUNIMULTIWAY 32MT
JOMO	SLIDUS HS32	ESSO OIL	UNIPOWER MP32
SHOWA SHELL OIL	SHELLTONA OIL S32		

Necessary oil quantity is **0.6 (RS200)**

DAFUNIMULTIWAY (IDEMITSU KOSAN) is provided in the unit before shipping.

### 4-3 Air supply for clamp

1) Supply air through air control unit (air filter, mist separator, regulator and drain catch).

(See page 4)

2) The air supply port of Rc1/8 is as shown in Fig.1. Connect the air hose to this port.

3) The air supply pressure used is within 0.5~0.6MPa(5.1~6.1kgf/cm<sup>2</sup>)



### 4-4 Referring to Air-purge

According to the circumstance of use, the dew may be occurred in the motor case.

Air is exhausted from the portion of the air exhaust so that it causes the obstacle of electric parts or each part.

The air purge is performed by air branched inside of NC table that uses air for clamp.

Be sure to use the clean air (passing through air filter, mist separator, regulator and drain catch) passing through the filter. If the air contains water content (moisture), oil content, etc.,

it is entered in the motor cover, thus causing in equipment damage. The air inside of motor case is exhausted from the air exhaust port.

In case that the portion of the air exhaust is closed, motor case or motor etc. may be damaged so that the dew cannot be exhausted and that air pressure is kept in the motor case. Therefore the portion of exhaust should not be closed.

## 5. Table Clamping

### 5-1 Precautions of table clamp



Always turn the table with the brake unclamped. Always ensure table has the brake clamped prior to machining except when milling.



never subject the table to more than the recommended braking force. Such action will cause excessive wear to the clamp and also damage the wormwheel.



It is important to ensure no residual pressure remains in the unit during unclamping as this can result in damage of the worm gear and clamping parts.

### 5-2 Clamp/unclamp check device

To perform correct procedure, be sure to check clamp/unclamp. (See Fig.1)

The check signal for clamp/unclamp is generated by the pressure switches. These pressure switches have been set as follows.

Clamp check (SP1) ————— 0.3 MPa ( 3.0 kgf/cm<sup>2</sup>)

Unclamp check (SP2) ————— 0.05 MPa ( 0.5 kgf/cm<sup>2</sup>)

### 5-3 Solenoid Valve for Clamp/unclamp

The solenoid valve is incorporated as shown in Fig.1.

Standard specification is as follows.

Solenoid ON ————— Table Unclamp

Solenoid OFF ————— Table Clamp




Fig. 1

## 6 Workpiece clamping

Clamp the workpiece securely to ensure high accuracy and precision.




Always ensure that the workpiece is firmly clamped. Failure to do this will cause damage and accidents.



Avoid mounting a workpiece which has poor flatness or perpendicularity directly to a table face. This may strain the table and prevent smooth rotation, which may result in very poor indexing accuracy. Shimming may be required to prevent this problem.



Set the work so as there is no eccentric load for the table rotation center by compensating with balance weight.



## 7 Daily inspection

The following procedures are recommended before operation.

- 1) Check the fixed condition of NC rotary indexing table (jig: if jig is mounted onto the face plate).
- 2) Check electric and air connection cables and air hose.
- 3) Check air supply pressure.
- 4) Check zero return, indexing and position.

## 8 Backlash adjustment of worm gear

The worm and worm wheel are made of special material and designed to maintain excellent accuracy. The backlash has been already adjusted before shipping. However, adjustment may be required when operating your unit over long periods. To obtain the optimum values of backlash the unit must be properly cool. If the unit is continuously operated over long periods the backlash will be smaller due to thermal expansion.



If the backlash is too small, the worm gear may seize.

## O Optimum values of backlash

Model	Measuring position	Angle(sec)	Circular length( $\mu\text{m}$ )
RS200	Face plate periphery( $\phi 165$ )	31~92	12~37

Measure backlash with the following methods before adjusting.

### 8-1 Measuring method of backlash (See Fig.2)

- 1) Place a dial indicator close to the table circumference on one of the T-Slot.
- 2) Insert a steel rod into another table T-Slot and move it in a clockwise direction with approximately 150 N·m (15.3 kgf·m) of force. Release and read the dial indicator.  
Next, apply force in a counter-clockwise direction on the steel rod. Release and read the dial indicator. The amount of backlash is the difference between the two dial indicator readings.
- 3) Check the amount of backlash at eight equally divided positions by repeating the procedures above. If the amount of backlash is not within the appropriate range, adjust the amount using following procedures.




Fig.2

## 8-2 Adjusting method of backlash (See Fig.3.)

The worm is supported by the worm housing. Also, the motor is fixed by this worm housing. The backlash is adjusted by varying the engagement of the worm and the worm wheel, moving the worm housing along body mounting face.

- 1) Remove the motor case and drain hydraulic oil in the table from the drain port. (See page 15 to remove the motor case.)
- 2) Slightly loosen the hexagon head bolt ① for the stopper.
- 3) Slightly loosen three hexagon socket head cap screws ③ little which fix the worm housing ②.
- 4) Insert the round bar ④ (about  $\phi 6$  or bar spanner) into  $\phi 8$  hole of body through  $\phi 7$  hole of the worm housing.
- 5) Approach the worm wheel side carefully to return the backlash to almost zero(0), operating the round bar.
- 6) Tighten the hexagon head bolt for the stopper and move the worm away from the worm wheel. Since the thread pitch of this bolt is 0.8 the backlash becomes larger by 0.036 with each  $1/12$  turn ( $30^\circ$ degrees).
- 7) Securely tighten the hexagon socket head cap screws ③ before measuring the backlash as indicated in 8-1.
- 8) If optimum value isn't found, repeat items 2) to 7).




Fig. 3



## 9 Built-in zero return device

The proximity SW ① detects the zero return.

### 9-1 Dog position of zero return reduction

On standard specification the zero return device turn clockwise (CW).

The ring type dog is set to the table spindle and it is possible to fix to optional periphery position. It is set where T-groove is horizontal before shipping.

To change the home position and dog position when marking return rotary direction counterclockwise, the following procedures are recommended.

### 9-2 Adjusting method of dog position(See Fig 4.)

- 1) Remove hexagonal hole plug ② located on the lubricant supply oil port and loosen two hexagon socket head cap screws ④ which fix the dog ③ to the table spindle through this oil supply port.
- 2) Move the dog ③ to proper position.
- 3) Securely tighten the hexagon socket head cap screws ④ after adjusting position.




Fig. 4

## 10 Motor case

### 10-1 Removing

When removing the motor, the following procedures are recommended only when the motor case must be removed. (See Fig.5)

- 1) Remove the cover of the motor case (RS200:②) and reconnect all the wires from the NC table of the terminal block ③. And also referring to the cables from the motor, remove a connector.
- 2) The motor case is fixed with seven hexagon socket head cap screw. One ④ among them is located inside motor case. Therefore, remove the cover ⑤ before loosening it.
- 3) Since the motor case can be removed as it is, carefully separate the body and the motor case.

### 10-2 Waterproof

In order to protect the unit from any leaking of coolant, liquid sealant is coated on the junction face of the motor case ① and covers ② and ⑤. Furthermore for the measures for waterproof of the inside of the motor case, the air supply port (Rc1/8) is prepared.

In case of the air-purging, clean air of 0.02MPa (0.2kgf/cm) of rated air pressure should be supplied. (Note:When products are delivered, this portion is plugged by a plug.)



When reassembling the unit scrape off any hardened liquid sealant thoroughly and recoat with fresh sealant. (Three bond 1216).

If cutting oil etc. is to be invaded into the motor case because of the break of a cable etc. It is urgently needed to be replaced a new cable so that electricies (motor, solenoid valve etc.) are to be damaged.




Fig. 5

## 11 Storage



When removing the NC rotary indexing table from the machine for storage, remove swarf and foreign matter before placing it on stable wooden base to maintain table accuracy. Also, coat it with rust-prevention oil and provide a wooden box or cover to protect from water and dust. Never use green fresh cut wooden case or box. Use treated timber.

## 12 Conversion of circumference length and angle




To calculate the circumference length when accumulated indexing accuracy is 30 sec or what is the angle when the accumulative pitch error is 0.05 use the following formula from relationship of the angle to the circumference length.

D: Work diameter (mm)

$\alpha$ : Angle (seconds)

L: Circumference length (mm)



$$\frac{L}{\pi \times D} = \frac{\alpha}{360^\circ \times 60' \times 60''} \text{----- (1)}$$

$$\alpha = \frac{360 \times 60 \times 60 \times L}{\pi \times D} = \frac{L \times 4.125 \times 10^5}{D} \text{----- (2)}$$

$$L = \frac{\alpha \times \pi \times D}{360 \times 60 \times 60} = 2.424 \times 10^{-6} \times \alpha \times D \text{----- (3)}$$

(Examples)

Regard the work diameter as 100mm and use previous "for cumulative index accuracy, the time of 30 seconds is indicated as circumference length." and formula (3). As a result, the following is found.

$$L = 2.424 \times 30 \times 100 \times 10^{-6} = 0.007272\text{mm} \approx 0.0073\text{mm}$$

Consequently, circumference length is about 0.0073mm.

Also, use "Cumulative pitch error is indicated with angle of 0.05." and formula (2), the following is found.


$$\alpha = \frac{4.125 \times 0.05 \times 10^5}{100} = 206.25''$$

Therefore, the angle is 206 seconds or 3 min., 26 sec. As shown above, the circumference length and angle can be converted by formulas (2) and (3).



# Appendix 2 Wiring Diagram

CONNECTION OF PROXIMITY SWITCH



SPECIFICATIONS

POWER SUPPLY	DC 10~30V
LOAD CURRENT	3~100 mA 4
LEAK CURRENT	max. 0.55 mA
RESIDUAL VOLTAGE	max. 3.0 V
OUT PUT TYPE	NC

MARK	N A M E	M A K E R	T Y P E	N O.	R E M A R K S
M	AC SERVO MOTOR	FANUC	A06B-0373-B075 (α2/3000 αAG4)	1	
SP1	PRESSURE SWITCH	WILLY VOGEL	176 110 300	1	0.3 MPa (3kg/cm <sup>2</sup> ) N.O.
SP2	PRESSURE SWITCH	WILLY VOGEL	176 120 100	1	0.05 MPa (0.5kg/cm <sup>2</sup> ) N.C. (CAPACITY 42V.30VA)
SQ1	PROXIMITY SWITCH	YAMATAKE	FL7M-3K6H	1	DC10~30V
YV1	SOLENOID VALVE	SMC	VK334-5GS	1	DC24V
XT1	TERMINAL BOX	WAGO	264-701	6	
	TERMINAL BOX	WAGO	264-721	1	
	TERMINAL BOX	WAGO	264-727	1	
	END PLATE	WAGO	264-368	1	
	END STOP	WAGO	249-101	2	
	CARRIER RAIL	WAGO	210-111	1	
XP1	RECEPTACLE	HRS	H/MS3102A18-10P(10)	1	A CANNON CONNECTOR EQUIPPED ON MOTOR
XP2	RECEPTACLE	HRS	H/MS3102A20-29PCW4(10)	1	A CANNON CONNECTOR EQUIPPED ON MOTOR

SPECIFICATIONS OF SOLENOID VALVE


RATED COIL VOLTAGE	24V
CONSUMPTION ELECTRIC POWER	4W

W I R E N O.	W I R E D I A.
A1	A4
A6	A5
A2	A7
U	A8
V	W

NOTE

- 0.75mm<sup>2</sup> wires must be used for 'A1', 'A4', 'A5', 'A6', 'A7', 'A2', 'A8' and 'W'.
- 'SHLD' IS EARTH.
- DOT LINE PORTION MUST BE PREPARED BY CUSTOMER

Model : RS200RAF10



XP1	W I R E N O.	W I R E N O.
A	U	S
B	V	T
C	W	
D	⊕	
E		
F	REQ	
G	*REQ	
H	SHLD	
J	+5V	
K	+5V	
L		
M		
N	0V	
P		
R	+6VA	

XP2	W I R E N O.	W I R E N O.
A	SD	OVA
B		OV
C		
D	*SD	
E		
F	REQ	
G	*REQ	
H	SHLD	
J	+5V	
K	+5V	
L		
M		
N	0V	
P		
R	+6VA	

# KITAGAWA



株式会社 北川鉄工所

本社/広島県府中市元町77-1  
〒726-8610/電話<0847>45-4560(代)  
FAX<0847>45-8911

仙台支店/仙台市若林区大和町4-15-13	〒984-0042/電話<022>232-6732(代)
	FAX<022>232-6739
東京支店/埼玉県さいたま市吉野町1-405-1	〒330-8634/電話<048>667-3469(代)
	FAX<048>663-4678
横浜支店/神奈川県横浜市港北区新横浜	〒222-0033/電話<045>476-5666(代)
	FAX<045>476-5667
名古屋支店/名古屋市中川区高畑3-19-11	〒454-0911/電話<052>363-0371(代)
	FAX<052>362-0690
大阪支店/大阪市住之江区加賀屋3-2-9	〒559-0011/電話<06>6685-9065(代)
	FAX<06>6684-2025
中四国営業課/広島県府中市元町77-1	〒726-8610/電話<0847>404-0541(代)
	FAX<0847>404-0541
広島支店/広島市南区東豊本町2-13-21	〒734-0023/電話<0832>2205-1333(代)
	FAX<0832>2205-1330
九州支店/福岡市博多区板付7-6-39	〒816-0088/電話<092>5001-2102(代)
	FAX<092>5001-2103
浜松営業所/静岡県浜松市上島3-29-23	〒433-8122/電話<053>468-7880(代)
	FAX<053>468-7881

工場/本山・下川辺・中須・甲山・東京・和歌山

## PRODUCTION PLANT

### KITAGAWA IRON WORKS CO.,LTD.

Head Office: 77-1 Motomachi, Fuchu-City, Hiroshima-Pref. 726-8610 Japan

Tel: (0847)45-4560 Telex: 6457-51 KIWJ Fax: (0847)45-8911  
Cable: KITATETSU, FUTHU, HIROSHIMA

### KITAGAWA USA, INC.

301E. Commerce Drive, Schaumburg, IL 60173 USA  
Tel: (708)310-8198 Fax: (708)310-9791

### KITAGAWA MANUFACTURING EUROPE LTD.

7 Dolphin Industrial Estate, Southampton Road,  
Salisbury, Wiltshire SP1 2NB UK  
Tel: (01722)414809 Fax: (01722)414819

## REPRESENTATIVE

### TECNARA TOOLING SYSTEMS, INC.

12535 McCANN DRIVE, SANTA FE SPRINGS, CALIFORNIA 90670  
Tel: 310/941-2000 Fax: 310/946-0506

415 W. GOLF ROAD, SUITE 12, ARLINGTON HEIGHTS, ILLINOIS 60005  
Tel: 708/956-8600 Fax: 708/956-8680

146 SCHOOLHOUSE ROAD, UNIT H, SPRING VALLEY, NEW YORK 10977  
Tel: 914/735-1280 Fax: 914/735-1254

## NORTH AMERICA REPRESENTATIVE

NORTH TECH WORKHOLDING, INC  
301 E. Commerce Drive, Schaumburg, IL 60173 USA  
Tel: (708)310-8787 Fax: (708)310-9484

## EUROPE REPRESENTATIVE KITAGAWA EUROPE LTD.

7 Dolphin Industrial Estate, Southampton Road,  
Salisbury, Wiltshire SP1 2NB UK  
Tel: (01722)421155 Fax: (01722)421071

## TAIWAN REPRESENTATIVE DEAMARK LIMITED

No. 6, Lane 5, Lin Sen North Road, Taipei, Taiwan R.O.C.  
Tel: (02)393-1221 Fax: (02)395-1231