

AUTOMATIC BAR FEEDER

ELENCO ALLEGATI
MANUAL FOR USE AND MAINTENANCE
KEYBOARD INSTRUCTION MANUAL
SPARE PARTS BOOK
SCHEMATICS
EC CONFORMITY DECLARATION FOR MACHINE

SIR 52 P - SIR 52 F

EN

MANUAL FOR USE AND MAINTENANCE

Rel. 2 Date 01/02/2006 Cod. 610505400

S/N

SOFTWARE RELEASE

OP:

PLC:

REDATTORE: Bosi Andrea

PER APPROVAZIONE: Magnani Claudio

COSTRUTTORE: IEMCA division of IGMI S.p.A.

INDIRIZZO: Via Granarolo, 167 - 48018 Faenza (RA) - ITALY

Tel. 0546/698000 - Fax. 0546/46338 - 0546/46224

TLX 550879

TIPO DI DOCUMENTO: MANUAL FOR USE AND MAINTENANCE


PRODOTTO: AUTOMATIC BAR FEEDER


MODELLO: SIR 52 P - SIR 52 F

1	GENERAL INFORMATION	SIR-52-P/F
2	TECHNICAL INFORMATION.....	SIR-52-P/F
3	SAFETY PROCEDURES - GENERAL INFORMATION.....	SIR-52-P/F
4	HANDLING AND INSTALLATION	SIR-52-P/F
5	ADJUSTMENTS AND SETTING-UP	SIR-52-P/F
6	USE AND OPERATION.....	SIR-52-P/F
7	BAR FEEDER MAINTENANCE	SIR-52-P/F
8	TROUBLES - CAUSES - CURES	SIR-52-P/F
9	PART REPLACEMENT	SIR-52-P/F
10	GUIDE CHANNELS-BAR PUSHER-REVOLVING TIPS.....	SIR-52-P/F
11	COLLETS	SIR-52-P/F
12	LIST OF AFTER-SALES CENTERS	SIR-52-P/F

INDEX

1.1	TERMS OF WARRANTY	2
1.2	MANUAL PURPOSE.....	3
1.3	MANUFACTURER AND BAR FEEDER IDENTIFICATION	4
1.4	TECHNICAL ASSISTANCE	4
1.5	ANNEXES ENCLOSED	4

 Operations described in paragraphs showing this symbol, must be performed by qualified and skilled personnel only.
Any other operation can be performed either by qualified personnel or by professional bar feeder operators.

 **Before carrying out any servicing whatsoever on the bar feeder, it is of the utmost importance to read this manual carefully.**

1.1 TERMS OF WARRANTY

The warranty validity is subordinated to a correct assembly and coupling of the bar feeder to lathe. In particular, before the first start-up, carry out an accurate check to make sure the bar feeder is correctly aligned with the lathe and fastened with the expansion plugs as shown in section 4.

The product warranty is valid only if the bar loader is installed by an authorized technician with Original Installation Certificate. Please ask the technician, who will make the installation, to show the certificate, in order to ascertain the quality of the technical works being carried out.

The warranty shall begin from the date on the Installation Certificate duly filled in and signed.

The document must be sent per mail to:

CUSTOMER SERVICE
IEMCA division of IGMI spa
48018 Faenza (Ra) ITALY - Via Granarolo,167

IEMCA		INSTALLATION CERTIFICATE	N° 1005 /02
ATTENTION: To comply with the warranty terms all parts of this form are to be filled in and mailed to IEMCA Italia			
Installation and training executed by:			
Company		DATE	
Installer		Service report	
Technician		No.	
Executed at:			
Customer		Participant/s	
Country		(write names in caps)	
Bar feeder			
Serial no.			
Equip./Type			
SUBJECT			
Bar feeder's general description and running, operating cycle instructions.			<input type="checkbox"/>
Bar feeder tooling instructions and changeover instructions.			<input type="checkbox"/>
Description and change of: guides, bar pusher, collet, half bushing, front nose and reduction nose			<input type="checkbox"/>
Description of operator's keyboard, description of parameters and their use.			<input type="checkbox"/>
Programming procedures based on the kind of process required.			<input type="checkbox"/>
Errors - Causes - Solutions; description of the main alarms listed on manuals.			<input type="checkbox"/>
Manuals and precautionary maintenance tips examination; Procedures to request IEMCA technical service.			<input type="checkbox"/>
Customer is familiar with the bar feeder and is aware of all its running and maintenance procedures having received such information during previous installations.			<input type="checkbox"/>
Marked subjects have been dealt with fully and thoroughly. Participant reports that training received was fully satisfactory. Side signature acknowledgement.			
NOTE: In order to benefit from our warranty - an IEMCA authorized technician must have carried out the installation - above mentioned "training" must be completed.			
Warranty terms is of 12 months beginning on the date of the installation and may not exceed 18 months from the delivery date. Warranty will have effect from the date of the general undersigning of this form. All parts of these form must be completely filled in and the same must be mailed to IEMCA, or returned by means of the installing technician, within 15 days.			Customer's stamp and signature
IGMI s.p.a. IEMCA GIULIANI MACCHINE ITALIA S.p.A. Sede Legale: Faenza (Ra) - Italy Via Granarolo, 167 - 48018 Faenza (Ra) - Italy Tel. +39 0546 41221 Cap. Soc. € 4.000.000 i.v. - I.C.E.A. Ra 41717 - Reg. Imp. C.F. P.I. 04827610397 - C.G. nr. 02817/0000000			BUCCI Member
			Copy for IEMCA

1.2 MANUAL PURPOSE

This manual has been written and supplied by the manufacturer, the information herewith contained has been written in Italian (manufacturer's language) to be translated to other languages, in order to comply with legal and/or commercial requirements. This manual is integral part of the bar feeder and of its equipment.

The compliance with the instructions contained herein ensures the operator and bar feeder safety as well as a running economy and a longer life of the bar feeder itself.

In order to allow a quick search of contents, consult the descriptive index. Particularly important parts of this manual have been highlighted in bold type and preceded by the following symbols:



DANGER - WARNING:

shows impending danger which might cause serious injuries, exert the maximum caution.



CAUTION - PRECAUTION

indicates measures to be adopted to avoid accidents or damages to property.



INFORMATION

technical instructions of particular importance.


For a quick search of topics see the table of contents.

In addition to this manual, which contains all the instructions for the bar feeder use and maintenance, one more is supplied: the "Push-button panel instruction manual".

The "Push-button panel instruction manual" contains all the instructions on how to use the installed software.

1.3 MANUFACTURER AND BAR FEEDER IDENTIFICATION

- A Manufacturer's identification
- B CE conformity marking
- C Year of manufacture
- D Bar feeder model
- E Serial number
- G Mains frequency
- H Absorption power
- M Feeding voltage
- N Direct driving voltage
- P Air pressure
- Q Bar feeder and pusher length
- R Breaking capacity
- S Number of base wiring diagram
- T Number of interface wiring diagram



i **INFORMATION:**

Always provide the Manufacturer with the above mentioned specifications when requesting information or ordering spare parts, etc.

1.4 TECHNICAL ASSISTANCE

Whenever necessary, please apply to one of the Technical Assistance Centres shown in the attached list.

i **INFORMATION**

when requesting technical assistance for the bar feeder, always specify the information shown on the machine dataplate.

1.5 ANNEXES ENCLOSED

- Electric diagram
- Pneumatic diagram
- Hydraulic diagram
- Lubrication system diagram
- Technical assistance departments list.
- Push-button panel instruction manual.

INDEX

2.1	DESCRIPTION OF MODELS	2
2.2	GENERAL BAR FEEDER DESCRIPTION	5
2.3	WORKING CYCLE - GENERAL DESCRIPTION	8
2.4	SAFETY DEVICES	9
2.5	SAFETY PLATES - LOCATION AND DESCRIPTION	11
2.6	TECHNICAL INFORMATION	12
2.6.1	Noise levels	15
2.7	FITTINGS - DESCRIPTION	16
2.7.1	Additional inner lighting lamp.....	16

2.1 DESCRIPTION OF MODELS

The bar feeder is available in four models:

- SIR 52 P for bars to 52 mm with rack magazine type (A);
- SIR 52 F for bars to 52 mm with bar bundle magazine type (B).

MANUFACTURING FEATURES

- Maximum and minimum bar length.




Table 1. Maximum and minimum bar length.

Models	Version	Max. length (mm)	Min. length (mm) *
SIR 52 P SIR 52 F	33	3300	2500
	38	3800	3000
	43	4300	3000

(*)Please contact IEMCA Sales Department before loading bundles of short bars into the bundle magazine, in order to check whether a short bar loading set is necessary.



INFORMATION

In bundle models, bars are loaded in the middle of the magazine.


- Bar loading: into the 6th or 1st station of lathe (A) in case of 6-spindle lathe.
Loading the bar in the seventh station of lathe (C) when the lathe has 8 spindles.
- Stock tube diameter \varnothing (B).

Table 2. Stock tube diameter

Models	Min diameter (mm)	Max diameter (mm)
SIR 52 P/F 6 channel	276	360
SIR 52 P/F 8 channel	330	370


In the case of a lathe with a number of spindles other than 6 - 8, such dimensions may change.

- Bar feeding in more stations: bar feeding can occur in two or more stations, in any possible combination. For further information, apply to IEMCA service department.



- Bar pusher extension.

Table 3.Bar pusher features




Models	Version	Bar pusher type	Bar pusher extension MAX	Clamp position
SIR 52 P SIR 52 F	N	STANDARD	1110	A
	L	LONG	1360	B
	XL	EXTRA LONG	1610	C


2.2 GENERAL BAR FEEDER DESCRIPTION

The automatic bar feeder SIR 52 P or SIR 52 F is used in the machine tools sector and more specifically to automatically feed multi-spindle lathes.


The bar feeder has been designed to be installed instead of the lathe stock tube, thus replacing the bar guiding and feeding systems. It allows round, hexagonal and square bars to be loaded. The working cycle is controlled by a PLC fitted in the electric switchboard, able to dialogue with the lathe control.



- A LATHE
machines the bars loaded by the bar feeder.
- B RACK MAGAZINE
stores the bars.
- C TRAVERSE DEVICE
takes single bars, moving them from the rack magazine to the inserting device.
- D DRIVE
drives the bar traverse device from the rack to the inserting device.




- E BUNDLE MAGAZIN/E stores bars.
- F BAR SELECTING DEVICE selects bars.
- G DRIVE drives the bar selecting device.
- H BAR INSERTING DEVICE takes the bars and arranges them into the guide channels.
- L CLAMP AND BAR PUSHER UNIT inserts into and removes the bar from the collet. Furthermore, it inserts into and removes the bar pusher from guide channels.
- M FEEDING DRUM inserts bars into lathe.
- N CONTROL PUSH-BUTTON PANEL controls all bar feeder functions.
- P HYDRAULIC CONTROLS adjust hydraulic oil flow.
- Q ADDITIONAL PUSH-BUTTON PANEL controls some bar feeder functions (not supplied in some models, being its functions included into the lathe push-button panel).
- R CUBICLE fits the electric switchboard.



- S REMNANT RECOVERY TANK
collects bar remnants.
- T HYDRAULIC OIL PUMP
produces pressure for the hydraulic functions of the bar feeder.
- U LUBRICATING OIL PUMP
produces pressure to lubricate guide channels.
- V HYDRAULIC OIL TANK
contains the hydraulic system oil.
- Z LUBRICATING OIL TANK
contains the oil for the lubricating system.

2.3 WORKING CYCLE - GENERAL DESCRIPTION



SIR 52 P










- The bars, manually loaded into magazine (A), are taken by the chain displacement device (B).
- The bar loading device (D) introduces them into drum (C).
- The clamp device (E) inserts the bar into the bar pusher collet.
- Then, bars are fed into the lathe.



SIR 52 F

- Bars, previously loaded inside the magazine (A) through a lifting device, are selected by the bar selecting device (B).
- The bar inserting device (D) introduces them into drum (C).
- The clamp device (E) inserts the bar into the bar pusher collet.
- Then, the bars are fed into the lathe.

2.4 SAFETY DEVICES

A INTERLOCKED MOBILE GUARD. It is associated to microswitch (B):

- when selector  is turned to , the bar feeder stops by opening the guard;
- when selector  is turned to , the bar feeder does not stop by opening the guard, but there are few controls enabled, i.e. those necessary for setting up or change the machining procedures; they are:     .



C AXIAL DISPLACEMENT LOCKING.

It is associated to sensor (D).

By releasing the lever, all lathe and bar feeder functions are disabled.

E MOBILE GUARD.


Associated to microswitch (F).

By opening the guard, all lathe and bar feeder functions are disabled.

G MOBILE GUARD.


Associated to microswitch (H).

By opening the guard, all bar magazine functions are disabled. The bar feeder keeps feeding the lathe until the feeding drum runs out of bars.




30213100400

- L Mobile guard
Prevents the accidental access to bundle magazine.
- M Mobile guard
Prevents the accidental access to the bar selecting station.
- N Main switch
Disconnects the electric supply when servicing the electric switchboard.
- P Emergency push-button
By pressing it, all lathe and bar feeder functions are disabled.





2.5 SAFETY PLATES - LOCATION AND DESCRIPTION



DANGER - WARNING:

Keep safety plates clean.

- A Danger of arm crushing.
- B Give the greatest attention to running parts.
- C Danger of material falling.
- D Do not remove safety guards.
- E Wear safety work gloves and shoes.
Do not lift any load exceeding 15 kg manually.
- F Do not open the bar feeder while it is running.
- G Caution: danger of electric shock.
- H Warning: fix the bar feeder to the ground.

2.6 TECHNICAL INFORMATION


IEMCA30213100500

Table 4. Technical specifications


Value	Version		
	33	38	43
A	4900	5400	5900
B	1720	2220	2720
C	2620	3120	3620
D	4520	5020	5520
E	3250	3750	4250

Table 5. Technical specifications

	SIR 25 P	SIR 36 P	SIR 25 F	SIR 36 F
Min round bar diameter	4mm (11/64") (version 33-38) 5 mm (13/64") (version 43)	5 mm (13/64") (version 33-38-43)	4 mm (11/64") (version 33)	5 mm (13/64") (version 33)
			6 mm (1/4") (version 38)	6 mm (1/4") (version 38)
			8 mm (21/64") (version 43)	8 mm (21/64") (version 43)
Max round bar diameter	25 mm (1")	36 mm (1-3/8")	25 mm (1")	36 mm (1-3/8")
Bar straightness	0,5 mm/m			
Max. bar length	3300 mm (version 33) - 3800 mm (version 38) - 4300 mm (version 43)			
Max. magazine capacity	n. 22 bars più 200 mm on the rack	n. 11 bars più 200 mm on the rack	2000 kg	
Supply voltage	380 three-phase / 50 Hz (other voltages upon request)			
Supply voltage	24 Volt D.C.			
Installed power	4,5 kW			
Feeding speed	up to 1.5 m/sec.			
Return speed	up to 1.5 m/sec.			
Bar change-over time	30 sec.			
Hydraulic system oil (not supplied)	Type C) HG32; quantity 80 l			
Guide channel oil (not supplied)	Type (C) CKB 100; quantity 170 l			
Compressed air	6 bar			
Bar feeder weight	1650 kg (version 33)		1800 kg (version 33)	
	1750 kg (version 38)		1900 kg (version 38)	
	1850 kg (version 43)		2000 kg (version 43)	
Control unit weight (dry weight)	220 kg			

(*) Please contact IEMCA Sales or Service Departments before loading thinner bars.

In pursuing a policy of continuous updating of the product, the manufacturer might introduce changes without any prior notice.



2.6.1 Noise levels

The bar feeder does not cause acoustic noise.

Noise occurs when lathe, to which the bar feeder is connected, is running and the bar turns into the bar feeder guide channels.

In such a situation, the noise level emitted depends on the following conditions:

- perfect alignment and levelling of the lathe-bar feeder unit;
- correct fastening of the lathe and bar feeder to the ground;
- perfect working order of the lathe bar gripping device;
- use of guide channels and bar pushers whose dimensions are suitable to the diameter of the bar to be machined;
- use of a front guiding bush of suitable diameter (if supplied);
- use of bars whose straightness is within the prescribed limits (max. deflection in mm equal to 0.5 per thousand of the bar length);
- use of a spindle liner with a diameter equal to the bar feeder guide channel diameter;
- spindle rotation speed suitable to the material to be machined;
- as far as the bar feeder is concerned, use of suitable oil, according to the diameter of the bar to be machined;
- all bar feeder guards must be closed.


If the above mentioned conditions are complied with, the noise level emitted during the bar rotation into the guide channel and measured according to the international standards, does not exceed the following limits:

- brass and steel round bars within 80 dB(A)
- steel hex. bars within 83 dB(A)
- brass hex. bars within 85 dB(A)

2.7 FITTINGS - DESCRIPTION

2.7.1 Additional inner lighting lamp

Lamp (A) allows the rear drum area to be lighted, to make operator's checking easier.
Lamp (B) may be fitted upon customer's request.



INDEX

3.1	GENERAL SAFETY PRESCRIPTIONS.....	2
3.2	HANDLING AND INSTALLATION - Safety	3
3.3	ADJUSTMENTS AND SETTING UP - Safety	3
3.4	USE AND OPERATION - Safety.....	4
3.5	BAR FEEDER MAINTENANCE - Safety	4

3.1 GENERAL SAFETY PRESCRIPTIONS



It is of the utmost importance to read this manual carefully before installing, using or servicing the bar feeder or performing any other work . Constant compliance with the instructions in this manual is a guarantee of protection against injury.

- The operator and skilled engineer must perform only their specified duties.
- Do not tamper with the safety devices for any reason whatsoever.
- Comply strictly with the work health and safety regulations issued by the relevant authorities in the country of installation of the machine.
- IEMCA declines any liability whatsoever for injury to persons or damage to property if the relevant safety prescriptions are disregarded.

3.2 HANDLING AND INSTALLATION - Safety

- The bar feeder must be handled using suitable means and methods.
- Persons must not stand or transit underneath a suspended load, or within the range of action of the crane, lift truck or other suitable means of lifting and transportation.
- The working area and bar loading area must be cordoned off to prevent collisions between the operator and machines used to transport or handle the barstock or other materials.
- Correct positioning of the bar feeder, adequate lighting and a clean working environment are of the utmost importance as far as personal safety is concerned.
- The electric system connection must be made exclusively by skilled electricians.
- Make sure the electrical system is connected to an efficient earth circuit by means of a dedicated wire.

3.3 ADJUSTMENTS AND SETTING UP - Safety

- Carry out the adjustments as described in the user manual.
- Do not change working parameters to obtain performances other than those envisaged in the design and testing phases.
- Do not adjust the bar feeder when it is running unless expressly requested to do so in the manual.
- Do not feed the machine with bars having dimensions different from those recommended by the manufacturer.
- Do not use hoses as handholds.










3.4 USE AND OPERATION - Safety

- The working area around the bar feeder must always be kept clean and uncluttered in order to allow immediate access to the emergency devices and bar loading to be performed without creating obstructions or danger.
- Perform the cycle starting sequence as prescribed.
- Keep hands and other parts of the body well clear of moving parts or live electrical parts.
- Remove bracelets, watches, rings and neckties.
- Whenever necessary, use strong work gloves with 5 fingers, which do not reduce the sensitivity or power of your grip.
- Wear working shoes as well as personal protection devices provided for by the accident prevention regulations in force in the country in which the machine is installed.
- Inform maintenance personnel of all operating anomalies that come to your attention.
- Before starting the bar feeder, make sure that there are no personnel engaged in servicing or cleaning the machine.

3.5 BAR FEEDER MAINTENANCE - Safety

- Do not allow unauthorized persons to carry out maintenance.
- Read this manual carefully before carrying out maintenance.
- Do not lubricate, repair or adjust the bar feeder while it is running, unless expressly indicated to do so in the manual.
- Stop the bar feeder in accordance with the prescribed methods before carrying out lubrication or other work.
- Do use matches, lighters or torches when servicing the machine in the presence of inflammable fluids.
- Keep spent oil in suitable containers and consign it to companies specialized in the storage and disposal of polluting waste products.
- Do not pollute the environment.
- Use original IEMCA spare parts only.


INDEX

4.1	PACKING	2
4.2	LIFTING - PREAMBLE 	3
4.2.1	Lifting without packing	3
4.2.2	Lifting with a pallet	5
4.2.3	Lifting with a box	5
4.3	INSTALLATION AREA - FEATURES 	6
4.4	INSTALLATION 	6
4.4.1	Lathe - Preliminary operations	7
4.4.2	Positioning.....	7
4.4.3	Height and levelling adjustment	8
4.4.4	Alignment.....	12
4.4.5	Fastening the bar feeder	14
4.5	HYDRAULIC CONTROL UNIT - OIL LOADING 	16
4.5.1	Hydraulic control unit - Connection.....	17
4.6	ELECTRIC CONNECTION 	19
4.7	ADDITIONAL PUSH-BUTTON PANEL - INSTALLATION 	19
4.8	PNEUMATIC CONNECTION 	20
4.9	LATHE MODIFICATIONS 	21
4.10	ALIGNMENT - FINAL CHECK 	21

4.1 PACKING

The machine may be packed in three ways:

- A **WITHOUT PACKING**: the bar feeder is divided from the hydraulic control unit.
- B **PALLET**: the bar feeder is placed on a pallet and covered by a protective sheeting.
- C **BOX**: the bar feeder is contained in a box and covered by a protective sheeting.



4.2 LIFTING - PREAMBLE 




DANGER - WARNING:

Lifting and handling shall be carried out using suitable means and performed by skilled personnel only.

4.2.1 Lifting without packing

With respect to the length of front crosspiece (A), two different lifting procedures are required.

If the crosspiece does not come out of the bar feeder shape, the lifting with tube is needed; otherwise, the tubeless lifting is needed.




LIFTING

Table 1. Belt length


Model	Version	Belt C (mm)	Belt D (mm)
SIR 52 P SIR 52 F	33	3000	3000
	38	2500	3000
	43	2500	3000

Check the length belts (C) and (D) and apply wooden pads (E). Use a bridge crane or a self-propelled crane.

i **INFORMATION:**
After positioning and alignment, remove the eye bolt brackets.
 Use the brackets supplied with the bar feeder.




To uplift the hydraulic drive unit, use belts or chains together with a bridge crane or a self-moving crane having an appropriate loading capacity.




4.2.2 Lifting with a pallet

Use two belts of 8 m in length and a bridge crane or a self-propelled crane having adequate capacity load.



4.2.3 Lifting with a box

Use two belts of 8 m in length and a bridge crane or a self-propelled crane having adequate capacity load. The case weight is 1000 kg.




4.3 INSTALLATION AREA - FEATURES

- The floor should be stable and levelled to guarantee good fastening to the ground.
- Provide an area of suitable dimensions according to the type of feeder use.

Table 2. Installation area dimensions

Models	Version	A (mm)
SIR 52 P SIR 52 F	33	4950
	38	5450
	43	5950

- The areas: (B) (work area), (C) (bar feeding area) and (D9 (remnant discharge area) should be properly delimited to prevent collisions between the operator and any handling equipment or transport vehicles travelling near the bar feeder.
- The selected bar feeder setting should be suitably lit and provided with an electric power and air outlets.
- During operation, the feeder will release small amount of oil vapors. Make sure that the premises where the feeder is installed are suitably ventilated.



4.4 INSTALLATION

The most important phase of installation is the alignment between the bar feeder and lathe, hence said operation shall be carried out by skilled personnel with the maximum precision.



WARNING-CAUTION:

A wrong alignment may be the main cause of bar feeder malfunctioning and may cause damages to the machine.

4.4.1 Lathe - Preliminary operations

- Remove the lathe stock tube and the countercollet unit, disconnect the lathe bar feeding system.




INFORMATION

This operation is necessary only if the lathe is supplied with the device.


- Check the lathe alignment.

4.4.2 Positioning

- Position the bar feeder nearby the lathe.




- In the front feet, remove the eyebolts (A) or the tube used for lifting.
- In the rear feet, remove brackets (B) and replace the relevant screws (C) with those supplied (M12x50 UNI 5931).




4.4.3 Height and levelling adjustment

Adjust height (X) of the bar feeder working axis with the lathe height, according to the procedure below:


- loosen screws (A) and turn column (B) through pin (C).




- Open rear guard and replace red screw (D) pin (E) supplied




- Lower lever (M) and move feeding drum backwards of 1000 mm approx.




- Move the bar feeder close to the lathe, according to value (G) (previously calculated), to allow bushes (H) to be centred with respect to lathe disk (L), previously moving the drum to its forward stop.




- Move the drum forward and adjust the height of the bar feeder working axis, to allow bushes (H) to fit into lathe disk (L) holes. Adjust through feet supports.



- Check the cross and longitudinal alignment by means of the proper tables of reference. Adjust through feet supports whenever necessary.



- Check the adjustment, moving the drum forwards and backwards trough lever (F); bushes (H) must fit (without an excessive effort) into lathe disk (L) holes.





4.4.4 Alignment



INFORMATION


Operation to be carried out by IEMCA skilled personnel only.

- Move the drum backwards of 500 mm approx.
- Stretch a nylon thread (\varnothing 1 mm) between the bar feeder and the lathe collet, as follows:
 - fit thread holding block (A) instead of the last sprocket pair;
 - position a plug (B) with hole \varnothing 1,5 mm. (to be manufactured by the client) into the lathe collet;
 - stretch nylon thread (C), moving the drum backwards and locking the displacement to keep the thread stretched.




36_16_128_0

Check, through a vernier calliper, the horizontal and vertical alignment in the front bush (D) of the bar feeder and in disk (E) of the lathe, according to the four directions shown by the arrows. Allowance must be of ± 0.15 mm. Height can be adjusted through the feet supports; side adjustments are obtained by giving calibrated blows on the feet side plates through a mallet. During this phase, keep to the height and level adjustments to find the correct bar feeder position.




- Check the adjustments by moving the drum forward and backward through lever (F); bushes (H) must fit (without an excessive effort) into lathe disk (L) holes.



4.4.5 Fastening the bar feeder

FASTENING TO THE GROUND

- Fasten the bar feeder to the ground using the expansion plugs (A) and tighten screws (B). Remove the front feet tie rods (C), should they hinder the chips removal or the lathe lubricating oil control unit.



Only for SIR 52 F


Install the central foot in the following way:

- Assemble the central foot by means of screws (D).
- Adjust the height.
- Fasten the plate to the ground.
- Tighten screws (E).




WARNING-CAUTION

When installing the central foot, make sure the magazine is empty.






PRECAUTION WARNING:
Before starting the bar feeder, remove the rod (F).



FASTENING TO THE LATHE

Once the bar feeder has been fastened to the ground, connect the bar feeder to the lathe. Figure 24 shows a general example; apply to IEMCA service department for more details.



4.5 HYDRAULIC CONTROL UNIT - OIL LOADING

LUBRICATING OIL


- Remove cover (A).
- Loading should be carried out by filling in lubricating oil of the following class: C CKB 100. Quantity: 170 l.
Make sure oil is between the MAX. and MIN. level.



INFORMATION


Perform this operation after some hours have passed since the bar feeder stop.

In that way the oil may flow back towards the control unit.




HYDRAULIC OIL

- Remove plug B.
- To top it up, fill with hydraulic oil: type class C HG 32 or equivalent. Quantity: 80 l.
Make sure oil is between the MAX. and MIN. level.




4.5.1 Hydraulic control unit - Connection

- Fit the control unit under the bar feeder.
- Connect pipes (A) of the hydraulic oil system.
- Connect the lubricating oil delivery pipe (B).



- Adjust the lubricating oil return pipe (C), operating the relevant ring (D).
- Connect the electric socket (X5) (F).






In case of transport, displacements or further installations of the bar feeder, a plug (E) is supplied, to be introduced into the oil collecting tank to prevent the lubricating oil from leaking while handling.

FIRST STARTING-UP OF THE HYDRAULIC OIL PUMP

An appropriate start of the pump is of the utmost importance, since the correct lubrication of the internal parts of the pump depends on this phase.

- Start the pulse-operated electric motor in order to allow for the priming and the lubrication of the pump parts.
- Check that the direction of rotation is correct with respect to the indication shown on the motor grid and on the coupling flange of the pump.
- The priming of the pump is not only shown on the pressure gauge mounted on the delivery pipe, but also by the change in the noise of the pump, as it becomes more silent when it has been successfully primed.



4.6 ELECTRIC CONNECTION



DANGER - WARNING:

this type of operation should only be entrusted to skilled technical staff to comply with the applicable standards and statutory regulations in force.

The feeder is normally provided with a multiple plug to plug into the special lathe outlet; refer to the "Wiring diagram" if necessary.


4.7 ADDITIONAL PUSH-BUTTON PANEL - INSTALLATION

Install the additional push-button panel (A) nearby the lathe push-button panel.



INFORMATION

Some equipment do not require the installation of the additional push-button panel since its functions are integrated in the lathe push-button panel.



4.8 PNEUMATIC CONNECTION


- Connect pipe (D) of the pneumatic system to the quick coupling (G).

FILTER A

- Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C). Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C).

PRESSURE SWITCH

- The filter is equipped with a control pressure switch, set to a pressure of 4.5 bar.
- To regulate the pressure switch proceed as follows:
 - remove the pressure gauge protecting glass;
 - turn the adjusting screw (G) anticlockwise (+) to increase pressure or clockwise (-) to lower it;
 - after this operation, replace the pressure gauge protecting glass.



CAUTION:

should the pressure switch needle point a Pressure=0 , do not absolutely turn the adjusting screw (H) clockwise (-) , for this will cause pressure switch breakage.


4.9 LATHE MODIFICATIONS

The lathe requires some adjustments obtained by fitting special sleeves manufactured by IEMCA.



INFORMATION

Figure shows a general example; for more details, apply to IEMCA service department.



4.10 ALIGNMENT - FINAL CHECK


When the installation is over, make sure clamp device (A) axis is aligned with the guide channel axis.

Keep to the following procedure: move the clamp device to the "bar insertion into collet" position







and close the sprockets by pressing key .




Sprockets must close without interfering with the bar pusher inserted into the clamp device.

In case of misalignment, please apply to IEMCA technical assistance department.



INDEX

5.1	SIR 52 P RACK MAGAZINE - ADJUSTMENT 	3
5.1.1	Bar selection - Adjustment.....	3
5.2	SIR 52 F BUNDLE MAGAZINE - ADJUSTMENT 	4
5.2.1	Bars drop - Quantity adjustment	4
5.2.2	Pressure foot - Adjustment	5
5.2.3	Separation push-rods - Adjustment	6
5.3	GUIDE CHANNELS - ADJUSTMENT 	7
5.3.1	Standard Working Mode	7
5.3.2	Working mode with staggered sprockets	8
5.3.3	Working mode with standard and staggered sprockets	11
5.4	BAR-PUSHER - PRELIMINARY OPERATIONS AND FITTING 	16
5.4.1	Collets - Selection and Preliminary operations	16
5.4.2	Bar-pusher - Assembly	17
5.4.3	Bar-pusher- Guide tube fitting.....	18
5.5	BARSTOCK LENGTH - ADJUSTMENT 	19
5.5.1	Remnant lenght - Adjustment for the "second feed	20
5.7	WORKING PRESSURES - ADJUSTMENTS 	21
5.7.1	Dynamic thrust (A).....	22
5.7.2	Clamps grip (B).....	23
5.7.3	Static thrust (C)	23
5.7.4	Clamps introduction force (D)	23
5.7.5	Feeding speed (E)	23
5.7.6	Best working pressure	24

5.8	OPERATING PRESSURE FOR THE "SECOND FEED" - ADJUSTMENTS 25
5.9	AIR FILTER - ADJUSTMENTS 26
5.10	SPECIAL REDUCTION PARTS 26

5.1 SIR 52 P RACK MAGAZINE - ADJUSTMENT

5.1.1 Bar selection - Adjustment


Turn the adjustment screw (B) to adjust the position of the limit stop (A) according to the bar diameter. The adjustment value (C) should be about 1 mm less than the diameter of the bar.

For bar diameters 15 to 25 mm, install guide channel (D) and fix it with the screws (E); value (F) corresponds to the bar diameter plus 1 mm.

For bar diameters 11 to 15 mm, it is recommended to install guide channel (D) though not strictly necessary.

For bar diameters over 15 mm, loosen screw (G) and remove guide channel (D).

Both guide channel (D) and support (H) are supplied with the bar feeder.




52006100108

5.2 SIR 52 F BUNDLE MAGAZINE - ADJUSTMENT

5.2.1 Bars drop - Quantity adjustment

Adjust levers stop point (A) by operating screws (B). The bars quantity shall be checked during the first selection cycles, keeping into account that bars must be arranged along a part of the belts plane of approx. 200 mm.




5.2.2 Pressure foot - Adjustment

Hexagonal and round bars

Regulate the pressure foot (A) height so that the nut (B) stays at a distance of $0,5 \div 1$ mm from the limit stop when there are some bars under the foot. Adjustment is carried out operating nuts (B) horizontally adjust the pressure foot position, in order to cover completely the bars in the selection area, thus allowing a certain number of bars to dwell whenever the stock tube lifts and unloads bars.

Use screws (C) holes and/or the double holing (D) to carry out the adjustment.

Should it be necessary, operate screws (E) so that the pressure foot plane is parallel to the belt plane.




Square bars

Regulate the pressure foot (A) height so that the nut (B) stays at a distance of $0,5 \div 1$ mm from the limit stop when there are some bars under the foot. Carry out the adjustment operating nuts (B).

The foot position must allow the first bar (F) to lift; as far as adjustment is concerned, use screws (C) holes and/or the double holing (D).

Whenever necessary, operate screws (E) so that the pressure foot surface is parallel to the belts surface.




5.2.3 Separation push-rods - Adjustment


Round and hexagonal bars

HEIGHT ADJUSTMENT

Adjust the push-rod (A) height by operating the knob (B) so that the first bar (C) remains in its position once the belts return.

DEPTH ADJUSTMENT

Adjust the push-rod (A) depth by operating knob (D) so that it is positioned between the first bar (C) and the following bar. Check the adjustments by pressing key .




Square bars

HEIGHT ADJUSTMENT

Adjust the push-rod (A) height by operating the knob (B) so that the first bar (C) is lifted just as much to be held when belts reverse the direction.

DEPTH ADJUSTMENT

Adjust the push-rod (A) depth by operating knob (D) so that it is positioned in the centre of the bar section.

Check the adjustments by pressing key .





5.3 GUIDE CHANNELS - ADJUSTMENT




DANGER - WARNING:

the following procedures must be carried out or authorized by a responsible and expert operator, who owns the selector key to carry out this procedure.

5.3.1 Standard Working Mode

- Turn  selector switch to  position and open the guard.
- Open the sprockets by pressing the  key .
- Adjust the diameter of the guide channel selecting one of the four settings as follows (fig. 10):
 - loosen pin (B);
 - screw pin (B) down into one of the positioning holes, 1,2,3 or 4;
 - make sure the pin secured correctly.
- Close sprockets by pressing  key.



INFORMATION

Diameters not included in the table

"RECOMMENDED ROUND BAR Ø" may cause vibrations and failures to the bar feeder.

It may therefore be necessary to reduce bar rotation speed.

For further information regarding work diameter, contact IEMCA Customer Service.

5.3.2 Working mode with staggered sprockets

If round bars are used, in order to improve bar guiding, all sprockets can be made to have the same outside diameter as the barstock. This working mode should only be used when strictly necessary, as it will cause an early wear of the guide channels.




DANGER - WARNING:




failure to comply with the procedure described below may cause serious damage to the bar feeder.



INFORMATION

This work mode is not used only when position 4 is selected.




- Turn the selector  switch to position  and open the guard.
- Open the sprockets by pressing the button .
- Regulate the diameter of the guide channel selecting one of the following three working positions in the following way (fig. 12):
 - loosen pin (B);
 - screw pin (B) down into one of the positioning holes, 1,2,3 or 4 or into a midposition;
 - make sure the pin secured correctly.

Set the guide channel adjustment position to a diameter immediately inferior to the diameter that would normally be selected when working in "STANDARD WORKING MODE".


EXAMPLE (with SPROCKET \varnothing 19 (d) - \varnothing 33 (c) - \varnothing 43 (b) - \varnothing 53 (a)), to load \varnothing 22 bars with a \varnothing 32 bar-pusher:

- If working in "Standard working mode" the sprocket guide must be set to position "c" (or in the \varnothing 33 guide channel, see fig. 0031), setting pin (B) in position 2 (see fig. 52006100109).
- In "Staggered Sprockets Working Mode" the guide channel must be set to position "d" (or in the \varnothing 19 guide channel, see fig. 0031), setting pin (B) in position 1 (see fig. 52006100109).




**OPERATIONS REQUIRED TO SET UP
"STAGGERED SPROCKETS WORKING MODE"**

- Set parameter 18 "Guide working mode (0-1)" to mode 1; see the "Keyboard Instruction Manual".
- Set the guide channel opening cylinder stroke as follows:
 - open rear guard (C);
 - remove fork (D) and move nose (E) axially;
 - insert the fork in the slot corresponding to the required mode according to the scheme shown in the table;



Guide channel Configuration *		Position of pin B	Slot for Fork D	Setting for staggered channel
57	53	4	--	a
46	43	3	IV	b
33	33	2	III	c
19	19	1	II	d

- Close the sprockets by pressing the  button.

(*)The configuration of the guide channel must be carried out according to the bar feeder tooling and to the lathe type.



INFORMATION:

If shaped bars (i.e. hexagonal or square bars) are loaded, revolving speed should be reduced in order to prevent premature wear and tear of the sprockets.

**INFORMATION:**

Please contact IEMCA Sales or Service Department if you need a special configuration of guide channel - bar pusher and bar.



INFORMATION

If shaped bars (hexagonal, square bars etc.) are to be machined, make sure that the guide diameter is larger than the diameter circumscribed on the profile, in order to prevent bar scraping against the sprocket edges.



INFORMATION:

In standard working mode parameter 18 "Guide working mode (0-1)" (see the "Keyboard Instruction Manual") must be set to mode 0; fork D can be positioned in any of the slots.




INFORMATION:

When working in "staggered channel" mode, only 3 settings shown in the table are selectable notwithstanding the 4 available guide channels for the smallest channel "d" cannot be staggered to a smaller channel.

5.3.3 Working mode with standard and staggered sprockets

Standard working mode


The two pairs of sprockets have the same rotation and do not move while the bar pusher is moving.



Ideal staggered channels mode


The selected channel is immediately inferior to the diameter of the bar pusher ; the bar pusher opens the passage while moving forward by causing the sprockets to rotate and be set to the next guide channel the diameter of which is larger than the selected channel.

The bar diameter larger (Picture 051) or even slightly larger (Fig.041) than the diameter of the selected channel. .



EXAMPLE (SPROCKET $\varnothing 19$ (d) - $\varnothing 33$ (c) - $\varnothing 43$ (b) - $\varnothing 53$ (a)), to machine $\varnothing 36$ bars using a $\varnothing 42$ bar-pusher:

- In "Staggered Sprockets Working Mode" the guide channel must be set to an intermediate position between "c" and "d" (that is to say that the sprocket edges create a channel of approximately $\varnothing 36$, see fig.0031), setting pin (B) to position 1• (see fig.52006100109).

**CAUTION:**


In staggered sprockets mode, do not use collets with slots that could cause accelerated wear of the sprockets IEMCA 600P. type collets.

Table 1. Standard working mode

COMPARATIVE TABLE OF MACHINING DIAMETERS (mm) FOR STANDARD OPERATION MODE									
MODEL	PIN POSITION	C Max Ø	Ø C	Ø B	Ø F	Ø A		POSITION OF THE FORK	PARAMETER 18 GUIDE CHANNEL OPERATION MODE
			Guide channel Ø	Bar pusher Ø	Engagement Ø on Rotating Tip Collet	Round bar Ø (* RECOMMENDED)			
						MIN	MAX		
SIR 52 P/F	1	53	19	18	11 G6	10	15	/	0
	2		33	32	20 G6	15	28	/	0
	3		43	42	20 G6	25	38	/	0
	4		53	52	20 G6	35	48	/	0

(*) Values of the diameter circumscribing the bar, which may be attained with IEMCA steel collets and SCHLENKER-type coupling (Table 1 summarising IEMCA collets for round bars). For shaped bars, the values must be checked according to the selected collet (Tables 2-3 summarising the collet type UNILOCK).

- A Bar diameter
- B Bar-pusher diameter or rotating tip
- C Guide channel
- F Collet engagement on rotating tip



16_125_1

Table 2. Working mode with staggered sprockets

COMPARATIVE TABLE OF MACHINING DIAMETERS (mm) FOR STANDARD OPERATION MODE (GUIDE 19-33-43-53)									
MODEL	PIN POSITION	C Max Ø	Ø C	Ø B	Ø F	Ø A		POSITION OF THE FORK	PARAMETER 18 GUIDE CHANNEL OPERATION MODE
			Guide channel Ø	Bar pusher Ø	Engagement Ø on Rotating Tip Collet	Round bar Ø (*) RECOMMENDED			
						MIN	MAX		
SIR52 P/F	1 Tra 1 e 2	52	19 19-33	18	15 G6	15	16	II	1
	2 Tra 2 e 3		33 33-43	32	20 G6	16	29	III	1
	3 Tra 3 e 4		43 43-53	42	20 G6	30	38	IV	1
	4		53	52	20 G6	35	48	-	0


Table 2. Working mode with staggered sprockets

COMPARATIVE TABLE OF MACHINING DIAMETERS (mm) FOR STANDARD OPERATION MODE (GUIDE 19-33-43-57)									
MODEL	PIN POSITION	C Max Ø	Ø C	Ø B	Ø F	Ø A		POSITION OF THE FORK	PARAMETER 18 GUIDE CHANNEL OPERATION MODE
			Guide channel Ø	Bar pusher Ø	Engagement Ø on Rotating Tip Collet	Round bar Ø (*) RECOMMENDED			
						MIN	MAX		
SIR 52 P/F	1 Tra 1 e 2	57	19 19-33	18	15 G6	15	16	II	1
	2 Tra 2 e 3		33 33-46	32	20 G6	16	29	III	1
	3 Tra 3 e 4		46 46-53	45	20 G6	30	42	IV	1
	4		57	56	20 G6	42	52	-	0

(*) For shaped bars, values must be checked according to the selected collet (Tables 2-3 summarising the IEMCA 600P collet type).

- A Bar diameter
- B Bar-pusher diameter or rotating tip
- C Guide channel
- F Collet engagement on rotating tip

Values shown in the table are based on two conditions:



1. According to the instructions of the collet manufacturer, the outer side of the collet must be at least 1 mm thick.
2. Sprockets are on their intermediate position (edges in contact with the bar) forming thus a channel the diameter of which is approximately 1 mm smaller than the guide channel diameter resulting from sprocket standard rotation.

1• = 19/33

2• = 33/43(46)


3• = 43/53(57)

1 = 19

2 = 33

3 = 43(46)

4 = 53(57)




5.4 BAR-PUSHER - PRELIMINARY OPERATIONS AND FITTING

5.4.1 Collets - Selection and Preliminary operations

- A Round bars: see enclosed tables.
- B Hexagonal bars: use a drill with a diameter 1 mm approx. less than the sharp edges diameter (see enclosed tables).
- C Square bars: use a drill with a diameter 1.5 mm approx. less than the sharp edges diameter (see enclosed tables).


Check the introduction force into collet by using a bar remnant. The force value must be 40÷60 kg; in case of exceeding value, shorten the rear polyurethane length of 5 mm at a time.



5.4.2 Bar-pusher - Assembly

SIR 52 P/F - Ø 18÷52

- Introduce slightly clutch unit (A) into rod (B) seat, turn up to obtain a small yielding and complete the insertion.
- Insert collet (C) into rod (B) seat, insert pin (D) until the clutch is engaged.






5.4.3 Bar-pusher- Guide tube fitting





DANGER - WARNING:

the following procedure has to be carried out by the responsible skilled technician, who also owns the key of the selector switch allowing this operation to be done.










Bring selector  switch to position  and open the guard.

Bar feeder with bar loading in the 6th station

- Open sprockets by pressing key .
- Fit the bar-pusher (A) of suitable diameter into seat (B) of the feeding carriage.
- Close sprockets by pressing key .
- Carry out said operation in the other guide tubes.


Bar feeder with bar loading in the 1st station

- Introduce bar pusher (A) into the clamps arm housing.
- Press the key  to lock the bar-pusher carriage.
- Open sprockets by pressing key .
- Press the key  in order to rotate the clamp arm towards the drum.
- Close sprockets by pressing key .
- Press the key  in order to release the bar-pusher locking.
- Press the key  in order to feed the bar-pusher of 150/200 mm.
- Press the key  to rotate the clamp arm outside the drum.
- Carry out said operation in the other guide tubes.

5.5 BARSTOCK LENGTH - ADJUSTMENT

To determine the remnant length, adjust the end-of-bar device in the following way.

- Loosen the knob (A) on the sensor mounting.
- Use the position indicator (B) to shift the sensor position up to the value corresponding to the length of the workpiece plus the width of the cutting tool.
- Tighten the knob (A).



CAUTION:

To avoid damages to the structures, check block (B) position whenever changing the lathe collet or the bar pusher diameter.



INFORMATION:

The max. length allowed for workpiece + width of the cutting tool is 160 mm, corresponding to position "C". Please contact IEMCA Sales or Service Department in case a longer length is required.

5.5.1 Remnant lenght - Adjustment for the "second feed"

If the "second feed" function is enabled, adjust the lower bar end device which is located in the default second feed position (according to the lathe the bar feeder is added to). Follow the steps under paragraph 5.5.


5.6 Loading bar diameter 15 to 30 mm

If the diameter of the bars to be loaded is between 15 and 30 mm, tighten the screw (a) on the lever (B).



PRECAUTION WARNING:

Before loading bars over 30 mm diameter, the screw (A) must be removed.



5.7 WORKING PRESSURES - ADJUSTMENTS 

Table 2. Working pressures (bar) table

Bar diameter (mm)	A Dynaminc thrust	B Clamps grip	C Static thrust	D Introduction force
20	40	55	5	27
30	50	60	5	29
40	60	65	5	31
52	70	70	5	33



INFORMATION


Values in the table are indicative only and they apply to round steel bars. Values may change according to the material machined, to the bar profile and to lather specifications (collet opening time, barstock length, etc.).

5.7.1 Dynamic thrust (A)

Table 3. Dynamic thrust (A)

Dynamic thrust pressure (bar)	Theoretical Thrust of the Bar pusher (N)
80	1250
70	1210
60	1140
50	1000
45	900
40	810
35	750
30	700

The dynamic thrust is the force through which the bar-pusher carriage feeds the bar. It works on the feeding station. To adjust it, operate knot (A).



5.7.2 Clamps grip (B)

The clamps grip is the force through which clamps hold the bar during the introduction phase into collet.

To carry out adjustment, operate knob (B).

5.7.3 Static thrust (C)

The static thrust is the force through which the bar-pusher continuously press against bars. It operates in every station, with the exception of the loading stations.

To carry out adjustments, operate knob (C).



INFORMATION

Usually, the static thrust must remain at a value of 5 bar, therefore it does not require any adjustment.

5.7.4 Clamps introduction force (D)

The force of introduction is the force through which the bar is introduced into the bar-pusher collet and the bar remnant is extracted.

To carry out adjustment, operate knob (D).

5.7.5 Feeding speed (E)

The feeding speed is the speed at which the bar feeds at each lathe opening.



CAUTION:

A too high feeding speed may cause damage to lathe equipment.

A too low feeding speed may cause the collet to close before the complete feed of bar.

To carry out adjustment, operate knob (E).

5.7.6 Best working pressure

The value of the optimal operating pressure of the pumps must be adjusted at 70 bars with hot oil (at about 50° C).



To adjust it, loosen the lock nut (A) (fig. 24) and tighten or loosen the screw (B).

To check that the value has been reached, open cock (C) and read the value on the pressure gauge (D).



CAUTION:


in order to prevent the pressure gauge from undergoing sudden pressure changes, keep cock (C) closed.



5.8 OPERATING PRESSURE FOR THE "SECOND FEED" - ADJUSTMENTS

If the bar feeder is equipped with a "second feed" function, then you must adjust the pressure of each of the knobs as described below, bearing in mind its function.

- A DYNAMIC THRUST: takes place in the first feeding channel, see paragraph 5.7.1.
- B Clamp connection: see paragraph 5.7.2.
- C DYNAMIC THRUST: takes place in the second feeding channel, see paragraph 5.7.1.
- D CLAMP FEEDING POWER: see paragraph 5.7.4.
- E BAR FEEDING SPEED: takes place in the first feeding channel, see paragraph 5.7.5.
- F BAR FEEDING SPEED: takes place in the second feeding channel, see paragraph 5.7.5.



5.9 AIR FILTER - ADJUSTMENTS


PRESSURE SWITCH

- The lubricator is equipped with a control pressure switch, set to 4.5 bar.
- remove the pressure gauge protecting glass;
- turn the adjusting screw (G) anticlockwise (+) to increase pressure or turn it clockwise (-) to reduce it;
- after this operation, replace the pressure gauge protecting glass.



CAUTION:

should the pressure switch needle indicate Pressure=0 , never turn the adjusting screw (H) clockwise (-) , for this will cause pressure switch to break.




5.10 SPECIAL REDUCTION PARTS

According to the diameter of the guide tube, it is necessary to install suitable special reduction parts.

- Open the rear cover and pull the feeding drum backward.
- Pull the nose (B) ring nut (A) backward and remove it.
- Add the special parts and repeat these operations in inverted order.




Fig. 27 shows a general example, since each lathe brand is supplied with its own special reduction parts.


For further details, apply to IEMCA service department.




16_062_1

INDEX










6.1	PUSH BUTTON PANEL - CONTROL DESCRIPTION	2
6.2	ADDITIONAL PUSH-BUTTON PANEL - CONTROL DESCRIPTION	8
6.3	MAGAZINE PUSH-BUTTON PANEL - CONTROL DESCRIPTION	9
6.4	LUMINOUS INDICATOR - SIGNAL DESCRIPTION	10
6.5	STARTING THE BAR FEEDER	11
6.5.1	Cold start	11
6.5.2	Hot start.....	11
6.6	BARS TO BE MACHINED - CHARACTERISTICS AND PREPARATION	12
6.6.1	BAR STRAIGHTNESS - Measurement	14
6.7	BARSTOCKS - LOADING	16
6.8	PROGRAMMING - PARAMETERS ENTRY 	18
6.9	WORKING DIAMETER CHANGE - OPERATIONS SEQUENCE 	18
6.9.1	Changing the machining diameter without the stock guide tube diameter change	19
6.9.2	Change of the working diameter without changing the guide tube diameter	21
6.10	BAR FEEDER STOP.....	22
6.11	EEPROM LOADING PROCEDURE 	23
6.11.1	Cold start	23

6.1 PUSH BUTTON PANEL - CONTROL DESCRIPTION


- A Main controls.
- B Controls for manual operation.
- C Display controls and LEDs.




MAIN CONTROLS

- 1 Green lighted push-button; it starts the feeder.
- 2 Red push-button; it stops the feeder.
- 3 Key-operated two-position selector
 - Position : the push-button panel is enabled for the "message display" mode.
 - Position : push-button panel enabled to data entering mode.
- 4 Key-operated two-position selector
 - Position : bar feeder enabled to automatic or manual operation.
 - Position : only controls      enabled, with open guards as well.
- 5 Emergency push-button; it stops the feeder. The feeder can be restarted only after the push-button has been manually released.

PROGRAMMING AND MANUAL FUNCTIONS CONTROLS




- F1 Key to open / close guide channels only in the area of bar pusher completely backwards. Press it to control operation, press it again to control return.
- F2 Key to open / close bar pusher locking. Press it to control operation, press it again to control return.
- F3 Key to open / close guide channels. Press it to control operation, press it again to control return.
- F4 Key to open / close clamps. Press it to control operation, press it again to control return.
- F5 Key for bar insertion / extraction. Press it to control operation, press it again to control return.
- F6 Key for bar holder lever rotation upwards / downwards. Press it to control operation, press it again to control return.
- F7 Key for clamp arm rotation towards drum. It controls the device in only one direction. Press push-button till position is reached. If push-button is released in advance, the device comes back to starting position.
- F8 Key for clamp arm rotation outside drum. It controls the device in only one direction.
- F9 Key for lever arm rotation towards drum. It controls the device in only one direction. Press push-button till position is reached. If push-button is released in advance, the device comes back to starting position.




36_003_0

- F10 Key for lever arm rotation outside drum.
It controls the device in only one direction.
- F11 Key for manual bar pusher movement backwards at low speed.
- F12 Key for manual bar pusher movement forwards at average speed.
- F13 Key to select bar feeder manual operation.
- F14 Key to select bar feeder automatic operation.
- F15 Key for bar feeding on selection belts.
SIR 52 F only.
- F16 Key for bar return on selection belts.
SIR 52 F only.
- F17 Key for lever movement upwards / downwards.
Press it to control operation, press it again to control return.
SIR 52 F only.
- F18 Key for selection push-rod movement upwards / downwards.
Press it to control operation, press it again to control return.
SIR 52 F only.
- F19 Key to switch on / off inner lighting lamp.
Push it to control switching on, push it again to control switching off.
- F20 Key to recall "MAIN MENU".

DISPLAY CONTROLS AND LEDS



- 1 Key for numerical value 1.
- 2 Key for numerical value 2.
- 3 Key for numerical value 3 and to access the date and hour programming mode.
- 4 Key for numerical value 4.
- 5 Key for numerical value 5.
- 6 Key for numerical value 6 and to access protected parameter entering mode.
- 7 Key for numerical value 7.
- 8 Key for numerical value 8.
- 9 Key for numerical value 9.
- 10 Key for numerical value 0 or to recall selection cursor.
- 11 Key for "minus" or "plus" sign.
- 12 Key for "comma" sign.
- 13 Key for "CLEAR" function:
 - to stop selection function,
 - to return to the value which had been displayed before the non-confirmed modification,
 - to return to displayed screen after date and time programming.
- 14 Key for "ENTER" function to confirm entered data.
- 15 Key to recall the previous parameter or to move the selection cursor left.
- 16 Key to recall the next parameter or to move the selection cursor right.
- 17 Key to scroll page upwards or to move selection cursor upwards or to increase by one the value in the date and hour programming mode.
- 18 Key to scroll page downwards or to move selection cursor downwards or to decrease by one the value in the date and hour programming mode.
- 19 Red LED:
 - OFF mode - indicates that there is no signal on the display;
 - ON mode - indicates that there is a signal on the display.
- 20 Green LED: BLINK mode - signals that the display does not interact with the PLC correctly;
- ON mode - signals that the display interacts with the PLC correctly.



21 LED not enabled.

22 Green LED:

OFF mode - signals that the display is not active;

ON mode - signals that the display is active.

23 Green LED:

OFF mode - signals that no key is pressed;

ON mode - signals that any key is pressed.

Red LED:

status BLINK - indicates that the keyboard battery needs to be replaced (refer to Chapter 9 for instructions on how to replace it);

ON state - indicates serious problems in the keyboard.

24 Key not enabled.

25 Display.



INFORMATION

To obtain all the instructions on the programming of the bar feeder refer to the "Push-Button Panel Instruction Manual".


6.2 ADDITIONAL PUSH-BUTTON PANEL - CONTROL DESCRIPTION



INFORMATION

Some bar feeder models are not supplied with the additional push-button panel, since its functions are integrated in the lathe functions.

- 1 Push-button with luminous pilot light (red)
It activates and deactivates the bar feeding.
on: the bar feeding is deactivated;
off: the bar feeding is activated.
- 2 Push-button with luminous pilot light (red)
It activates and deactivates the bar loading.
on: the bar is not loaded in the drum. The lathe machines all bars in the drum then stops;
off: bars are loaded in the drum.
- 3 Push-button enabling the "Slow backwards" manual bar-pusher motion.
- 4 Push-button enabling the "Slow forwards" manual bar-pusher motion.
- 5 Luminous pilot light push-button (white)
It activates and deactivates the bar feeder automatic function
on: the automatic function is enabled;
off: the automatic function is disabled.
- 6 Luminous pilot light push-button (white)
It activates and deactivates the bar feeder manual function
on: the manual function is activated;
off: the manual function is deactivated.
- 7 Red push-button; it stops the feeder.
- 8 Green lighted push-button; it starts the feeder.
- 9 Emergency push-button; it stops the feeder. The feeder can be restarted only after the push-button has been manually released.
- 10 Bar loading lathe collet open/close push-button.




6.3 MAGAZINE PUSH-BUTTON PANEL - CONTROL DESCRIPTION

SIR 52 P

- 1 MAGAZINE CONTROL SELECTOR (2 positions)
POSITION 0: the magazine is pre-set for the manual bars loading;
POSITION 1: the magazine is pre-set for the bar feeder automatic function.
- 2 LUMINOUS PILOT LIGHT (orange)
When it blinks means that the magazine is carrying out the loading cycle.
- 3 EMERGENCY PUSH-BUTTON; it stops the feeder. The feeder can be restarted only after the push-button has been manually released.


SIR 52 F

- 4 MAGAZINE COMMAND SWITCH (2-position)
POSITION 0: the magazine is pre-set for the manual lowering of belts in order to carry out the loading;
POSITION 1: the magazine is pre-set for the bar feeder automatic function.
- 5 MANUAL LOWERING OF THE MAGAZINE BELTS PUSH-BUTTON
BY PRESSING IT: the belts lower. By keeping the push-button pressed, the belts completely unwind until they disappear into their seats.
BY RELEASING IT: the belts stop.
- 6 EMERGENCY PUSH-BUTTON; it stops the feeder. The feeder can be restarted only after the push-button has been manually released.



6.4 LUMINOUS INDICATOR - SIGNAL DESCRIPTION

- A RED LIGHT;
signals that the bar feeder is not operating, or that it is in the manual mode.
- B GREEN LIGHT;
it indicates that the bar feeder is in the automatic mode.
- C BLUE LIGHT;
signals that the bar feeder is carrying out the bar change.
- D ORANGE LIGHT;
it indicates that magazine safety guards are open (Master 880 P) or removed (Master 880 F).



6.5 STARTING THE BAR FEEDER

There are different procedures to start the bar feeder, depending on the hydraulic oil temperature:

- cold start (paragraph 6.5.1);
- hot start (paragraph 6.5.2).


6.5.1 Cold start

Cold start occurs according to two different procedures.


ADVANCED AUTOMATIC START

Program the advanced automatic start following the procedures described in the "Push-button panel operation and instruction manual", paragraph "Operator's parameters - description and entering".

MANUAL START

- Make sure that all guards are closed and the emergency push-buttons are not pressed.
- Turn the main electric switch to "I".
- Start the lathe.
- Press push-button  to start the bar feeder, keeping it pressed for 15 seconds, until the green light of the luminous indicator temporarily switches on.
This procedure allows valve (EV317) to close; it will remain closed for 45 minutes, thus allowing a faster hydraulic oil heating.

6.5.2 Hot start

- Make sure that all guards are closed and the emergency push-buttons are not pressed.
- Turn the main electric switch to "I".
- Start the lathe.
- Press push-button  to start the bar feeder.

6.6 BARS TO BE MACHINED - CHARACTERISTICS AND PREPARATION

**CAUTION:**

do not feed bars having different sizes than the manufacturer's prescribed sizes.

Table 1. Maximum bar length

Models	Version	Max. length (mm)	Min. length (mm) *
SIR 52 P SIR 52 F	33	3300	2500
	38	3800	3000
	43	4300	3000

**INFORMATION:**

() bars are to be loaded in the middle of the bundle magazine.*


**INFORMATION:**

Bar must not present a straightness defect above 0.5 per 1000.


Please find herewith some advice to optimise the bar feeder performances.
Usually barstocks do not need any preliminary operations to be carried out on ends,
nevertheless to obtain the best results when loading them, it is advisable to chamfer them.

SOLID BARS


Check that there is not too much rag on bar head, which might hinder insertion in the lathe collet. Check that there is not too much rag on bar rear end, which might hinder insertion in the bar-pusher collet. In any case, to improve operation during this phase, we advise to chamfer the bar as shown in the figure.



If bars with front remnant ejection have to be machined, we advise to chamfer the bar rear end as shown in the figure.




If bars have to be machined having a diameter equal to or only slightly smaller than the bar-pusher diameter, bar rear ends should be machine-turned; diameter "D" should be suitable for the collet size installed in the bar-pusher.



PIPES

If pipes have to be machined, their rear ends should be chamfered as shown in the figure.




6.6.1 BAR STRAIGHTNESS - Measurement

The bar vibrations are partially caused by the condition of the bar itself: in case the bar is not perfectly straight, this can cause vibrations.

Round bars

As stated also in the UNI-10233/2 regulation, the bar straightness can be measured by positioning the bar on two V-supports and control its straightness. In that case, the measurement can be carried out as shown in the figure.

It is necessary to rotate the bar on itself and measure the three indicated sections. In this case the S-max value (difference between maximum and minimum reading on the comparator) should be interpreted as follows:



S max	Quality
< 0,25 mm	Good
0,25 < S max < 0,5 mm	Mediocre
> 0,5 mm	Problematic

In order to obtain a reliable value it is necessary to repeat measurements on the whole bar length by positioning it on a series of supports at a distance of 500 mm from each other and comparing the different values between prisms.



INFORMATION:

Obviously, bar straightness is proportional to the rigidity of the material and to the number of revolutions (RPM) the lathe is operated at. highly The lack of bar straightness highly influences the maximum number of revolutions reachable: the bigger the diameter the greater the influence. The data concerning bar straightness do not absolutely refer to local inflection and/or deformation that the bar shall not absolutely show. Instead, they refer to the bar uniform curvature.




INFORMATION:

For efficient operation of the feeder the use of rolled bar stock is not recommended.

Hexagonal, square and section bars

For non-round bars, insert some bushings on the bar to be controlled.
 Position 2 bushings on the 2 V-supports.
 In that case, the measurement can be carried out as shown in the figure.
 Rotate the bar on itself and carry out the measurement on a bushing external to the two V-supports.



INFORMATION:

The use of polygonal bars (hexagonal bars, square bars, etc.) is allowed but you should keep in mind that this will lead to:

- excessive wear and tear on the guide channel (wear and tear due to the use of round bars is reasonable).*
- bar rotation speed reduction (in comparison with round bars).*


Excessive wear and tear on the guide channel is due to the shape of bars as well as to material straightness and stiffness.

6.7 BARSTOCKS - LOADING

In accordance with the two different models, loading occurs as follows.

SIR 52 P

1 Start the bar feeder

2 The selector  must be positioned on 0. The

luminous pilot light  emits a persistent light, wait until it becomes flickering.

3 Open the case and manually load the magazine plane with bars up to its filling (A).



DANGER - WARNING:


Do not manually lift loads exceeding 15 kg.

4 Close the case.

5 Bars are drawn from the feed chain.

6 When the luminous pilot light emits a flickering light again, operations 3,4 and 5 have to be repeated.

7 Carry out the above mentioned operations up to the complete filling both of the magazine and feed chain (B).


8 When the selector  is positioned on 1, the luminous pilot light is off; hence, the magazine is ready to feed the drum.



During the setting up operations of drum or other device, the selector must be





positioned on 0; should the feeding chain be unloaded, it stops after approx. 35 sec.




SIR 52 F

1 Start the bar feeder.

2 Position the selector  on 0 .

3 Press the  push-button to lower belts completely.

4 Feed the bars using a bridge crane or a lifting carriage.



INFORMATION

Bars are to be loaded in the middle of the bundle magazine.




CAUTION:

Do not load bars having sizes different from those suggested by the manufacturer.



DANGER - WARNING:

Make sure the lifting device has a suitable capacity.

5 Position the  selector on 1; the magazine is ready to feed the drum.

6.8 PROGRAMMING - PARAMETERS ENTRY

The entering of parameters is necessary to program the automatic cycle of the bar feeder, according to the working requirements and to the machine type.
For more detailed instructions, see the "Push-button panel operation and instruction manual".

6.9 WORKING DIAMETER CHANGE - OPERATIONS SEQUENCE

The operations for the machining diameter change have to be done on the basis of the previous machining and in relation to the following machining; see "COMPARATIVE TABLE OF THE WORKING DIAMETERS" (paragraph 5.3.).



















If the stock guide tube diameter has to be replaced, you need to follow the procedure explained in paragraph 6.9.1; otherwise, follow the procedure explained in paragraph 6.9.2.
















DANGER - WARNING:


















During the working diameter change operations, do not open the machine doors when it is running and do not manually turn the lathe spindles when drum guide is open.

6.9.1 Changing the machining diameter without the stock guide tube diameter change

- 1 Once all bars in the drum are ended, stop the lathe with the collet open.
- 2 Press the key  in order to move the bar-pusher back to its limit switch (backwards).
- 3 Deactivate the automatic carriage feeding through the  key or other control.
- 4 Press the , key in order to actuate the rotation of one of the lathe spindles station and carry out these operations in order to release the spindles from the remaining bars.
- 5 Press push-button  to stop the bar feeder.
- 6 Open the rear hatch.
- 7 Release the drum locking lever by pressing it downwards and manually pull the drum up to its stop. (approx. 65 cm).
- 8 Remove the sleeves (§ 5.10.).
- 9 Remove the lathe collets and reassemble the new collets suitable to the profile of the new barstock.
- 10 Assemble the sleeves with the reductions supplied, if any.
- 11 Place the drum in working position, pushing it carefully and making sure there is no jamming.
- 12 Lock the drum by means of its relevant lever and close the rear hatch.
- 13 Position the magazine control selector on "0".
- 14 Remove from the magazine the remaining bars.
- 15 Prepare the new bars (§ 6.6.).
- 16 Feed the bars (§ 6.7.).
- 17 Adjust the magazine (§ 5.1. and 5.2.).
- 18 Press the push-button  to start the bar feeder.
- 19 Position the magazine control selector on "1".
- 20 Press the  key in order to feed the bar-pusher of 200/300 mm.
- 21 Press the  key in order to rotate the clamp arm towards the drum.
- 22 Press the  key to position the bar-pusher at its limit switch.
- 23 Press the  key to lock the bar-pusher carriage.
- 24 Press the  key to open the guides.
- 25 Press the  key to rotate the clamp arm outside the drum.
- 26 Press the  key to close clamps.
- 27 Press the  key to extract the bar remnant.
- 28 Press the  key to open clamps; the bar remnant thus released will drop.
- 29 Push the  button to bring the clamp unit into operating position.
- 30 Turn the  switch in  position.
- 31 Manually open the lateral case in the clamps area.
- 32 Press the  key in order to release the bar-pusher locking.


- 33 Remove the bar-pusher to be replaced and place the rear rotating unit into the new bar-pusher.
- 34 Assemble the suitable collet by means of a standard bar remnant previously introduced into the collet and position the new bar-pusher in the same housing of the previous bar-pusher.
- 35 Press the  key to lock the bar-pusher carriage.
- 36 Adjust the guide channel at the desired diameter by using the "Standard Operation Mode" or the "Staggered Sprockets Operation Mode" (paragraph 5.3.).
- 37 Push the  button to close the guides.
- 38 Close the lateral case.
- 39 Turn the  switch in  position.
- 40 Press the  key to open guides.
- 41 Press the  key to rotate the clamp arm towards the drum.
- 42 Press the  key to close guides.
- 43 Press the  key to open the bar-pusher locking.
- 44 Press the  key to feed the bar-pusher; position the bar-pusher into the spindle and the bar remnant into the collet and its relevant carriage in the bar end area.
- 45 Press the  key to rotate the clamp arm outside the drum.
- 46 Press the  key.
- 47 Rotate the lathe spindle of any station whatsoever up to the OPEN COLLET position.
- 48 Press the  key.
- 49 Repeat all the operations from number 21 up to number 43 in the same sequence to replace all the bar-pushers.
- 50 Press the  key.


6.9.2 Change of the working diameter without changing the guide tube diameter

- 1 End all bars in the drum and stop the lathe with the collet open.
- 2 Press the  key to move the bar-pusher back to its limit switch (backwards).
- 3 Deactivate the automatic carriage feeding through the  key or other control.
- 4 Press the  key in order to actuate the rotation of one of the lathe spindles station and carry out these operations in order to release all spindles from the remaining bars.
- 5 Press push-button  to stop the bar feeder.
- 6 Open the rear hatch.
- 7 Unhook the drum lever by pressing it downwards and manually pull the drum up to the stop (approx. 65 cm).
- 8 Remove sleeves (§ 5.10.).
- 9 Disassemble the spindle collets and assemble the new collets suitable to the new bar profile.
- 10 Assemble the sleeves using the reductions supplied, if any.
- 11 Place the drum in working position, pushing it carefully and making sure there is no jamming.
- 12 Lock the drum with the suitable lever and close the rear hatch.
- 13 Position the magazine control selector on "0".
- 14 Remove all the remaining bars from the magazine.
- 15 Prepare the new barstocks (§ 6.6.).
- 16 Feed the barstocks (§ 6.7.).
- 17 Adjust the magazine (§ 5.1. and 5.2.).
- 18 Press the  key to start the bar feeder.
- 19 Position the magazine control selector on "1".
- 20 Press the  key to feed the bar-pusher of 200/300 mm.
- 21 Press the  key to rotate the clamp arm towards the drum.
- 22 Press the  key to position the bar-pusher to the limit switch.
- 23 Press the  key to lock the bar-pusher carriage.
- 24 Press the  key to open guides.
- 25 Press the  key to rotate the clamps bar outside the drum.
- 26 Press the  key to close clamps.
- 27 Press the  key to extract the bar remnant.
- 28 Press the  key to open clamps; bar remnant thus released will drop.
- 29 Push the  button to bring the clamp unit into operating position.
- 30 Turn the  switch in  position.
- 31 Manually open the lateral case in the clamps area.
- 32 Disassemble the collet and assemble the new collet with a standard bar remnant of the new bar introduced.


33 Close the lateral case.





34 Turn the  switch in  position.


35 Press the  key to rotate the clamp arm towards the drum.

36 Press the  key to close guides.


37 Press the  key to unlock the bar-pusher carriage.

38 Press the  key to feed the bar-pusher; place the bar-pusher inside the spindle and the bar remnant in the collet with the carriage in the bar end area.


39 Press the  key to rotate the clamp arm outside the drum.

40 Press the  key.

41 Rotate the lathe spindle of any station whatsoever up to the OPEN COLLET position.

42 Press the  key.

43 Repeat all the operations from No. 21 to No. 38 up to the complete replacement of all bar-pushers.


44 Press the  key.

6.10 BAR FEEDER STOP



CAUTION:

Do not stop the bar feeder through the emergency push-button unless necessary.

- Finish the operations provided for by the working program.
- Stop the bar feeder by pressing the  key.
- Stop the lathe.
- Position the main switch on "0".

6.11 EEPROM LOADING PROCEDURE


In case of programme deletion or eeprom replacement, the programme needs to be loaded again by adopting the following procedure.



INFORMATION

The procedure is appropriate for 1AE04 version CPUs and the subsequent versions (example: 1AE05, 1AE06, etc.).

- Power the bar feeder.
- Disconnect the CPU by turning selector A to position (fig. 10).
- Position selector (B) on RUN-P.
- Power the CPU by turning selector A to position . Wait until the STOP (C) light starts flashing.
- Position selector (B) on MRES, and keep it in that position until the STOP (C) warning light stops flashing and remains constantly on.
- Turn selector (B) to position RUN. If the procedure has been followed correctly, the RUN (D) warning light should flash for a while and then remain constantly on, and the programme should be loaded.



CAUTION:

After loading the programme, the parameters are to be reset; call the IEMCA Service Department.

6.11.1 Cold start


Cold start occurs according to two different procedures.

ADVANCED AUTOMATIC START

Program the advanced automatic start following the procedures described in the "Push-button panel operation and instruction manual", paragraph "Operator's parameters - description and entering".

MANUAL START

- Make sure that all guards are closed and the emergency push-buttons are not pressed.

- Turn the main electric switch to "I".
- Start the lathe.
- Press push-button  to start the bar feeder, keeping it pressed for 15 seconds, until the green light of the luminous indicator temporarily switches on.
This procedure allows valve (EV317) to close; it will remain closed for 45 minutes, thus allowing a faster hydraulic oil heating.

INDEX

7.1	MAINTENANCE - GENERAL INSTRUCTIONS 	2
7.2	MAINTENANCE - SCHEDULED MAINTENANCE TABLE 	3
7.2.1	SIR 52 F Bar stop clutch - Adjustment	4
7.2.2	SIR 52 F translation belts - Tightening	4
7.2.3	SIR 52 F Pins bushings - Lubrication	5
7.2.4	SIR 52 P torque limiter - Adjustment	5
7.2.5	SIR 52 P bar lifting chain - Tightening	6
7.2.6	SIR 52 P bar translation chain - Tightening	6
7.2.7	SIR 52 P motor chain - Tightening	7
7.2.8	Chain feeding belt - Tightening	7
7.2.9	Feeding drum - Bearings end play adjustment	8
7.2.10	Loading levers - Adjustment	8
7.2.11	Clamps device and bar-pusher locking - Alignment check	9
7.2.12	Hydraulic joint - Check	9
7.2.13	Clamps - Sharpening and adjustment	10
7.2.14	Lubricating oil - Level check	10
7.2.15	Lubricating oil - Filters cleaning	11
7.2.16	Lubricating oil - Change	13
7.2.17	Hydraulic oil - Level check	13
7.2.18	Hydraulic oil - Filter maintenance	14
7.2.19	Hydraulic oil - Change	16
7.2.20	Air filter unit - Check	17
7.3	LUBRICATING/HYDRAULIC OIL - COMPARATIVE TABLE 	18
7.4	PREPARING THE BAR FEEDER FOR MAINTENANCE TO THE LATHE 	19

7.1 MAINTENANCE - GENERAL INSTRUCTIONS

Regular cleaning and maintenance are critical to ensure smooth operation and longer machine service life.

It is recommended to regularly and effectively clean the machine, its accessories and work area, which also increases operator's safety.

Do not use petrol or other detergents which might spoil painting, transparent parts, cable sheaths, etc.

To protect the bar feeder when you expect not to use it for long periods of time, disconnect it from mains voltage and from compressed air supply and cover it with a suitable protective sheet.



DANGER - WARNING:

Oxidation may cause damages either to the metallic parts or to electric equipment.

Any protective cover must not be completely sealed at the base and must be provided with air inlet holes, to prevent the humidity inside the cover from condensing due to an air circulation deficiency.

Said condensation might oxidise the metallic parts and damage the electric equipment.

7.2 MAINTENANCE - SCHEDULED MAINTENANCE TABLE 

Table 1.Scheduled maintenance


BAR FEEDER MODEL	BAR FEEDER SECTION	OPERATIONS TO BE CARRIED OUT	HOURS FREQUENCY			
			50	200	1250	2500
SIR 52 F	Bundle	Check the lifting belts wear		•		
		Adjust the bar stop clutch.			•	
	Bars translation	Tighten the translation belts.			•	
		Check the translation belts wear.				• (*)
		Lubricate pins bushings.			•	
SIR 52 P	Bars lifting and translation	Check and adjust the torque limiter whenever necessary.				•
		Check and tighten the bar lifting chain whenever necessary.		•		
		Check and tighten the bar translation chain whenever necessary.			•	
		Check and tighten the motor chain whenever necessary.			•	
SIR 52 P SIR 52 F	Bar loading	Check and whenever necessary replace the bar loading levers rollers.				•
	Carriage feeding	Tighten the belt.		•		
	Guides	Check and replace sprockets whenever necessary.			•	
		Verificare la scorrevolezza tra i rocchetti e le cremagliere		•		
	Clamps device	Check and sharpen clamps whenever necessary.			•	
	Lubricating system	Check the oil level.	•			
		Clean the oil filter.			•	
		Check the delivery pipes.				•
		Change the hydraulic oil.	once a year			
	Hydraulic system	Check the oil level.		•		
		Clean the oil filter.			•	
		Check the oil pipes.				•
		Change the hydraulic oil.	once a year			
Keyboard	Replace the battery	once a year				
PLC	Replace the battery	once a year				

(*) Should the standard belts wear excessively due to oil, chipping or sharp bars, it is advisable to assemble polyurethane belts supplied upon request.

7.2.1 SIR 52 F Bar stop clutch - Adjustment


Should the bar stop clutch fail to work properly, adjust it as follows.

- | | |
|--------------|--|
| Left clutch | Tighten ring nut (A) tightening it by means of the counternut. |
| Right clutch | Loosen the three nuts (B).
Equally tighten the three screws (C) so that disk (D) may progress in parallel with the counter disk.
Tighten the three nuts (B). |




7.2.2 SIR 52 F translation belts - Tightening

- Loosen screw (A) (fig. 2).
- Tighten the belt by manually pressing the pulley.
- Tighten screw (A).
- Repeat the operation to tighten the other belts whenever necessary.



7.2.3 SIR 52 F Pins bushings - Lubrication


Lubricate the pins bushings (see areas displayed in bold type, fig. 3).



7.2.4 SIR 52 P torque limiter - Adjustment


The bar lifting device is equipped with a torque limiter which actuates should the device fail to work properly. To adjust it:

- The magazine must be completely loaded (paragraph 6.7.) with barstock of the max. diameter.
- Loosen the nuts of sensor (A) in order to remove it from disk (B) (fig. 4).
- Disassemble the disk by loosening screw (C).
- Loosen screw (D).
- Completely loosen ring nut (E). When the bar feeder is started, the torque limiter slides.
- Stop the bar feeder and tighten ring nut (E) step by step, making attempts up to the bar lifting device is restored.
- Tighten screw (D).
- Reassemble the disk and the sensor.




7.2.5 SIR 52 P bar lifting chain - Tightening

- Loosen screws (A) (fig. 5) and nut (B).
- Tighten screw (C).
- Tighten screws (A) and nut (B).
- Whenever necessary, repeat the operation to tighten the other chains.




7.2.6 SIR 52 P bar translation chain - Tightening

- Loosen ring nut (A) (fig. 6).
- Turn the pinion eccentric pin (B).
- Tighten ring nut (A).
- Whenever necessary, repeat the operation in order to tighten all other chains.




7.2.7 SIR 52 P motor chain - Tightening

- Loosen screw (A) (fig. 7).
- Tighten the chain by pressing manually pinion (B).
- Tighten screw (A).



7.2.8 Chain feeding belt - Tightening

- Loosen the nut (A).
- Screw the screw (B) to tighten the chain using a torque wrench; tighten to $C = 5 \text{ N/m}$ (about 0,5 Kg/m).
- Tighten nut (A.)
- Whenever necessary, repeat the operation to tighten the other chains.




7.2.9 Feeding drum - Bearings end play adjustment

The feeding drum rotates on bearings (A) and (B) (fig. 9) placed both in the front and rear area of the bar feeder.

Adjust the end play operating bearings (B), which are supplied with eccentric pin.

End play must be of $0.15 \div 0.25$ mm.


Bearings (A) are not equipped with eccentric pin.




7.2.10 Loading levers - Adjustment


BAR FEEDER LEVERS IN PICK-UP POSITION:

Adjust the levers (B) as shown in picture "52006100115" and make sure the capacitive sensor LED lights up.



7.2.11 Clamps device and bar-pusher locking - Alignment check

Check the clamps device (A) axis (fig. 11) is aligned with the guide tube axis.
 Keep to the following procedure: move the clamp device to the "bar insertion into collet" position and close the sprockets by pressing key . Sprockets must close without interfering with the bar pusher inserted into the clamp device.
 In case of misalignment, please apply to IEMCA technical assistance department.



7.2.12 Hydraulic joint - Check

In case of troubles to the rotating joint (A) (fig. 12) apply to IEMCA technical assistance department.



IEMCA52006100104

7.2.13 Clamps - Sharpening and adjustment

Sharpening

- Untighten screws (A).
- Remove and sharpen clamps according to the sharp edges.
- Reassemble clamps.
- Tighten screws (A).



INFORMATION


If only a single clamp is sharpened, check and centre the other clamps whenever necessary.

Centring adjustment

Adjust the lower clamp position so that, once the clamps are closed, the bar (D) axis is aligned with the bar-pusher axis (E).


To adjust it:

- Loosen screw (A).
- Loosen nut (B).
- Tighten or untighten screw (C).
- Tighten nut (B).
- Tighten screw (A).



7.2.14 Lubricating oil - Level check



- The oil level must be between the minimum level MIN. and maximum level MAX.
- To top up oil, remove cover (A) and fill with lubricating oil type: class (C) CKB 100.



7.2.15 Lubricating oil - Filters cleaning


Filter under the box

- Remove box (A) and cover (B).
- Remove frame (C).
- Remove filter (D) and clean it by means of compressed air.



Suction filter

- Disconnect the drive unit, see paragraph 4.5.1
- Remove cover (E).
- Lift box (F) and clean its filter by means of compressed air.



7.2.16 Lubricating oil - Change


Replacement can be carried out by using an auxiliary pump or by means of the drain plug.

Replacement with an auxiliary pump

- Remove box (A) and cover (B).
- Remove frame (C).
- Remove filter (D).
- Empty the tank by using an auxiliary pump.
- Clean the tank bottom.
- Fill it up with lubricating oil: type class (C) CKB 100. Quantity: 170 l.


Replacement by means of the drain plug

- Disconnect the drive unit, see paragraph 4.5.1.
- Uplift the drive unit (see paragraph 4.2.) and place it on two stands.
- Unscrew the drain plug and let the oil be drained out.
- Remove box (A) and cover (B).
- Remove frame (C).
- Remove filter (D).
- Clean the tank bottom.
- Fill it up with lubricating oil: type class (C) CKB 100. Quantity: 170 l.



7.2.17 Hydraulic oil - Level check


- The level oil must be between the minimum level MIN. and the maximum level MAX.
- To top it up, whenever necessary, remove cap (B) and fill with hydraulic oil: type class (C) HG 32.



7.2.18 Hydraulic oil - Filter maintenance


SUCTION FILTER

- Disconnect the drive unit, see paragraph 4.5.1.
- Loosen the screw of lid (A).
- Uplift the pump unit by the help of the appropriate lifting equipment.
- Disassemble filter (B) and clean it with compressed air.



DRAIN FILTER

- Loosen screws (C) and lift cover (D).
- Extract filter (E), check its condition and replace, if necessary.



7.2.19 Hydraulic oil - Change


Replacement can be carried out by using an auxiliary pump or by means of the drain plug.

REPLACEMENT WITH AN AUXILIARY PUMP

- Disconnect the drive unit, see paragraph 4.5.1.
- Loosen the screw of lid (A).
- Uplift the pump unit by the help of the appropriate lifting equipment.
- Empty the tank by using an auxiliary pump.
- Clean the tank bottom.
- To top it up, fill with hydraulic oil: type class (C) HG 32. Quantity: 80 l.

REPLACEMENT BY MEANS OF THE DRAIN PLUG

- Disconnect the drive unit, see paragraph 4.5.1.
- Uplift the drive unit (see paragraph 4.2.) and place it on two stands.
- Unscrew the drain plug and let the oil be drained out.
- Loosen the screw of lid (A).
- Uplift the pump unit by the help of the appropriate lifting equipment.
- Clean the tank bottom.
- To top it up, fill with hydraulic oil: type class (C) HG 32. Quantity: 80 l




7.2.20 Air filter unit - Check

FILTER A

- Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C). Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C).

PRESSURE SWITCH

- The lubricator is equipped with a control pressure switch, set to a pressure of 4.5 bar.
 - remove the pressure gauge protecting glass;
 - turn the adjusting screw (G) anticlockwise (+) to increase pressure or clockwise (-) to lower it;
 - after this operation, replace the pressure gauge protecting glass.



CAUTION:

should the pressure switch needle point a Pressure=0 , do not absolutely turn the adjusting screw (H) clockwise (-) , for this will cause pressure switch breakage.

7.3 LUBRICATING/HYDRAULIC OIL - COMPARATIVE TABLE 

Table 2. Lubricating oil

Table 3. Hydraulic oil

ISO/UNI DESIGNATION	BRAND	DENOMINATION	ISO/UNI DESIGNATION	BRAND	DENOMINATION
CLASS C CKB 100	Agip	Acer 100	CLASS C HG 32	Agip	Exidia 32
	Api	Api Cis 100		Api	Api Cis EP-32
	BP	Energol CS 100		BP	Energol GHL 32
	Castrol	Magna 100		Castrol	Magna GC 32
	Chevron	Circulating Oil 100		Chevron	HWS 280 32 cSt
	Elf	Movixa 100		Elf	Hygliss 32
	Esso	Nuto 100		Esso	Febis K 32
	Fina	Solna 100		Fina	Hydran 32
	IP	IP Hermea 100		IP	Bantia HG 32
	Klüber	Crucolan 100		Klüber	Lamora 32
	Mobil	Vectra Oil Heavy		Mobil	Mobil Vacuoline 1405
	Olio FIAT	Daphne LPN 100		Olio FIAT	Daphne Husoli 32 HG/I
	Roloil	Arm V 100		Roloil	LI-EP 32
	Shell	Vitrea 100 Tellus C 100		Shell	Tonna TX 32
	Tamoil	Industrial Oil 100		Tamoil	Tamway oil 32
	Texaco	Omnis 100		Total	Drosera MS 32
	Total	Cortis 100 Azolla ZS 100		Texaco	Way lubricant 32
Q8	Verdi 100				

7.4 PREPARING THE BAR FEEDER FOR MAINTENANCE TO THE LATHE

For easy maintenance of the lathe, it is possible to remove some parts of the bar feeder and to use the device to slide the feeding drum.


Removing the middle leg (A) - SIR 52 F (fig. 23);
See paragraph 4.4.5.



CAUTION:

The central foot removal and following installation must be done when the magazine is empty.

Removing the hydraulic drive unit (B) (fig. 23); see paragraph 4.5.




How to use the Sliding Feeding Drum




CAUTION:

Function to be undertaken with great care, making sure that the bar feeder is stable.


Open the rear cover, lower the lever (M) and move the feeding drum backwards.





The (D) stroke is standard, stroke (E) is oversized and must be used in those installations which require a larger working area (fig. 25).





INDEX


8.1 GENERAL PROBLEMS 2

8.2 BAR MAGAZINE - FAILURES 2

8.3 DEVICE INTRODUCING BARS INTO GUIDES - PROBLEMS 3

8.4 CLAMPS DEVICE - PROBLEMS 4

8.5 GUIDES - PROBLEMS 4

8.6 HYDRAULIC SYSTEM - PROBLEMS 5

8.1 GENERAL PROBLEMS

ERROR	CAUSE	CURE
BAR FEEDER DOES NOT START	Open cases.	Close the cases.
	The feeding drum is out of position.	Position the feeding drum properly.
	Air missing.	Check the air system.
	Emergency devices activated.	Disable the emergency devices.
	Motors thermal switches blown.	Reset the overload relay by means of the relevant push-buttons.
THE BAR FEEDER DOES NOT WORK IN THE AUTOMATIC MODE	Levers are in a loading phase.	Read for any possible defects on the DISPLAY and provide the required conditions for the bar feeder to be started automatically
	Clamp arm on the guides.	
	Clamps are closed.	
	Guides are open.	

8.2 BAR MAGAZINE - FAILURES

ERROR	CAUSE	CURE
SIR 52 P THE BARS ARE NOT UPLIFTED BY THE CHAINS	The torque limiter slides.	Calibrate the torque limiter.
SIR 52 F BAR LIFTING IS OUT OF BALANCE	One of the belts is loosened or torn.	One of the belts is loosened or torn.
BARS ARE NOT SELECTED	The control cylinders do not work.	Check both the cylinders operation and the pneumatic system.
	The bar detection sensors are not excited.	Make sure that the bar detection signalling levers are exciting the sensors.
	Failure of the selector lifted cam.	Replace the cam .

8.3 DEVICE INTRODUCING BARS INTO GUIDES - PROBLEMS 

ERROR	CAUSE	CURE
BAR DROPS OUTSIDE THE LOWERING ROLLERS	Lever stop in a lower position because they are misaligned	Adjust the loading levers
	Torn rollers	Replace the control levers rollers
ARMS DO NOT LOWER	The cylinder does not work	Check the operation of the levers control cylinder.
	Lever are jammed in a high position.	Check there are no crosswise bars or folded levers
ARMS DO NOT INTRODUCE BARS	The lateral cylinders do not work.	Check the operation of the bar introducing cylinder.
	Lever are misaligned and interfere with the guiding sprockets.	Position the levers in the loading cycle.
CLOSED SPROCKETS PREVENTING THE BAR FEEDING	Jammed sprockets	Clean and check sprockets, making s

8.4 CLAMPS DEVICE - PROBLEMS

ERROR	CAUSE	CURE
CLAMPS DO NOT TIGHTEN THE BAR	The cylinder does not work	Check the hydraulic system operation.
	Failure of a tightening clamp	Replace the broken clamp.
	Low pressure	Adjust pressure, see paragraph 5.7.2..
THE BAR-PUSHER IS NOT HELD	The holding pneumatic cylinder is jammed.	Release the cylinder as well as the holding levers
	Failure of the holding rollers	Replace the broken roller
BAR-PUSHER AND CARRIAGE DO NOT ENTER THE GUIDE	The clamps unit is misaligned as to the guide axis.	Align the unit (apply to IEMCA technical assistance department
THE CLAMP ARM IS BLOCKED IN AN INTERMEDIARY POSITION	The clamp arm is blocked in an intermediary position	At the same time push the button and the button , the bar feeder will go into gear and the clamp arm will rotate towards the drum. Loosen the release knob for the nonreturn valve of the clamp arm (this can be found near the valve unit), in order to manually operate the clamp unit lifting and lowering. Bring the clamp unit in a position where sensor S3 can be read, then tighten the valve release knob and restart the



8.5 GUIDES - PROBLEMS

ERROR	CAUSE	CURE
Sprockets jam	Racks and sprocket supports are dirty.	Clean the concerned parts.
Sprockets close in the wrong guide	Chips or dirtiness in the spring and in the sprockets control rack.	Clean the concerned parts.
Sprocket open during the bar rotation	Failure of the locking spring.	Replace the spring. Make sure the sprockets closing phase occurs correctly.
Bar vibrates excessively thus causing side skids	Sprockets are out of phase Sprockets are not closed.	Clean the sprockets closing unit and make sure the closing phase occurs correctly.

8.6 HYDRAULIC SYSTEM - PROBLEMS 

ERROR	CAUSE	CURE
NOISY PUMPS	Insufficient or non-existent pump suction.	Clean the suction filter; make sure no throttling or damage occurred in the suction line.
	Pump sucks air from the suction line.	Tighten the suction line unions.
	Pump sucks air because the tank oil level is too low.	Top up the oil
	The working pressure is too high.	Decrease the working pressure
	Wrong type of oil.	Change it with a recommended oil
	The pump is worn out.	Repair or replace the pump
SYSTEM PRESSURE MISSING	Oil level is too low	Top up oil
	Insufficient or non-existent pump suction.	Clean the suction filter; make sure no throttling or damage occurred in the suction line.
	Pump sucks air from the suction line	Tighten the suction line unions
	Wrong type of oil	Change it with a recommended oil
	Failure of the pump.	Repair the pump
AIR IN THE SYSTEM AND/OR FOAM IN THE OIL	Oil level is too low	Top up oil.
	Leakage in the suction line.	Tighten the unions.
	Excessive resistance in the suction line.	Clean the filter
	Wrong type of oil.	Change it with a recommended oil

INDEX

.1	KEYBOARD BATTERY - REPLACEMENT 2
9.2	PLC BATTERY - REPLACEMENT 3

.1 KEYBOARD BATTERY - REPLACEMENT


The battery should be replaced every year or, in any case, when the battery warning light 23[sir_tasto 23] sends a red flashing signal.



INFORMATION

If the battery is not replaced, the date and time will disappear from the display.

- Cut off the bar feeder supply.
- Unscrew the key-board's panel (A).
- With a screwdriver, unscrew (but not completely) the 4 angle screws (B) of the double back box (C). Remove the double back box by keeping it parallel to the surface to which it was fastened.
- Remove the battery (D) from its compartment. Insert the new battery (type: lithium 3-volt CR 2430)



DANGER - WARNING:

Battery explosion danger if inserted with reversed polarity.

- Fix the double housing (C) to the panel again and tighten the 4 screws (B).
- Connect the bar feeder and check that the battery charge is signalled.


9.2 PLC BATTERY - REPLACEMENT

Replace the battery every year.



INFORMATION

If the battery is not replaced, the "PLC/CNC software" data will be deleted.




INFORMATION

When replacing the battery, make sure that the bar feeder is live. Warning: if the battery is replaced with the bar feeder off, I.E. with PLC not live, the bar feeder parameters will be cleared from the PLC memory and will have to be immediately restored.

- Open the cubicle.
- Uplift the small door (A) and remove battery (B) from its housing by disconnecting the socket.
- Fit the new battery (type: lithium 3.6-volt 1/2 AA): be careful to fit the connector correctly.
- Close door (A).

10.1 GUIDE CHANNELS AND BAR PUSHER - TABLE

The choice of guide channels and bar pusher must be made according to the diameter of the barstock. The bar feeder is usually supplied with a bar pusher whose diameter is equal to the maximum bar passage of the lathe. In certain cases, to be able to work in the best possible conditions, it may also be necessary to use a bar pusher with smaller diameter.



- A Guide channel
- B Bar pusher
- C Revolving tip
- D Collet
- E Bar


CAUTION:

the field of application of collets for machining specific bar diameters in the different guide channels are indicated in the table. When this diameter is lower than the diameter of the guidechannel, there can be vibrations or working problems in the barloader. It is useful to consider the possibility to reduce the speed rotation of the bar or to change the diameter of the guide channel to optimize the application. Therefore, in order to optimise operation, the bar rotation speed should be reduced or the guide channel diameter should be changed.


Diameters Comparative table during the standard working mode.

Bar diameter – $\varnothing A$ (mm)		Maximum tube diameter (*)– $\varnothing A$ (mm)	Guide channel diameter – $\varnothing B$ (mm)	Bar pusher diameter– $\varnothing C$ (mm)
Min	Max			
10	15	18	19	18
15	28	32	33	32
25	38	42	43	42
25	40	45	46	45
35	48	52	53	52
35	50	55	57	56

() Also valid for prepared bars and normal barstock with front ejection of bar remnant.*

10.2 REVOLVING TIP - TABLE

The choice of the revolving tip depends on the diameter of the guide channel, that of the bar pusher and the collet coupling version.




- A Guide channel
- B Bar pusher
- C Revolving tip
- D Collet
- E Bar

Guide channel diameter $\varnothing B$ (mm)	Bar pusher diameter $\varnothing C$ (mm)	Collet version – D (type of coupling)	Revolving tip diameter $\varnothing GR$ (mm)	Revolving tip code	See section
19	18	With pin (SCHL)	18	D60151801	
33	32	With pin (SCHL)	32	D60153201	
43	42	With pin (SCHL)	42	D60154201	
46	45	With pin (SCHL)	45	D60154501	
53	52	With pin (SCHL)	52	D60155201	
57	56	With pin (SCHL)	56	D60155601	

10.3 Revolving Tips \varnothing GR 18÷56 - Table

- For collet with pin coupling (SCHL)




- A Collet
- B See section
- C See section 001 than 602P
- D Collet for tube
- E Revolving tip





\varnothing GR (mm)	Revolving tip code	\varnothing F (mm)	\varnothing B (mm)	GP (mm)	C (mm)	A2 (mm)	SP1 (mm)
18	D60151801	11	18.5	127	M15x1 sx	18.5	6
32	D60153201	20	32.5	169.5	M28x1 sx	37.5	8
42	D60154201	20	42.5	169.5	M30x1 sx	37.5	8
45	D60154501	20	45.5	169.5	M30x1 sx	37.5	8
52	D60155201	20	52.5	215.5	M45x1 sx	31	8
56	D60155601	20	56.5	215.5	M50x1.5 sx	31	8



11.1 CONVERSION TABLES 001



HEXAGONAL BARS (unit of measurement "millimetres") - Table

Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.




	 $Y = Z \times 1,154$	$\varnothing A$		 $Y = Z \times 1,154$	$\varnothing A$
mm	mm	mm	mm	mm	mm
1.5	1.73	1.7	28	32.33	32
2	2.31	2.2	29	33.48	33.2
2.5	2.89	2.8	30	34.64	34.5
3	3.48	3.25	31	35.79	35.5
3.5	4.04	3.8	32	36.95	36.8
4	4.61	4.5	33	38.10	37.8
4.5	5.19	5	34	39.25	39
5	5.77	5.5	35	40.41	40.2
5.5	6.35	6.2	36	41.56	41.3
6	6.92	6.8	38	43.87	43.5
6.5	7.50	7.3	39	45.03	44.8
7	8.08	7.8	40	46.18	46
7.5	8.66	8.5	41	47.34	47
8	9.23	9	42	48.49	48.2
9	10.39	10.2	43	49.65	49.5
10	11.54	11.3	44	50.80	50.5
11	12.70	12.5	45	51.96	51.8
12	13.85	13.5	46	53.11	52.8
13	15.02	14.8	48	55.42	55
14	16.16	16	50	57.73	57.5
15	17.32	17.2	52	60.04	59.5
16	18.47	18.3	55	63.50	63
17	19.62	19.5	57	65.78	65.25
18	20.78	20.6	60	69.24	68.75
19	21.93	21.8	62	71.55	71
20	23.09	22.8	65	75	74.5
21	24.24	24	67	77.3	76.75
22	25.40	25.2	70	80.78	80.25





	 $Y=Z \times 1,154$	ØA
mm	mm	mm
23	26.55	26.2
24	27.71	27.5
25	28.86	28.5
26	30.02	29.8
27	31.17	31

	 $Y=Z \times 1,154$	ØA
mm	mm	mm
72	83.08	82.5
75	86.55	86
80	92.32	91.75
85	98.1	97.5

SQUARE BARS (unit of measurement "millimetres") - Table


Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.





	 $Y = Z \times 1,414$	$\varnothing A$		 $Y = Z \times 1,414$	$\varnothing A$
mm	mm	mm	mm	mm	mm
1	1.41	1.3	20	28.28	27.5
1.5	2.12	2	22	31.10	30.5
2	2.82	2.7	23	32.52	32
2.5	3.53	3.4	24	33.93	33
3	4.24	4	25	35.35	34.5
4	5.65	5.5	26	36.76	36
4.5	6.36	6.2	27	38.17	37.5
5	7.07	6.8	28	39.59	38.5
5.5	7.77	7.5	30	42.42	41.5
6	8.48	8.3	32	45.24	44.5
6.5	9.19	9	34	48.07	47
7	9.89	9.7	35	49.49	48.5
8	11.31	11	36	50.90	50
8.5	12.01	11.8	37	52.31	51.5
9	12.72	12.5	38	53.73	52.5
10	14.14	13.8	39	55.15	54.5
10.5	14.84	14.5	40	56.56	55.5
11	15.55	15	41	57.97	57
12	16.97	16.5	42	59.38	58.5
12.5	17.67	17	43	60.08	59
13	18.38	18	44	62.21	61
14	19.79	19.5	45	63.63	62.5
15	21.21	20.8	46	65.04	64
16	22.62	22	50	70.7	69.5
17	24.04	23.5	55	77.77	76.75
18	25.52	25	60	84.84	83.75
19	26.86	26	65	91.91	91

HEXAGONAL BARS (unit of measurement "inches") - Table

Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.







	$\varnothing A$	
	inches	mm
1/8	3.5	9/64
3/16	5.25	13/64
1/4	7	9/32
5/16	8.75	11/32
3/8	10.75	27/64
7/16	12.5	31/64
1/2	14.25	9/16
9/16	16.25	41/64
5/8	18	45/64
11/16	19.75	25/32
3/4	21.75	55/64
13/16	23.5	59/64
7/8	25.25	63/64
15/16	27.25	1"5/64
1"	29	1"9/64
1"1/16	30.75	1"13/64
1"1/8	32.5	1"9/32
1"3/16	34.25	1"11/32
1"1/4	36.25	1"27/64
1"5/16	38	1"1/2

	$\varnothing A$	
	inches	mm
1"3/8	39.75	1"9/16
1"7/16	41.75	1"41/64
1"1/2	43.5	1"23/32
1"9/16	46.5	1"53/64
1"5/8	47.25	1"55/64
1"11/16	49	1"15/16
1"3/4	50.75	2"
1"13/16	52.75	2"5/64
1"7/8	54.5	2"9/64
1"15/16	56.25	2"7/32
2"	58	2"9/32
2"1/16	59.75	2"11/32
2"1/8	61.5	2"27/64
2"3/16	63.5	2"1/2
2"1/4	65.25	2"37/64
2"1/2	72.5	2"55/64
2"3/4	79.75	3"9/64
3"	87	3"27/64
3"1/4	94.25	3"23/32

ROUND BARS (unit of measurement "inches") - Table

Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.



	$\varnothing A$		$\varnothing A$		$\varnothing A$
inches	mm	inches	mm	inches	mm
1/32	0.8	17/32	13.5	1"1/8	28.5
3/64	1.2	35/64	14	1"3/16	30.25
1/16	1.6	9/16	14.25	1"1/4	31.75
5/64	2	37/64	14.75	1"5/16	33.25
3/32	2.4	19/32	15	1"3/8	35
7/64	2.8	39/64	15.5	1"7/16	36.25
1/8	3.2	5/8	16	1"1/2	38
9/64	3.6	41/64	16.25	1"9/16	39.75
5/32	4	21/32	16.75	1"5/8	41.25
11/64	4.4	43/64	17	1"11/16	43
3/16	4.8	11/16	17.5	1"3/4	44.5
13/64	5.2	45/64	18	1"13/16	46
7/32	5.6	23/32	18.25	1"7/8	47.75
15/64	6	47/64	18.75	1"15/16	49.25
1/4	6.4	3/4	19	2"	50.75
17/64	6.8	49/64	19.5	2"1/16	52.5
9/32	7.2	25/32	19.75	2"1/8	54
19/64	7.6	51/64	20.25	2"3/16	55.5
5/16	8	13/16	20.75	2"1/4	57.25
21/64	8.4	53/64	21	2"5/16	58.75
11/32	8.8	27/32	21.5	2"3/8	60.5
23/64	9.1	55/64	21.75	2"7/16	62
3/8	9.6	7/8	22.25	2"1/2	63.5
25/64	10	57/64	22.75	2"9/16	65
13/32	10.4	29/32	23	2"5/8	66.75
27/64	10.8	59/64	23.5	2"11/16	68.25
7/16	11.25	15/16	24	2"3/4	70
29/64	11.5	61/64	24.25	2"13/16	71.5
15/32	12	31/32	24.75	2"7/8	73
31/64	12.5	63/64	25	2"15/16	74.75
1/2	12.75	1	25.5	3"	76.25
33/64	13.25	1"1/16	27		

CONVERSION TABLE Inches/Millimetres

Inch fraction		Inch fraction			
		1	2	3	4
		Millimetres			
0	0	0	25,400 0	50,800 0	76,200 0
1/64	0,015 625	0,396 9	25,796 9	51,196 9	76,596 9
1/32	0,031 25	0,793 8	26,193 8	51,593 8	76,993 8
3/64	0,046 875	1,190 6	26,590 6	51,990 6	77,390 6
1/16	0,062 5	1,587 5	26,987 5	52,387 5	77,787 5
5/64	0,078 125	1,984 4	27,384 4	52,784 4	78,184 4
3/32	0,093 75	2,381 2	27,781 2	53,181 2	78,581 2
7/64	0,109 375	2,778 1	28,178 1	53,578 1	78,978 1
1/8	0,125	3,175 0	28,575 0	53,985 0	79,375 0
9/64	0,140 625	3,571 9	28,971 9	54,371 9	79,771,9
5/32	0,156 25	3,968 8	29,368 8	54,768 8	80,168 8
11/64	0,171 875	4,365 6	29,765 6	55,165 6	80,565 6
3/16	0,187 5	4,762 5	30,162 5	55,562 5	80,962 5
13/64	0,203 125	5,159 4	30,559 4	55,959 4	81,359 4
7/32	0,218 75	5,556 2	30,956 2	56,356 2	81,756 2
15/64	0,234 375	5,953 1	31,353 1	56,753 1	82,153 1
1/4	0,25	6,350 0	31,750 0	57,150 0	82,550 0
17/64	0,265 625	6,746 9	32,146 9	57,546 9	82,946 9
9/32	0,281 25	7,143 8	32,543 8	57,943 8	83,343 8
19/64	0,296 875	7,540 6	32,940 6	58,340 6	83,740 6
5/16	0,312 5	7,937 5	33,337 5	58,737 5	84,137 5
21/64	0,328 125	8,334 4	33,734 4	59,134 4	84,534 4
11/32	0,343 75	8,731 2	34,131 2	59,531 2	84,931 2
23/64	0,359 375	9,128 1	34,528 1	59,928 1	85,328 1
3/8	0,375	9,525 0	34,925 0	60,325 0	85,725 0
25/64	0,390 625	9,921 9	35,321 9	60,721 9	86,121 9
13/32	0,406 25	10,318 8	35,718 8	61,118 8	86,518 8
27/64	0,421 875	10,715 6	36,115 6	61,515 6	86,915 6
7/16	0,437 5	11,112 5	36,512 5	61,912 5	87,312 5
29/64	0,453 125	11,509 4	36,909 4	62,309 4	87,709 4
15/32	0,468 75	11,906 2	37,306 2	62,706 2	88,106 2
31/64	0,484 375	12,303 1	37,703 1	63,103 1	88,503 1
1/2	0,5	12,700 0	38,100 0	63,500 0	88,900 0
33/64	0,515 625	13,096 9	38,496 9	63,896 9	89,296 9
17/32	0,531 25	13,493 8	38,893 8	64,293 8	89,693 8
35/64	0,546 875	13,890 6	39,290 6	64,690 6	90,090 6
9/16	0,562 5	14,287 5	39,687 5	65,087 5	90,487 5
37/64	0,578 125	14,684 4	40,084 4	65,484 4	90,884 4
19/32	0,593 75	15,081 2	40,481 2	65,881 2	91,281 2
39/64	0,609 375	15,478 1	40,878 1	66,278 1	91,678 1
5/8	0,625	15,875 0	41,275 0	66,675 0	92,075 0
41/64	0,640 625	16,271 9	41,671 9	67,071 9	92,471 9
21/32	0,656 25	16,668 8	42,068 8	67,468 8	92,868 8
43/64	0,671 875	17,065 6	42,465 6	67,865 6	93,265 6

Inch fraction		Inch fraction			
		1	2	3	4
		Millimetres			
11/16	0,687 5	17,462 5	42,862 5	68,262 5	93,662 5
45/64	0,703 125	17,859 4	43,259 4	68,659 4	94,059 4
23/32	0,718 75	18,256 2	43,656 2	69,056 2	94,456 2
47/64	0,734 375	18,653 1	44,053 1	69,453 1	94,853 1
3/4	0,75	19,050 0	44,450 0	69,850 0	95,250 0
49/64	0,765 625	19,446 9	44,846 9	70,246 9	95,646 9
25/32	0,781 25	19,843 8	45,243 8	70,643 8	96,043 8
51/64	0,796 875	20,240 6	45,640 6	71,040 6	96,440 6
13/16	0,812 5	20,637 5	46,037 5	71,437 5	96,837 5
53/64	0,828 125	21,034 4	46,434 4	71,834 4	97,234 4
27/32	0,843 75	21,431 2	46,831 2	72,231 2	97,631 2
55/64	0,859 375	21,828 1	47,228 1	72,628 1	98,028 1
7/8	0,875	22,225 0	47,625 0	73,025 0	98,425 0
57/64	0,890 625	22,621 9	48,021 9	73,421 9	98,821 9
29/32	0,906 25	23,018 8	48,418 8	73,818 8	99,218 8
59/64	0,921 875	23,415 6	48,815 6	74,215 6	99,615 6
15/16	0,937 5	23,812 5	49,212 5	74,612 5	100,012 5
61/64	0,953 125	24,209 4	49,609 4	75,009 4	100,409 4
31/32	0,968 75	24,606 2	50,006 2	75,406 2	100,806 2
63/64	0,984 375	25,003 1	50,403 1	75,803 1	101,203 1

11.2 COLLETS FOR BARS 602P

COLLETS FOR BARS - Table



CAUTION:


the external diameter of the collet must be at least 0.5 mm less than the external diameter of the bar pusher.

Note for consultation

The codes on the grey ground are indicating the "EMPLOYED SECTOR" to prefer.

Note for ordering

- Collets with codes in bold characters are available from stock.
- Please contact IEMCA service to use the collets with codes in Italics. The delivery times for this kind of collets are longer.



- A Collet
- B Bar diameter
- C Example:
 - 3 mm = 030
 - 3.5 mm = 035
 - 12.5 mm = 125
 - 12.75 mm = 127
- D Family to which it belongs

øA		øF Ø7 G6	øF Ø8 G6	øF Ø11 G6	øF Ø20 G6	
<i>mm</i>	<i>inches</i>	øD 10	øD 12	øD 15	øD 25	
3		602P10030	602P12030			
3.1		602P10031	602P12031			
3.2	1/8"	602P10032	602P12032			
3.3		602P10033	602P12033			
3.4		602P10034	602P12034			
3.5		602P10035	602P12035			
3.6	9/64"	602P10036	602P12036			
3.7		602P10037	602P12037			
3.8		602P10038	602P12038			
3.9		602P10039	602P12039			
4	5/32"	602P10040	602P12040	<i>602P15040</i>		
4.1		602P10041	602P12041	<i>602P15041</i>		
4.2		602P10042	602P12042	<i>602P15042</i>		
4.3		602P10043	602P12043	<i>602P15043</i>	<i>602P25043</i>	
4.4	11/64"	602P10044	602P12044	<i>602P15044</i>		
4.5		602P10045	602P12045	<i>602P15045</i>		
4.6		602P10046	602P12046	<i>602P15046</i>		
4.7		602P10047	602P12047	<i>602P15047</i>		
4.8	3/16"	602P10048	602P12048	<i>602P15048</i>		
4.9		602P10049	602P12049	<i>602P15049</i>		
5		602P10050	602P12050	602P15050	<i>602P25050</i>	
5.1		602P10051	602P12051	602P15051		
5.2	13/64"	602P10052	602P12052	602P15052		

øA		øF Ø7 G6	øF Ø8 G6	øF Ø11 G6	øF Ø11 G6
<i>mm</i>	<i>inches</i>	øD 10	øD 12	øD 15	øD 18
5.3		602P10053	602P12053	602P15053	
5.4		602P10054	602P12054	602P15054	
5.5		602P10055	602P12055	602P15055	
5.6	7/32"	602P10056	602P12056	602P15056	
5.7		602P10057	602P12057	602P15057	
5.8		602P10058	602P12058	602P15058	
5.9		602P10059	602P12059	602P15059	
6	15/64"	602P10060	602P12060	602P15060	
6.1		602P10061	602P12061	602P15061	
6.2		602P10062	602P12062	602P15062	
6.3		602P10063	602P12063	602P15063	
6.4	1/4"	602P10064	602P12064	602P15064	
6.5		602P10065	602P12065	602P15065	
6.6		602P10066	602P12066	602P15066	
6.7		602P10067	602P12067	602P15067	
6.8	17/64"	602P10068	602P12068	602P15068	
6.9		602P10069	602P12069	602P15069	
7		602P10070	602P12070	602P15070	
7.1		602P10071	602P12071	602P15071	
7.2	9/32"	602P10072	602P12072	602P15072	
7.3		602P10073	602P12073	602P15073	
7.4		602P10074	602P12074	602P15074	
7.5		602P10075	602P12075	602P15075	
7.6	19/64"	602P10076	602P12076	602P15076	
7.7		602P10077	602P12077	602P15077	
7.8		602P10078	602P12078	602P15078	
7.9		602P10079	602P12079	602P15079	
8	5/16"	602P10080	602P12080	602P15080	602P18080
8.1			602P12081	602P15081	
8.2			602P12082	602P15082	
8.3			602P12083	602P15083	
8.4	21/64"		602P12084	602P15084	
8.5			602P12085	602P15085	
8.6			602P12086	602P15086	
8.7			602P12087	602P15087	
8.8	11/32"		602P12088	602P15088	
8.9			602P12089	602P15089	
9			602P12090	602P15090	602P18090
9.1	23/64"		602P12091	602P15091	602P18091
9.2			602P12092	602P15092	602P18092

øA		øF Ø14 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 20	øD 25	øD 32
5.3				
5.4				
5.5				
5.6	7/32"			
5.7				
5.8				
5.9				
6	15/64"	602P20060	602P25060	602P32060
6.1		602P20061	602P25061	
6.2		602P20062	602P25062	
6.3		602P20063	602P25063	
6.4	1/4"	602P20064	602P25064	
6.5		602P20065	602P25065	602P32065
6.6		602P20066	602P25066	
6.7		602P20067	602P25067	
6.8	17/64"	602P20068	602P25068	
6.9		602P20069	602P25069	
7		602P20070	602P25070	602P32070
7.1		602P20071	602P25071	
7.2	9/32"	602P20072	602P25072	
7.3		602P20073	602P25073	
7.4		602P20074	602P25074	
7.5		602P20075	602P25075	602P32075
7.6	19/64"	602P20076	602P25076	
7.7		602P20077	602P25077	
7.8		602P20078	602P25078	
7.9		602P20079	602P25079	
8	5/16"	602P20080	602P25080	602P32080
8.1		602P20081	602P25081	
8.2		602P20082	602P25082	
8.3		602P20083	602P25083	
8.4	21/64"	602P20084	602P25084	
8.5		602P20085	602P25085	602P32085
8.6		602P20086	602P25086	
8.7		602P20087	602P25087	
8.8	11/32"	602P20088	602P25088	
8.9		602P20089	602P25089	
9		602P20090	602P25090	602P32090
9.1	23/64"	602P20091	602P25091	
9.2		602P20092	602P25092	

øA		øF Ø8 G6	øF Ø11 G6	øF Ø11 G6	øF Ø11 G6
<i>mm</i>	<i>inches</i>	øD 12	øD 15	øD 16	øD 18
9.3		602P12093	602P15093		602P18093
9.4		602P12094	602P15094		602P18094
9.5		602P12095	602P15095		602P18095
9.6	3/8"	602P12096	602P15096		602P18096
9.7		602P12097	602P15097		602P18097
9.8		602P12098	602P15098		602P18098
9.9		602P12099	602P15099		602P18099
10	25/64"	602P12100	602P15100		602P18100
10.1			602P15101		602P18101
10.2			602P15102		602P18102
10.3			602P15103		602P18103
10.4	13/32"		602P15104		602P18104
10.5			602P15105		602P18105
10.6			602P15106		602P18106
10.7			602P15107		602P18107
10.8	27/64"		602P15108		602P18108
10.9			602P15109		602P18109
11			<i>602P15110</i>	602P16110	602P18110
11.1					602P18111
11.2					602P18112
11.25	7/16"		<i>602P15112</i>	602P16112	
11.3					602P18113
11.4					602P18114
11.5	29/64"		<i>602P15115</i>	602P16115	602P18115
11.6					602P18116
11.7					602P18117
11.75			<i>602P15117</i>	602P16117	
11.8					602P18118
11.9					602P18119
12	15/32"		<i>602P15120</i>	602P16120	
12.25			<i>602P15122</i>	602P16122	
12.5	31/64"		<i>602P15125</i>	602P16125	<i>602P18125</i>
12.75	1/2"		<i>602P15127</i>	602P16127	<i>602P18127</i>
13			<i>602P15130</i>	<i>602P16130</i>	602P18130
13.25	33/64"			<i>602P16132</i>	602P18132
13.5	17/32"			<i>602P16135</i>	602P18135
13.75				<i>602P16137</i>	602P18137

øA		øF Ø8 G6	øF Ø11 G6	øF Ø11 G6	øF Ø11 G6
<i>mm</i>	<i>inches</i>	øD 12	øD 15	øD 16	øD 18
14	35/64"			602P16140	602P18140
14.25	9/16"				602P18142
14.5					602P18145
14.75	37/64"				602P18147
15	19/32"				602P18150
15.25					602P18152
15.5	39/64"				602P18155
15.75					602P18157

øA		øF Ø14 G6	øF Ø14 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 20	øD 23	øD 25	øD 32
9.3		602P20093		602P25093	
9.4		602P20094		602P25094	
9.5		602P20095		602P25095	602P32095
9.6	3/8"	602P20096		602P25096	
9.7		602P20097		602P25097	
9.8		602P20098		602P25098	
9.9		602P20099		602P25099	
10	25/64"	602P20100		602P25100	602P32100
10.1		602P20101		602P25101	
10.2		602P20102		602P25102	
10.3		602P20103		602P25103	
10.4	13/32"	602P20104		602P25104	
10.5		602P20105		602P25105	602P32105
10.6		602P20106		602P25106	
10.7		602P20107		602P25107	
10.8	27/64"	602P20108		602P25108	
10.9		602P20109		602P25109	
11		602P20110		602P25110	602P32110
11.1					
11.2					
11.25	7/16"	602P20112		602P25112	
11.3					
11.4					
11.5	29/64"	602P20115		602P25115	602P32115
11.6					
11.7					
11.75		602P20117		602P25117	
11.8					
11.9					
12	15/32"	602P20120		602P25120	602P32120
12.25		602P20122		602P25122	
12.5	31/64"	602P20125		602P25125	602P32125
12.75	1/2"	602P20127		602P25127	
13		602P20130		602P25130	602P32130
13.25	33/64"	602P20132		602P25132	
13.5	17/32"	602P20135		602P25135	602P32135
13.75		602P20137		602P25137	

øA		øF Ø14 G6	øF Ø14 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 20	øD 23	øD 25	øD 32
14	35/64"	602P20140	<i>602P23140</i>	602P25140	602P32140
14.25	9/16"	602P20142	<i>602P23142</i>	602P25142	
14.5		602P20145	<i>602P23145</i>	602P25145	602P32145
14.75	37/64"	602P20147	<i>602P23147</i>	602P25147	
15	19/32"	602P20150	<i>602P23150</i>	602P25150	602P32150
15.25		602P20152	<i>602P23152</i>	602P25152	
15.5	39/64"	602P20155	<i>602P23155</i>	602P25155	602P32155
15.75		602P20157	<i>602P23157</i>	602P25157	

øA		øF Ø11 G6	øF Ø14 G6	øF Ø14 G6	øF Ø14 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 18	øD 20	øD 21	øD 23	øD 25	øD 27	øD 32
16	5/8"	602P18160	602P20160		<i>602P23160</i>	602P25160		602P32160
16.25	41/64"		602P20162		<i>602P23162</i>	602P25162		
16.5			<i>602P20165</i>	602P21165	602P23165	602P25165		602P32165
16.75	21/32"		<i>602P20167</i>	602P21167	602P23167	602P25167		
17	43/64"		<i>602P20170</i>	602P21170	602P23170	602P25170		602P32170
17.25			<i>602P20172</i>	602P21172	602P23172	602P25172		
17.5	11/16"		<i>602P20175</i>	602P21175	602P23175	602P25175		602P32175
17.75			<i>602P20177</i>	602P21177	602P23177	602P25177		
18	45/64"		<i>602P20180</i>	602P21180	602P23180	602P25180		602P32180
18.25	23/32"			602P21182	602P23182	602P25182		
18.5				602P21185	602P23185	602P25185		602P32185
18.75	47/64"			602P21187	602P23187	602P25187		
19	3/4"			602P21190	602P23190	602P25190		602P32190
19.25					602P23192	602P25192		
19.5	49/64"				602P23195	602P25195		602P32195
19.75	25/32"				602P23197	602P25197		
20					602P23200	602P25200		602P32200
20.25	51/64"				602P23202	602P25202		
20.5					602P23205	602P25205		602P32205
20.75	13/16"				602P23207	602P25207		
21	53/64"				602P23210	<i>602P25210</i>	602P27210	602P32210
21.25						<i>602P25212</i>	602P27212	
21.5	27/32"					<i>602P25215</i>	602P27215	602P32215
21.75	55/64"					<i>602P25217</i>	602P27217	

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 25	øD 27	øD 29	øD 32	øD 35	øD 36
22		602P25220	602P27220		602P32220		
22.25	7/8"	602P25222	602P27222				
22.5		602P25225	602P27225		602P32225		
22.75	57/64"	602P25227	602P27227	602P29227			
23	29/32"	602P25230	602P27230	602P29230	602P32230		
23.25			602P27232	602P29232			
23.5	59/64"		602P27235	602P29235	602P32235		
23.75			602P27237	602P29237			
24	15/16"		602P27240	602P29240	602P32240		
24.25	61/64"		602P27242	602P29242			
24.5			602P27245	602P29245			
24.75	31/32"		602P27247	602P29247			
25	63/64"		602P27250	602P29250	602P32250		
25.25			602P27252	602P29252	602P32252		
25.4			602P27254				
25.5	1"		602P27255	602P29255	602P32255		
25.75				602P29257	602P32257		
26				602P29260	602P32260		602P36260
26.25				602P29262	602P32262		602P36262
26.5				602P29265	602P32265		602P36265
26.75				602P29267	602P32267		602P36267
27	1" 1/16			602P29270	602P32270	602P35270	602P36270
27.25					602P32272	602P35272	602P36272
27.5					602P32275	602P35275	602P36275
27.75					602P32277	602P35277	602P36277
28					602P32280	602P35280	602P36280
28.25					602P32282	602P35282	602P36282
28.5	1" 1/8				602P32285	602P35285	602P36285
28.75					602P32287	602P35287	602P36287

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 32	øD 34	øD 35	øD 36	øD 39	øD 42	øD 45
29		602P32290		602P35290	602P36290			
29.25		602P32292		602P35292	602P36292			
29.5		602P32295		602P35295	602P36295			
29.75		602P32297		602P35297	602P36297			
30		602P32300		602P35300	602P36300			
30.25	1" 3/16			602P35302	602P36302			
30.5				602P35305	602P36305			
30.75				602P35307	602P36307			
31				602P35310	602P36310		602P42310	
31.25				602P35312	602P36312		602P42312	
31.5			602P34315	602P35315	602P36315		602P42315	
31.75	1" 1/4			602P35317	602P36317		602P42317	
32				602P35320	602P36320	602P39320	602P42320	
32.25					602P36322		602P42322	
32.5					602P36325		602P42325	
32.75					602P36327		602P42327	
33					602P36330		602P42330	602P45330
33.25	1" 5/16				602P36332		602P42332	602P45332
33.5					602P36335		602P42335	602P45335
33.75					602P36337		602P42337	602P45337
34					602P36340		602P42340	602P45340
34.25							602P42342	602P45342
34.5							602P42345	602P45345
34.75						602P39350	602P42347	602P45347
35	1" 3/8						602P42350	602P45350
35.25							602P42352	602P45352
35.5							602P42355	602P45355
35.75							602P42357	602P45375
36						602P39360	602P42360	602P45360
36.25	1" 7/16						602P42362	602P45362
36.5							602P42365	602P45365
36.75							602P42367	602P45367
37						602P39370	602P42370	602P45370
37.25							602P42372	602P45372
37.5							602P42375	602P45375
37.75							602P42377	602P45377

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	SIR 52		
					øD 42	øD 45	
<i>mm</i>	<i>inches</i>						
38		602P42380	602P45380				
38.25		602P42382	602P45382				
38.5		602P42385	602P45385				
38.75		602P42387	602P45387				
39		602P42390	602P45390				
39.25		602P42392	602P45392				
39.5		602P42395	602P45395				
39.75		602P42397	602P45397	602P51397			
40		602P42400	602P45400	602P51400			
40.25			602P45402	602P51402			
40.5			602P45405	602P51405			
40.75			602P45407	602P51407			
41			602P45410	602P51410			
41.25			602P45412	602P51412			
41.5			602P45415	602P51415			
41.75			602P45417	602P51417			
42			602P45420	602P51420			
42.25				602P51422			
42.5				602P51425			
42.75				602P51427			
43	1" 11/16			602P51430			
43.25				602P51432			
43.5				602P51435			
43.75				602P51437			
44				602P51440	602P52440		
44.25				602P51442			
44.5				602P51445	602P52445		
44.75				602P51447			
45				602P51450			
45.25				602P51452			
45.5				602P51455			
45.75				602P51457			
46				602P51460	602P52460		
46.25				602P51462			
46.5				602P51465			
46.75				602P51467			
47				602P51470	602P52470	602P56470	

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	SIR 52		
					øF Ø20 G6	øF Ø20 G6	
<i>mm</i>	<i>inches</i>	øD 42	øD 45	øD 51	øD 52	øD 56	
48					602P52480	602P56480	
49					602P52490	602P56490	
50						602P56500	
51						602P56510	
52						602P56520	


11.3 "UNILOCK" COLLETS FOR BARS 601P

"UNILOCK" COLLETS FOR SQUARE BARS - Table



INFORMATION:

for defining the internal diameter ϕA do not consult "001 - Conversion Tables" document, but directly consult the table below.



- A Collet
- B Bar diameter
- C Example:
 3 mm = 030
 3.5 mm = 035
 12.5 mm = 125
 12.75 mm = 127
- D Family to which it belongs

S	E E=Sx1.414	øA +0.1 0	øF M5x0.5	øF Ø8 G6	øF Ø11 G6	øF Ø14 G6	øF Ø20 G6
<i>mm</i>	<i>mm</i>	<i>mm</i>	øD 7.5	øD 12	øD 18	øD 21	øD 25
3	4.24	3.8	601P08038				
4	5.65	5.1		601P12051			
5	7.07	6.6		601P12066			
6	8.48	8		601P12080	601P18080		
7	9.90	9.2			601P18092	601P21092	
8	11.31	10.3			601P18103	601P21103	
9	12.73	11.7			601P18117	601P21117	
10	14.14	13.1			601P18131	601P21131	601P25131
11	15.55	14.5				601P21145	601P25145
12	16.97	15				601P21150	601P25150

S	E E=Sx1.414	øA +0.1 0	øF M5x0.5	øF Ø8 G6	øF Ø11 G6	øF Ø14 G6
<i>mm</i>	<i>mm</i>	<i>mm</i>	øD 25	øD 29	øD 32	øD 36
13	18.38	17.4	601P25174			
14	19.80	18.8	601P25188			
15	21.21	20.2	601P25202			
16	22.62	21.6		601P29216		
17	24.04	23		601P29230		
18	25.45	24.5			601P32245	
19	26.87	25.9			601P32259	
20	28.28	27.3			601P32273	
21	29.69	28.7				601P36287
22	31.11	30.1				601P36301
23	32.52	31.5				601P36315

“UNILOCK” COLLETS FOR HEXAGONAL BARS - Table



INFORMATION:

for defining the internal diameter $\varnothing A$ do not consult “001 - Conversion Tables” document, but directly consult the table below.


Note for consultation

The codes on the grey ground are indicating the "EMPLOYED SECTOR" to prefer.

Note for ordering

- Collets with codes in bold characters are available from stock.
- Please contact IEMCA service to use the collets with codes in Italics. The delivery times for this kind of collets are longer.

Code structure



601P_01-02

- A Collet
- B Bar diameter
- C Example:
 3 mm = 030
 3.5 mm = 035
 12.5 mm = 125
 12.75 mm = 127
- D Family to which it belongs

S		E E=Sx1.154	øA +0.1 0	øF M5x0.5	øF Ø8 G6	øF Ø11 G6	øF Ø14 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	<i>mm</i>	<i>mm</i>	øD 7.5	øD 12	øD 18	øD 21	øD 25
3		3.46	3.1	601P08031				
	1/8"	3.66	3.3	601P08033				
4		4.62	4.1	601P08041				
	3/16"	5.5	5		601P12050			
5		5.77	5.2		601P12052			
6		6.92	6.2		601P12062	601P18062		
	1/4"	7.33	6.6		601P12066	<i>601P18066</i>		
7		8.08	7.3		<i>601P12073</i>	601P18073		
	5/16"	9.16	8.3			601P18083	601P21083	
8		9.23	8.4			601P18084	601P21084	
8.5		9.82	9					601P25090
9		10.39	9.5			601P18095	601P21095	
	3/8"	10.99	10			601P18100	601P21100	
10		11.54	10.6			601P18106	601P21106	
10.5		12.13	11.1			601P18111		
11		12.7	11.7			601P18117	601P21117	
	7/16"	12.82	11.8			601P18118	601P21118	
12		13.85	12.8			601P18128	601P21128	601P25128
	1/2"	14.65	13.7			601P18137		
13		15.01	13.9			601P18139		

S		E E=Sx1.154	øA +0.1 0	øF 14 G6	øF 20 G6	øF 20 G6
<i>mm</i>	<i>inches</i>	<i>mm</i>	<i>mm</i>	øD 21	øD 25	øD 29
	1/2"	14.65	13.7	601P21137	601P25137	
13		15	14	601P21140	601P25140	
14		16.16	15.2	601P21152	601P25152	
	9/16"	16.49	15.5	601P21155	601P25155	
15		17.31	16.3	601P21163	601P25163	
	5/8"	18.32	17.3		601P25173	
16		18.46	17.5		601P25175	
17		19.62	18.6		601P25186	<i>601P29186</i>
	11/16"	20.15	19.2		601P25192	<i>601P29192</i>
18		20.77	19.8		601P25198	<i>601P29198</i>
19	3/4"	21.93	21		601P25210	601P29210
20		23.08	22.1			601P29221
	13/16"	23.81	22.8			601P29228
21		24.24	23.2			601P29232
22		25.39	24.4			601P29244
	7/8"	25.65	24.7			601P29247
23		26.54	25.5			
	15/16"	27.48	26.5			
24		27.7	26.7			
	31/32"	28.41	27.3			
25		28.85	27.9			
	1"	29.31	28.3			
26		30	29			
	1" 1/16	31.14	30.2			
28		32.31	31.3			
	1" 1/8	33	32			

S		E E=Sx1.154	øA +0.1 0	øF 20 G6	øF 20 G6	øF 20 G6
<i>mm</i>	<i>inches</i>	<i>mm</i>	<i>mm</i>	øD 32	øD 36	øD 40
	1/2"	14.65	13.7			
13		15	14			
14		16.16	15.2			
	9/16"	16.49	15.5			
15		17.31	16.3			
	5/8"	18.32	17.3			
16		18.46	17.5			
17		19.62	18.6			
	11/16"	20.15	19.2			
18		20.77	19.8			
19	3/4"	21.93	21			
20		23.08	22.1	601P32221		
	13/16"	23.81	22.8			
21		24.24	23.2	601P32232	601P36232	
22		25.39	24.4	601P32244	601P36244	
	7/8"	25.65	24.7	601P32247		
23		26.54	25.5	601P32255		
	15/16"	27.48	26.5	601P32265	601P36265	
24		27.7	26.7	601P32267	601P36267	
	31/32"	28.41	27.3	601P32273		
25		28.85	27.9	601P32279	601P36279	
	1"	29.31	28.3		601P36283	
26		30	29		601P36290	
	1" 1/16	31.14	30.2		601P36302	601P40302
28		32.31	31.3		601P36313	
	1" 1/8	33	32		601P36320	

11.4 COLLETS FOR TUBES 603P

COLLETS FOR TUBES - Table




CAUTION:

the external diameter of the collet must be at least 0.5 mm less than the external diameter of the bar pusher.



INFORMATION:

The 603P collets..... fitted with a Schlenker coupling, allowing the assembly on the rotating unit, are designed with an oversized length. Therefore, the 1st feeding value of the bar pusher carriage shall be increased of 7,5 mm. with respect to the standard value.



- A Bar diameter
- B Example:
5 mm = 060
10 mm = 100
12.5 mm = 125
- C Family to which it belongs

øA		øF ø8 G6	øF ø11 G6	øF ø11 G6	øF ø14 G6	øF ø20 G6	øF ø20 G6	
<i>mm</i>	<i>inches</i>	øD 12	øD 15	øD 18	øD 20	øD 25	øD 27	
5		603P12050	603P15050					
5.5		603P12055	603P15055					
6	15/64"	603P12060	603P15060		603P20060			
6.5		603P12065	603P15065		603P20065			
7		603P12070	603P15070		603P20070			
7.5		603P12075	603P15075		603P20075			
8	5/16"	603P12080	603P15080		603P20080			
8.5		603P12085	603P15085		603P20085			
9		603P12090	603P15090		603P20090			
9.5		603P12095	603P15095		603P20095			
10	25/64"		603P15100	603P18100	603P20100	603P25100		
10.5			603P15105		603P20105	603P25105		
11			603P15110		603P20110	603P25110		

øA		øF ø8 G6	øF ø11 G6	øF ø14 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6
<i>mm</i>	<i>inches</i>	øD 12	øD 15-16	øD 20	øD 25	øD 27	øD 32	øD 35
11.5			603P15115	603P20115	603P25115			
12			603P15120	603P20120	603P25120			
12.5	31/64"		603P15125	603P20125	603P25125			
13			603P15130	603P20130	603P25130			
13.5			603P16135	603P20135	603P25135			
14			603P16140	603P20140	603P25140			
14.5				603P20145	603P25145			
15				603P20150	603P25150		603P32150	
15.5				603P20155	603P25155			
16	5/8"			603P20160	603P25160		603P32160	
16.5				603P20165	603P25165		603P32165	
17				603P20170	603P25170		603P32170	
17.5	11/16"			603P20175	603P25175		603P32175	
18	45/64"			603P20180	603P25180		603P32180	
18.5					603P25185		603P32185	
19	3/4"				603P25190		603P32190	
19.5					603P25195		603P32195	
20					603P25200		603P32200	
20.5					603P25205		603P32205	
21					603P25210		603P32210	
21.5					<i>603P25215</i>	603P27215	603P32215	
22					<i>603P25220</i>	603P27220	603P32220	
22.5					<i>603P25225</i>	603P27225	603P32225	

øA		øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6
<i>mm</i>	<i>inches</i>	øD 25	øD 27	øD 29	øD 32	øD 35	øD 42	øD 49
23		603P25230	603P27230		603P32230	603P35230	603P42230	
23.5			603P27235		603P32235			
24			603P27240		603P32240	603P35240	603P42240	
24.5			603P27245		603P32245		603P42245	
25			603P27250		603P32250		603P42250	
25.5	1"			603P29255	603P32255			
26				603P29260	603P32260		603P42260	
26.5				603P29265	603P32265			
27				603P29270	603P32270		603P42270	
27.5					603P32275			
28					603P32280		603P42280	
28.5	1"1/8				603P32285			
29					603P32290	603P35290	403P42290	
29.5					603P32295			
30					603P32300	603P35300	603P42300	603P49300
30.5								603P49305
31						603P35310	603P42310	603P49310
31.5								603P49315
32						603P35320	603P42320	603P49320
32.5								603P49325
33						603P35330	603P42330	603P49330
33.5								603P49335

øA		øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6		
<i>mm</i>	<i>inches</i>	øD 40	øD 42	øD 44-45	øD 49		
34		603P40340	603P42340		603P49340		
34.5					603P49345		
35	1"3/8	603P40350	603P42350		603P49350		
35.5					603P49355		
36		603P40360	603P42360		603P49360		
36.5					603P49365		
37		603P40370	603P42370		603P49370		
37.5					603P49375		
38	1"1/2		603P42380		603P49380		
38.5					603P49385		
39			603P42390		603P49390		
39.5				603P44395	603P49395		
40			<i>603P42400</i>	603P44400	603P49400		
40.5				603P44405	603P49405		
41				603P44410	603P49410		
41.5				603P44415	603P49415		
42				603P45420	603P49420		
42.5				603P45425	603P49425		
43	1"11/16				603P49430		
43.5					603P49435		
44					603P49440		
44.5	1"3/4				603P49445		
45					603P49450		

INDEX

12.1	LIST OF AFTER-SALES CENTERS.....	2
------	----------------------------------	---

12.1 LIST OF AFTER-SALES CENTERS
AUSTRALIA - NEW ZEALAND

GIMCO – Giuliani Iemca Machinery Co. Ltd.	301-1, Dongsing Rd., Dali City, Taichung County, 412, Taiwan	Phone +886-4-2406-6970 Telefax + 886-4-2406-6943 E-mail: gimco@gimco.com.tw Website: www.gimco.com.tw
---	--	--

BRAZIL

IGM DO BRASIL LTDA.	rua Melo Palheta 165 CEP 05002030 Sao Paulo - Brasil	Phone +55 11 3801 3763 Telefax +55 11 3801 3563 Email: igmdobrasil@uol.com.br
---------------------	--	---

CHINA (PRC)

Bi-tech (Suzhou) Co. Ltd.	Wu Fang Road, Wu Jiang City, JiangSu Province - PRC	Phone +86 512 8155 6988 Telefax +86 512 8155 6986 E-mail: bi-tech@vip.163.com
---------------------------	--	---

CZECH REPUBLIC - SLOVAK REPUBLIC

ALBA PRECISION	Skorkovského 79 636 00 Brno	Phone +420 548 226 400 Telefax +420 548 532 689 E-mail: albabrno@sky.cz Website: www.albaprecision.cz
----------------	--------------------------------	--

DENMARK – NORWAY - SWEDEN

KENSON Component AB	Borgens Gata, 6 44139 Alingsaas	Phone ++46 322 637890 Telefax ++46 322 633367 E-mail: info@kenson.se Website: www.kenson.se
---------------------	------------------------------------	--

FINLAND

INDUSTRIAL TRADING HELSINKY OY	Klovinportti 5 02180 ESPOO - Finland	Phone +358 9 45592305 Telefax +358 9 455 92 306 E-mail: matti.valakari@iki.fi Website: www.ith.fi
--------------------------------	---	--

FRANCE

IEMCA France	145, rue Louis Armand ZI Des Grands Pres F- 74300 CLUSES	Phone ++33 450 896960 Telefax ++33 450 896135 E-mail: iemca@iemca.fr Website: www.iemca.fr
--------------	--	---

GERMANY (West - Nord)

Hoßfeld GmbH	Königsberger Straße 10 D-58511 Lüdenscheid	Phone ++49 02351 80521 Telefax ++49 02351 860442 Email : HossfeldgmbH@t-online.de
--------------	---	---

GERMANY (East)

IG GmbH	Motorstrasse 4 D - 70499 Stuttgart	Phone ++49 711 139991-0 Fax ++49 711 139991-25 E-mail: info@iggmbh.de
---------	---------------------------------------	---

GERMANY (South)

Reimo LOBERS	Rebgartenweg 5/1 D-79576 Weil am Rhein	Phone ++49 7621 69551 Telefax ++49 7621 69491 Email : mail@lobers.de
--------------	---	--

ITALY

IEMCA S.p.A.	Via Granarolo, 167 I-48018 Faenza (RA)	Phone 0546 / 698208 Telefax 0546 / 698290 Email : iemca@igmi.it Website: www.iemca.com
--------------	---	---

JAPAN

IGM Nippon K.K.	Tokyo-to, Edogawa-Ku, Nakakasai 7-31-15 Shimizu Bld 1th floor. Zip code 134-0083	Phone ++81 3 5605 8016 Telefax ++81 3 5605 8066 E-mail: h.murakami@ignippon.co.jp
-----------------	--	---

KOREA

U-HAN TRADING CO. LTD.	1111 Kumsan Building 17-1, Yoido-Dong Yeongdeungpo-Ku SEOUL, Korea	Phone ++82 2 782 2454 Fax ++82 2 780 1880 E-mail: uhanco@unitel.co.kr Website: www.uhantrading.com
------------------------	---	---

POLAND

Andrzej Gryko

 ul Włodarzewska 57F/23
02-384 Warszawa

 Phone +48 22 8231790
Fax +48 22 8231690
E-mail a.gryko@acn.waw.pl

SPAIN

 SISTECO Máquinas-Herramienta,
S.L.

 Pagatza Parke Industrial, 7A Saila
20690 Elgeta (Gipuzkoa)

 Phone 943-788058
Fax 943-768100
E-mail:empresa@sisteco.net

SWITZERLAND (Canton Ticino)

IEMCA S.p.A.

 Via Granarolo, 167
I-48018 Faenza (RA)

 Phone 0546 / 698208
Telefax 0546 / 698290
Email : iemca@igmi.it
Website: www.iemca.com

SWITZERLAND (French speaking area)

IEMCA France

 145, rue Louis Armand
ZI Des Grands Pres
F- 74300 CLUSES

 Phone ++33 450 896960
Telefax ++33 450 896135
E-mail: iemca@iemca.fr
Website: www.iemca.fr

SWITZERLAND (German speaking area)

Reimo LOBERS

 Rebgartenweg 5/1
D-79576 Weil am Rhein

 Phone ++49 7621 69551
Telefax ++49 7621 69491
Email : mail@lobers.de

TAIWAN – SINGAPORE – MALAYSIA - PHILIPPINES:

 GIMCO – Giuliani Iemca Machinery
Co. Ltd.

 301-1, Dongsing Rd.,
Dali City, Taichung County, 412,
Taiwan

 Phone +886-4-2406-6970
Telefax + 886-4-2406-6943
E-mail: gimco@gimco.com.tw
Website: www.gimco.com.tw

THAILAND

 GEM - General Engineering
Machinery Co.

 1/781 M. 17, Phahonyothin Rd,
Kukot-Lamlukka, Phatumthanee 12130
Thailand

 Phone +66-2-993-8548/9
Fax +66 2 993 8010
E-mail: sisara@hotmail.com

UNITED KINGDOM

Kitagawa Europe Ltd.

 Unit 1, The Headlands
Downton, Salisbury
Wiltshire SP5 4JJ

 Phone ++44 1725 514000
Telefax ++44 1725 514001
E-mail: jtownsend@kitagawaeurope.com
Website: www.kitagawaeurope.com

USA – CANADA - MEXICO

Bucci Industries USA Inc.

 9332 Forsyth Park Drive
Charlotte NC 28273 - USA

 Phone ++1 704 583 8341
Telefax ++1 704 583 8486
E-mail: info@bucci-industries.us

