

AUTOMATIC BAR FEEDER

ELENCO ALLEGATI
MANUAL FOR USE AND MAINTENANCE
KEYBOARD INSTRUCTION MANUAL
SPARE PARTS BOOK
SCHEMATICS
EC CONFORMITY DECLARATION FOR MACHINE

SIR52 MS52 P/F

EN

MANUAL FOR USE AND MAINTENANCE

Rel. 1 Date 20/05/2006 Cod. 610575420

S/N

SOFTWARE RELEASE

OP:

PLC:

REDATTORE: Bosi Andrea

PER APPROVAZIONE: Melandri Pierantonio

COSTRUTTORE: IEMCA division of IGMI S.p.A.

INDIRIZZO: Via Granarolo, 167 - 48018 Faenza (RA) - ITALY


Tel. 0546/698000 - Fax. 0546/46338 - 0546/46224

TLX 550879

TIPO DI DOCUMENTO: MANUAL FOR USE AND MAINTENANCE

PRODOTTO: AUTOMATIC BAR FEEDER


MODELLO: SIR52 MS52 P/F




1	GENERAL INFORMATION	SIR 52 MS52 P/F
2	TECHNICAL INFORMATION.....	SIR 52 MS52 P/F
3	SAFETY PROCEDURES - GENERAL INFORMATION.....	SIR 52 MS52 P/F
4	HANDLING AND INSTALLATION	SIR 52 MS52 P/F
5	ADJUSTMENTS AND SETTING-UP	SIR 52 MS52 P/F
6	USE AND OPERATION.....	SIR 52 MS52 P/F
7	BAR FEEDER MAINTENANCE	SIR 52 MS52 P/F
8	TROUBLES - CAUSES - CURES	SIR 52 MS52 P/F
9	PART REPLACEMENT	SIR 52 MS52 P/F
10	DRILLING MACHINE.....	SIR 52 MS52 P/F
11	GUIDE CHANNELS-BAR PUSHER-REVOLVING TIPS.....	SIR 52 MS52 P/F
12	GRIPPERS.....	SIR 52 MS52 P/F
13	LIST OF AFTER-SALES CENTERS	SIR 52 MS52 P/F

INDEX

1.1	TERMS OF WARRANTY	2
1.2	MANUAL PURPOSE.....	3
1.3	MANUFACTURER AND BAR FEEDER IDENTIFICATION	4
1.4	TECHNICAL ASSISTANCE	4
1.5	ANNEXES ENCLOSED	4

 Operations described in paragraphs showing this symbol, must be performed by qualified and skilled personnel only.
Any other operation can be performed either by qualified personnel or by professional bar feeder operators.

 **Before carrying out any servicing whatsoever on the bar feeder, it is of the utmost importance to read this manual carefully.**

1.1 TERMS OF WARRANTY

The warranty validity is subordinated to a correct assembly and coupling of the bar feeder to lathe. In particular, before the first start-up, carry out an accurate check to make sure the bar feeder is correctly aligned with the lathe and fastened with the expansion plugs as shown in section 4.

The product warranty is valid only if the bar loader is installed by an authorized technician with Original Installation Certificate. Please ask the technician, who will make the installation, to show the certificate, in order to ascertain the quality of the technical works being carried out.

The warranty shall begin from the date on the Installation Certificate duly filled in and signed.

The document must be sent per mail to:

CUSTOMER SERVICE
IEMCA division of IGMI spa
48018 Faenza (Ra) ITALY - Via Granarolo,167

IEMCA		INSTALLATION CERTIFICATE	N° 1005 /02
<small>ATTENTION: To comply with the warranty terms all parts of this form are to be filled in and mailed to IEMCA Italia</small>			
<small>Installation and training executed by:</small>			
Company	DATE	Installer	Servicing report No.
<small>Technician</small>			
<small>Executed at:</small>			
Customer	Participant/s <small>(write names in caps)</small>		
Country			
Bar feeder			
Serial no.			
Equip./Type			
SUBJECT			
Bar feeder's general description and running, operating cycle instructions.			<input type="checkbox"/>
Bar feeder tooling instructions and changeover instructions. Description and change of: guides, bar pusher, collet, half bushing, front nose and reduction nose			<input type="checkbox"/>
Description of operator's keyboard, description of parameters and their use.			<input type="checkbox"/>
Programming procedures based on the kind of process required.			<input type="checkbox"/>
Errors - Causes - Solutions; description of the main alarms listed on manuals.			<input type="checkbox"/>
Manuals and precautionary maintenance tips examination; Procedures to request IEMCA technical service.			<input type="checkbox"/>
Customer is familiar with the bar feeder and is aware of all its running and maintenance procedures having received such information during previous installations.			<input type="checkbox"/>
Marked subjects have been dealt with fully and thoroughly. Participant reports that training received was fully satisfactory. Side signature acknowledgement.			
NOTE: In order to benefit from our warranty - an IEMCA authorized technician must have carried out the installation - above mentioned "training" must be completed.			
Warranty terms is of 12 months beginning on the date of the installation and may not exceed 18 months from the delivery date. Warranty will have effect from the date of the general undersigning of this form. All parts of these form must be completely filled in and the same must be mailed to IEMCA, or returned by means of the installing technician, within 15 days.			Customer's stamp and signature
IGMI s.p.a.		IEMCA GIULIANI MACCHINE ITALIA S.p.A.	
<small>Strada Legato, Faenza (Ra) 48018 - Tel. 0545/466111 - Fax 0545/466122</small>		<small>Strada Legato, Faenza (Ra) 48018 - Tel. 0545/466111 - Fax 0545/466122</small>	
<small>Cap. Soc. € 4.800.000 i.v. - S.E.C. Ra 47171 - Reg. Imp. C.F. P.I. 04827610397 - C.G. n° 02817/00000</small>		<small>BEUCCEI</small>	
		<small>Copy for IEMCA</small>	

1.2 MANUAL PURPOSE

This manual has been written and supplied by the manufacturer, the information herewith contained has been written in Italian (manufacturer's language) to be translated to other languages, in order to comply with legal and/or commercial requirements. This manual is integral part of the bar feeder and of its equipment.

The compliance with the instructions contained herein ensures the operator and bar feeder safety as well as a running economy and a longer life of the bar feeder itself.

In order to allow a quick search of contents, consult the descriptive index. Particularly important parts of this manual have been highlighted in bold type and preceded by the following symbols:



DANGER - WARNING:

shows impending danger which might cause serious injuries, exert the maximum caution.



CAUTION - PRECAUTION

indicates measures to be adopted to avoid accidents or damages to property.



INFORMATION

technical instructions of particular importance.


For a quick search of topics see the table of contents.

In addition to this manual, which contains all the instructions for the bar feeder use and maintenance, one more is supplied: the "Push-button panel instruction manual".

The "Push-button panel instruction manual" contains all the instructions on how to use the installed software.

1.3 MANUFACTURER AND BAR FEEDER IDENTIFICATION

- A Manufacturer's identification
- B CE conformity marking
- C Year of manufacture
- D Bar feeder model
- E Serial number
- G Mains frequency
- H Absorption power
- M Feeding voltage
- N Direct driving voltage
- P Air pressure
- Q Bar feeder and pusher length
- R Breaking capacity
- S Number of base wiring diagram
- T Number of interface wiring diagram



INFORMATION:

Always provide the Manufacturer with the above mentioned specifications when requesting information or ordering spare parts, etc.

1.4 TECHNICAL ASSISTANCE

Whenever necessary, please apply to one of the Technical Assistance Centres shown in the attached list.



INFORMATION

when requesting technical assistance for the bar feeder, always specify the information shown on the machine dataplate.

1.5 ANNEXES ENCLOSED

- Electric diagram
- Pneumatic diagram
- Hydraulic diagram
- Lubrication system diagram
- Technical assistance departments list.
- List of after-sales centre

INDEX


2.1	DESCRIPTION OF MODELS	2
2.2	GENERAL BAR FEEDER DESCRIPTION	3
2.3	WORKING CYCLE - GENERAL DESCRIPTION	5
2.4	SAFETY DEVICES	6
2.5	SAFETY PLATES - LOCATION AND DESCRIPTION	8
2.5.1	Noise levels	9
2.6	TECHNICAL INFORMATION	10
2.7	FITTINGS - DESCRIPTION	13
2.7.1	Additional inner lighting lamp.....	13

2.1 DESCRIPTION OF MODELS

- The bar feeder is available in two models:
- SIR MS32 P for bars up to 32 mm with rack magazine A;
 - SIR MS32 F for bars up to 32 mm with bar bundle magazine type B;

MANUFACTURING FEATURES

- Maximum and minimum bar length.
- Table 1. Maximum and minimum bar length.



Models	Version	Max. length (mm)	Min. length (mm) (*)
SIR 52-MS52 P SIR 52-MS52 F	33	3300	2500
	38	3800	3000
	43	4300	3000



INFORMATION

Bars are to be loaded in the middle of the bundle magazine.


(*)To load short bars in the magazine bundle, please refer to IEMCA sales and customer services in order to verify the possibility of installing a short bar loading kit.

Bar feeling is performed in different stations: it can be carried out in two or more loading stations in every possible combinations.


2.2 GENERAL BAR FEEDER DESCRIPTION

The automatic bar feeder SIR52 MS32 P o SIR52 MS32 F, hereinafter referred to as the bar feeder, works in the field of the machine tools, more specifically to feed a multi-spindle lathe automatically.

The bar feeder has been designed to be installed instead of the lathe stock tube, thus replacing the bar guiding and feeding systems. It allows round, hexagonal and square bars to be loaded. The working cycle is controlled by a PLC fitted in the electric switchboard, able to dialogue with the lathe control.




- A LATHE
machines the bars loaded by the bar feeder.
- B RACK MAGAZINE
stores the bars.
- C CONVEYING DEVICE
takes single bars, moving them from the rack magazine to the inserting device.
- D DRIVE
drives the bar traverse device from the rack to the inserting device.
- E BUNDLE MAGAZINE
stores bars.
- F BAR SELECTING DEVICE
selects bars.
- G DRIVE
drives the bar selecting device.



- H BAR INSERTING DEVICE**
takes the bars and arranges them into the guide channels.
- L CLAMP AND BAR PUSHER UNIT**
inserts into and removes the bar from the collet.
Furthermore, it inserts into and removes the bar pusher from guide channels.
- M FEEDING DRUM**
inserts bars into lathe.
- N CONTROL PUSH-BUTTON PANEL**
controls all bar feeder functions.
- P HYDRAULIC CONTROLS**
adjust hydraulic oil flow.
- Q RACEWAY**
houses the lathe cables.
- R CUBICLE**
fits the electric switchboard.
- S REMNANT RECOVERY TANK**
collects bar remnants.
- T HYDRAULIC OIL PUMP**
produces pressure for the hydraulic functions of the bar feeder.
- U LUBRICATING OIL PUMP**
produces pressure to lubricate guide channels.
- V HYDRAULIC OIL TANK**
contains the hydraulic system oil.
- Z LUBRICATING OIL TANK**
contains the oil for the lubricating system.

2.3 WORKING CYCLE - GENERAL DESCRIPTION



SIR MS32 P



- Bars, loaded into magazine (A) manually, are taken by chain traverse device (B).
- Bar inserting device (D) introduces them into drum (C).
- Clamp device (E) inserts the bar into the bar pusher collet.
- Then, bars are fed into the lathe.




SIR MS32F

- Bars, previously loaded into magazine (A) through a lifting device, are selected by bar selecting device (B).
- Bar inserting device (D) introduces them into drum (C).
- Clamp device (E) inserts the bar into the bar pusher collet.
- Then, bars are fed into the lathe.

2.4 SAFETY DEVICES

A INTERLOCKED MOBILE GUARD. It is associated to microswitch (B):

- when selector  is turned to , the bar feeder stops by opening the guard;

- when selector  is turned to , the bar feeder does not stop by opening the guard, but there are few controls enabled, i.e. those necessary for setting up or change the machining procedures; they are: 



C AXIAL DISPLACEMENT LOCKING.


It is associated to sensor (D).
By releasing the lever, all lathe and bar feeder functions are disabled.

E INTERLOCKED MOBILE GUARD.


Associated to microswitch (F).
By opening the guard, all lathe and bar feeder functions are disabled.

G INTERLOCKED MOBILE GUARD.
Associated to microswitch (H).


By opening the guard, all bar magazine functions are disabled. The bar feeder keeps feeding the lathe until the feeding drum runs out of bars.




- L FIXED GUARD
Prevents the accidental access to bundle magazine.
- M MOBILE GUARD
Prevents the accidental access to the bar selecting station.
- N MAIN SWITCH
Disconnects the electric supply when servicing the electric switchboard.
- P EMERGENCY PUSH-BUTTON
By pressing it, all lathe and bar feeder functions are disabled.



2.5 SAFETY PLATES - LOCATION AND DESCRIPTION



 **DANGER - WARNING:**
Keep safety plates clean.

- A Danger of arm crushing.
- B Give the greatest attention to running parts.
- C Danger of material falling.
- D Do not remove safety guards.
- E Wear safety work gloves and shoes.
Do not lift any load exceeding 15 kg manually.
- F Do not open the bar feeder while it is running.
- G Caution: danger of electric shock.
- H The bar feeder must be fixed to the ground.

2.5.1 Noise levels

The bar feeder does not cause acoustic noise.

Noise occurs when lathe, to which the bar feeder is connected, is running and the bar turns into the bar feeder guide channels.

In such a situation, the noise level emitted depends on the following conditions:

- perfect alignment and levelling of the lathe-bar feeder unit;
- correct fastening of the lathe and bar feeder to the ground;
- perfect working order of the lathe bar gripping device;
- use of guide channels and bar pushers whose dimensions are suitable to the diameter of the bar to be machined;
- use of a front guiding bush of suitable diameter (if supplied);
- use of bars whose straightness is within the prescribed limits (max. deflection in mm equal to 0.5 per thousand of the bar length);
- use of a spindle liner with a diameter equal to the bar feeder guide channel diameter;
- spindle rotation speed suitable to the material to be machined;
- as far as the bar feeder is concerned, use of suitable oil, according to the diameter of the bar to be machined;
- all bar feeder guards must be closed.

If the above mentioned conditions are complied with, the noise level emitted during the bar rotation into the guide channel and measured according to the international standards, does not exceed the following limits:

- brass and steel round bars within 80* dbA
- steel hex. bars within 83 dbA
- brass hex. bars within 85 dbA

The noise level is affected by the actual conditions of the lathe to which the bar loader is applied as well as by the type of bars.

The operator should check if wearing personal protection equipment is required based on regulations in force in the country of use applicable to work environments.

*) Measurements taken with \varnothing 35 mm round bar, \varnothing 36 mm channel < 5% straightness at 3750 rpm with lathe Index MS52 Serial number

2.6 TECHNICAL INFORMATION





Table 1. Technical specifications

Value	Version		
	33	38	43
A	4900	5400	5900
B	1720	2220	2720
C	2620	3120	3620
D	4520	5020	5520
E	3250	3750	4250

Table 3. Technical specifications

	SIR 52-MS52 P	SIR 52-MS52 F	
Min round bar diameter	15 mm (25/64") *	15 mm (25/64") (version 33,38) *	15 mm (1/2") (version 43) *
Max round bar diameter	52 mm (2")		
Bar straightness	0,5 mm/m		
Max. bar length	3300 mm (version 33) - 3800 mm (version 38) - 4300 mm (version 43)		
Max. magazine capacity	n. 15 bars più 200 mm on the rack	2000 kg	
Supply voltage	380 three-phase / 50 Hz (other voltages upon request)		
Supply voltage	24 Volt D.C.		
Installed power	4,5 kW		
Feeding speed	up to 0.8 m/sec.		
Return speed	up to 0.8 m/sec.		
Bar change-over time	45 sec.		
Hydraulic system oil (not supplied)	Type C) HG32; quantity 80 l		
Guide channel oil (not supplied)	Type (C) CKB 100; quantity 170 l		
Compressed air	Least 6 bar (10 bar max) Recommended 7 bar		
Bar feeder weight	2800 kg (version 33)	3050 kg (version 33)	
	2900 kg (version 38)	3150 kg (version 38)	
	3000 kg (version 43)	3250 kg (version 43)	
Control unit weight (dry weight)	220 kg. Dry weight, 400 Kg with lubricating and hydraulic oil		


(*) Please contact IEMCA Sales or Service Departments before loading thinner bars.
 In pursuing a policy of continuous updating of the product, the manufacturer might introduce changes without any prior notice.



2.7 FITTINGS - DESCRIPTION

2.7.1 Additional inner lighting lamp

Lamp A and B allow the rear drum area to be lighted, to make operator's checking easier. Lamp C may be fitted upon customer's request.



INDEX

3.1	GENERAL SAFETY PRESCRIPTIONS.....	2
3.2	HANDLING AND INSTALLATION - Safety	3
3.3	ADJUSTMENTS AND SETTING UP - Safety	3
3.4	USE AND OPERATION - Safety.....	4
3.5	BAR FEEDER MAINTENANCE - Safety	4

3.1 GENERAL SAFETY PRESCRIPTIONS



It is of the utmost importance to read this manual carefully before installing, using or servicing the bar feeder or performing any other work . Constant compliance with the instructions in this manual is a guarantee of protection against injury.

- The operator and skilled engineer must perform only their specified duties.
- Do not tamper with the safety devices for any reason whatsoever.
- Comply strictly with the work health and safety regulations issued by the relevant authorities in the country of installation of the machine.
- IEMCA declines any liability whatsoever for injury to persons or damage to property if the relevant safety prescriptions are disregarded.

3.2 HANDLING AND INSTALLATION - Safety

- The bar feeder must be handled using suitable means and methods.
- Persons must not stand or transit underneath a suspended load, or within the range of action of the crane, lift truck or other suitable means of lifting and transportation.
- The working area and bar loading area must be cordoned off to prevent collisions between the operator and machines used to transport or handle the barstock or other materials.
- Correct positioning of the bar feeder, adequate lighting and a clean working environment are of the utmost importance as far as personal safety is concerned.
- The electric system connection must be made exclusively by skilled electricians.
- Make sure the electrical system is connected to an efficient earth circuit by means of a dedicated wire.

3.3 ADJUSTMENTS AND SETTING UP - Safety

- Carry out the adjustments as described in the user manual.
- Do not change working parameters to obtain performances other than those envisaged in the design and testing phases.
- Do not adjust the bar feeder when it is running unless expressly requested to do so in the manual.
- Do not feed the machine with bars having dimensions different from those recommended by the manufacturer.
- Do not use hoses as handholds.








3.4 USE AND OPERATION - Safety

- The working area around the bar feeder must always be kept clean and uncluttered in order to allow immediate access to the emergency devices and bar loading to be performed without creating obstructions or danger.
- Perform the cycle starting sequence as prescribed.
- Keep hands and other parts of the body well clear of moving parts or live electrical parts.
- Remove bracelets, watches, rings and neckties.
- Whenever necessary, use strong work gloves with 5 fingers, which do not reduce the sensitivity or power of your grip.
- Wear working shoes as well as personal protection devices provided for by the accident prevention regulations in force in the country in which the machine is installed.
- Inform maintenance personnel of all operating anomalies that come to your attention.
- Before starting the bar feeder, make sure that there are no personnel engaged in servicing or cleaning the machine.

3.5 BAR FEEDER MAINTENANCE - Safety

- Do not allow unauthorized persons to carry out maintenance.
- Read this manual carefully before carrying out maintenance.
- Do not lubricate, repair or adjust the bar feeder while it is running, unless expressly indicated to do so in the manual.
- Stop the bar feeder in accordance with the prescribed methods before carrying out lubrication or other work.
- Do use matches, lighters or torches when servicing the machine in the presence of inflammable fluids.
- Keep spent oil in suitable containers and consign it to companies specialized in the storage and disposal of polluting waste products.
- Do not pollute the environment.
- Use original IEMCA spare parts only.


INDEX

4.1	PACKING	2
4.2	LIFTING - PREAMBLE 	3
4.2.1	Lifting without packing	3
4.2.2	Lifting with a pallet	5
4.2.3	Lifting with a box	5
4.3	INSTALLATION AREA - FEATURES 	6
4.4	INSTALLATION 	7
4.4.1	Preliminary operations	7
4.4.2	Positioning	8
4.4.3	Levelling	11
4.4.4	Alignment	12
4.4.5	Fastening the bar feeder	15
4.4.6	Final operations	15
4.4.7	ADJUSTMENT OF BAR END DEVICE ZERO POSITION	17
4.5	HYDRAULIC CONTROL UNIT - OIL LOADING 	18
4.5.1	Hydraulic control unit - Connection	19
4.6	ELECTRIC CONNECTION 	20
4.7	PNEUMATIC CONNECTION 	21
4.8	ALIGNMENT - FINAL CHECK 	21

4.1 PACKING

There are three possible bar feeder packagings:

- A **WITHOUT PACKING:** the bar feeder is divided from the hydraulic control unit.
- B **PALLET:** the bar feeder is placed on a pallet and covered by a protective sheeting.
- C **BOX:** the bar feeder is contained in a box and covered by a protective sheeting.



4.2 LIFTING - PREAMBLE




DANGER - WARNING:

Lifting and handling shall be carried out using suitable means and performed by skilled personnel only.

4.2.1 Lifting without packing

Before lifting the bar feeder, be sure the supports of the rear door have been installed; they should be fixed to the rear legs of the bar feeder and must be mounted as close as possible to the lower surface of the rear door.




LIFTING WITH TUBE

Table 1. Belt length

Model	Version	Belt C (mm)	Belt D (mm)
SIR 52-MS 52 P SIR 52-MS 52 F	33	3000	3000
	38	2500	3000
	43	2500	3000

To lift the bar feeder it is necessary to fix the eye-bolts (A) to the supports. Check the length of the belts (C) and (D) and apply wooden pads (E). Use a bridge crane or a self-propelled crane.




To uplift the hydraulic drive unit, use belts or chains together with a bridge crane or a self-moving crane having an appropriate loading capacity.

i **INFORMATION:**

Before lifting and moving the bar feeder, make sure that the eye-bolts are properly and firmly fixed against the support surface, that the front nose has been correctly positioned and that the rings are rigidly fixed.

Do not let weights swing or bounce during transport.



4.2.2 Lifting with a pallet


Use two belts of 8 m in length and a bridge crane or a self-propelled crane having adequate capacity load.

By means of a bridge crane and of belts having adequate capacity and with reference to the belt lengths indicated in table 1 (paragraph 4.2.1.) it is possible to move a bar feeder on pallet following the same instructions as for a bar feeder with no packaging (paragraph 4.2.1).

In this case, the length of the belts and of the lifting system must be set according to the weight of the bar feeder, of the pallet (400kg) and of the devices that have been fixed on it (see table 3, paragraph 2.6).


Before lifting and moving a bar feeder on pallet, remove the protective film and make sure the additional equipment has been fixed to the pallet; make sure that all screws and bolts have been properly tightened.

Do not let weights swing or bounce during transport.



4.2.3 Lifting with a box

Use two belts of 8 m in length and a bridge crane or a self-propelled crane having adequate capacity load. The case weight is 1000 kg.




4.3 INSTALLATION AREA - FEATURES

- The floor should be stable and levelled to guarantee good fastening to the ground.
- Provide an area of suitable dimensions according to the type of feeder use.

Table 2. Dimension of the installation area.

Models	Version	A (mm)
SIR 52 P SIR 52 F	33	4950
	38	5450
	43	5950

- The areas: (B) (work area), (C) (bar feeding area) and (D) (remnant discharge area) should be properly delimited to prevent collisions between the operator and any handling equipment or transport vehicles travelling near the bar feeder.
- The chosen area has to be lit and must have a distribution socket for pneumatic energy.
- During operation, the feeder will release small amount of oil vapors. Make sure that the premises where the feeder is installed are suitably ventilated.



4.4 INSTALLATION


The most important phase of installation is the alignment between the bar feeder and lathe, hence said operation shall be carried out by skilled personnel with the maximum precision.



WARNING-CAUTION:

A wrong alignment may be the main cause of bar feeder malfunctioning and may cause damages to the machine.


4.4.1 Preliminary operations




- Check lathe spindles (A) levelling; adjust lathe levelling, if necessary.

4.4.2 Positioning


- Position the bar feeder near the lathe.
Lift the bar feeder and remove feet (A) and tie rods (B) if they interfere with the bowls and the ejectors of the lathe.




- Loosen grub screws (C) and adjust the height of screws (D) of the value.




- Lower lever (E) and move the feeding drum backwards.


INFORMATION


In order to help the drum displacement, the barfeeder need to be on a flat surface and levelled.



Please use the special security block and adjust the back door during the facing in right way.




- Position the bar feeder behind the lathe. Screws (D) have to be at the same height as holes(F); respect value (G) mentioned.
- Introduce screws (H) complete with washer and screw without tightening.
- Put the bar feeder down and remove feet (A) and tie rods (B) if they had not been removed when positioning.
- Open the rear guard and replace screw (D) (red) with pin (E) supplied.



4.4.3 Levelling

- Check the cross and longitudinal alignment by means of the proper tables of reference. For any adjustment, act on rear feet (A) and on screws (B).




4.4.4 Alignment



INFORMATIONS

Operation to be carried out by IEMCA skilled personnel only.




- Stretch a nylon yarn (\varnothing 1 mm) between the bar feeder and the lathe collet as mentioned below:
 - assemble yarn-holder block (E) instead of the last pair of reels;
 - position a cap (F) with hole \varnothing 1,5 mm. (to be manufactured by the client) in the lathe collet;
 - ove the feeding drum slightly forwards in relation to the back limit stop and stretch yarn (G); move the drum backwards and lock sliding to keep the yarn stretched.




INFORMATION:

The alignment of at least two guide channels must be performed.


- For the rear cross adjustments, land two calibrated blows in the feet plates side with a mallet.
For the front cross adjustments and the front adjustments in height, act on screws (L) and (B).
During this phase, the adjustments done while levelling must be respected; in most cases, it is therefore necessary to find the right adjustment of the bar feeder position.



- With a vernier caliper, check the cross alignment of those positions pointed out by the arrows; adopt a ± 0.15 mm tolerance.
To check the height and the front centering, introduce centering pins in the rear driving plate moving the feeding drum forwards and backwards.




- When alignment is over, bring the drum to the front limit stop position .
- Tighten in sequence:
 - screws (Q);
 - grub screws (L) and their nuts;
 - the screws of the rear feet.



4.4.5 Fastening the bar feeder


FASTENING TO THE GROUND

- Fix the bar feeder to the ground with expansion plugs (A).



4.4.6 Final operations


- Bring the drum to the back limit stop position.
- Check the bar feeder leveling and alignment again.
- Remove the nylon yard and the pierced cap of the spindle.
- Remove the yarn-holder block and reassemble the two reels.
- Remove the centering sleeves, reassemble the bushes and assemble the special reducers (paragraph 5.9.).
- Bring the drum to the front limit stop position.




**CAUTION:**


remove pin (E) before starting the bar feeder.

- Remove the whole equipment used to lift the bar feeder.



4.4.7 ADJUSTMENT OF BAR END DEVICE ZERO POSITION


- Press button  to move the bar pusher forward until it reaches the lathe collet.
- Loosen the bar end sensor (D) adjustment knob (B).
- Loosen the screws (C) securing the "ZERO" backing plate.
- Move the bar end sensor (D) towards the chain sprocket until it reaches the chain outer position.
- Tighten the knob (B) to maintain the position of the sensor.
- Move the "ZERO" backing plate as close as possible to the sensor bracket.
- Tighten the screw (C) securing the "ZERO" backing plate.



4.5 HYDRAULIC CONTROL UNIT - OIL LOADING

LUBRICATING OIL

- Remove cover (A).
 - Loading should be carried out using lubricating oil of the following class: C CKB 100. Quantity: 250 l.
- Fill the oil tank to the fill level.



INFORMATION



Perform this operation after some hours have passed since the bar feeder stop. In that way the oil may flow back towards the control unit.

HYDRAULIC OIL



- See enclosed documentation: "Hydraulic System".

4.5.1 Hydraulic control unit - Connection

- Fit the control unit under the bar feeder.
- Connect pipes (A) of the hydraulic oil system.
- Connect the lubricating oil delivery pipe (B).



- Adjust the lubricating oil return pipe (C), operating the relevant ring (D).
- Connect the electric socket (X5) (F).






In case of transport, displacements or further installations of the bar feeder, a plug (E) is supplied, to be introduced into the oil collecting tank to prevent the lubricating oil from leaking while handling.

FIRST STARTING-UP OF THE HYDRAULIC OIL PUMP

An appropriate start of the pump is of the utmost importance, since the correct lubrication of the internal parts of the pump depends on this phase.

- Start the pulse-operated electric motor in order to allow for the priming and the lubrication of the pump parts.
- Check that the direction of rotation is correct with respect to the indication shown on the motor grid and on the coupling flange of the pump.
- The priming of the pump is not only shown on the pressure gauge mounted on the delivery pipe, but also by the change in the noise of the pump, as it becomes more silent when it has been successfully primed.



4.6 ELECTRIC CONNECTION



DANGER - WARNING:

this type of operation should only be entrusted to skilled technical staff to comply with the applicable standards and statutory regulations in force.

The feeder is normally provided with a multiple plug to plug into the special lathe outlet; refer to the "Wiring diagram" if necessary.

4.7 PNEUMATIC CONNECTION


- Connect pipe (D) of the pneumatic system to the quick coupling (G).

FILTER A

- Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C). Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C).

PRESSURE SWITCH

- The lubrication system is equipped with a control pressure switch, set to a pressure of 4.5 bar.
- Proceed as follows to adjust the pressure switch:
 - remove the pressure gauge protecting glass;
 - turn the adjusting screw (G) anticlockwise (+) to increase pressure or clockwise (-) to lower it;
 - after this operation, replace the pressure gauge protecting glass.




CAUTION:


should the pressure switch needle point a Pressure=0, do not absolutely turn the adjusting screw (H) clockwise (-), for this will cause pressure switch breakage.

4.8 ALIGNMENT - FINAL CHECK








When the installation is over, make sure clamp device (A) axis is aligned with the guide channel axis.

Keep to the following procedure: move the clamp device to the "bar insertion into collet" position and close the sprockets by pressing key  F3. Sprockets must close without interfering with the bar pusher inserted into the clamp device.

In case of misalignment, please apply to IEMCA technical assistance department.



INDEX

5.1	SIR 52-MS 52 P RACK MAGAZINE - ADJUSTMENT 	2
5.1.1	Bar selection - Adjustment.....	2
5.2	SIR 52-MS 52 F BUNDLE MAGAZINE - ADJUSTMENT 	3
5.2.1	Bars drop - Quantity adjustment	3
5.2.2	Pressure foot - Adjustment	4
5.2.3	Separation push-rods - Adjustment	5
5.3	GUIDE CHANNELS - ADJUSTMENT 	6
5.3.1	Standard Working Mode	6
5.3.2	Working mode with staggered sprockets	7
5.3.3	Working mode with standard and staggered sprockets	9
5.4	BAR-PUSHER - PRELIMINARY OPERATIONS AND FITTING 	14
5.4.1	Collets - Selection and Preliminary operations	14
5.4.2	Bar-pusher - Assembly	14
5.4.3	Bar-pusher- Guide tube fitting.....	15
5.5	BARSTOCK LENGTH - ADJUSTMENT 	16
5.6	WORKING PRESSURES - ADJUSTMENTS 	17
5.6.1	Dynamic thrust (A).....	18
5.6.2	Clamps grip (B).....	19
5.6.3	Clamps introduction force (D)	19
5.6.4	Feeding speed (E)	19
5.6.5	Best working pressure	20
5.7	AIR FILTER - ADJUSTMENTS 	21

5.1 SIR 52-MS 52 P RACK MAGAZINE - ADJUSTMENT

5.1.1 Bar selection - Adjustment


Turn the adjustment screw (B) to adjust the position of the limit stop (A) according to the bar diameter. The adjustment value (C) should be about 1 mm less than the diameter of the bar.

For bar diameters 15 to 25 mm, install guide channel (D) and fix it with the screws (E); value (F) corresponds to the bar diameter plus 1 mm.

For bar diameters 11 to 15 mm, it is recommended to install guide channel (D) though not strictly necessary.

For bar diameters over 15 mm, loosen screw (G) and remove guide channel (D).


Both guide channel (D) and support (H) are supplied with the bar feeder.



5.2 SIR 52-MS 52 F BUNDLE MAGAZINE - ADJUSTMENT

5.2.1 Bars drop - Quantity adjustment

Adjust levers stop point (A) by operating screws (B). The bars quantity shall be checked during the first selection cycles, keeping into account that bars must be arranged along a part of the belts plane of approx. 200 mm.




5.2.2 Pressure foot - Adjustment

Hexagonal and round bars

Regulate the pressure foot (A) height so that the nut (B) stays at a distance of $0,5 \div 1$ mm from the limit stop when there are some bars under the foot. Adjustment is carried out operating nuts (B) horizontally adjust the pressure foot position, in order to cover completely the bars in the selection area, thus allowing a certain number of bars to dwell whenever the stock tube lifts and unloads bars.

Use screws (C) holes and/or the double holing (D) to carry out the adjustment.

Should it be necessary, operate screws (E) so that the pressure foot plane is parallel to the belt plane.




Square bars

Regulate the pressure foot (A) height so that the nut (B) stays at a distance of $0,5 \div 1$ mm from the limit stop when there are some bars under the foot. Carry out the adjustment operating nuts (B).

The foot position must allow the first bar (E) to lift; as far as adjustment is concerned, use screws (C) holes and/or the double holing (D).

Whenever necessary, operate screws (E) so that the pressure foot surface is parallel to the belts surface.




5.2.3 Separation push-rods - Adjustment


Round and hexagonal bars

HEIGHT ADJUSTMENT

Adjust the push-rod (A) height by operating the knob (B) so that the first bar (C) remains in its position once the belts return.

DEPTH ADJUSTMENT

Adjust the push-rod (A) depth by operating knob (D) so that it is positioned between the first bar (C) and the following bar. Check the adjustments by pressing key .




Square bars

HEIGHT ADJUSTMENT

Adjust the push-rod (A) height by operating the knob (B) so that the first bar (C) is lifted just as much to be held when belts reverse the direction.

DEPTH ADJUSTMENT

Adjust the push-rod (A) depth by operating knob (D) so that it is positioned in the centre of the bar section.

Check the adjustments by pressing key .

5.3 GUIDE CHANNELS - ADJUSTMENT








DANGER - WARNING:

the following procedures must be carried out or authorized by a responsible and expert operator, who owns the selector key to carry out this procedure.

5.3.1 Standard Working Mode



- Turn  selector switch to  position and open the guard.
- Open the sprockets by pressing the  key .
- Adjust the diameter of the guide channel selecting one of the four settings as follows (fig. 10):
 - loosen pin (B);
 - screw pin (B) down into one of the positioning holes, 1,2,3 or 4;
 - make sure the pin secured correctly.
- Close sprockets by pressing  key.



INFORMATION

Diameters not included in the table "RECOMMENDED ROUND BAR Ø" may cause vibrations and failures to the bar feeder.

It may therefore be necessary to reduce bar rotation speed.

For further information regarding work diameter, contact IEMCA Customer Service.

5.3.2 Working mode with staggered sprockets

If round bars are used, in order to improve bar guiding, all sprockets can be made to have the same outside diameter as the barstock. This working mode should only be used when strictly necessary, as it will cause an early wear of the guide channels.




DANGER - WARNING:




failure to comply with the procedure described below may cause serious damage to the bar feeder.



INFORMATION

This work mode is not used only when position 4 is selected.




- Turn the selector  switch to position  and open the guard.
- Open the sprockets by pressing the button .
- Regulate the diameter of the guide channel selecting one of the following three working positions in the following way (fig. 12):
 - loosen pin (B);
 - screw pin (B) down into one of the positioning holes, 1,2,3 or 4 or into a midposition;
 - make sure the pin secured correctly.

Set the guide channel adjustment position to a diameter immediately inferior to the diameter that would normally be selected when working in "STANDARD WORKING MODE".


EXAMPLE (with SPROCKET \varnothing 19 (d) - \varnothing 33 (c) - \varnothing 43 (b) - \varnothing 53 (a)), to load \varnothing 22 bars with a \varnothing 32 bar-pusher:

- If working in "Standard working mode" the sprocket guide must be set to position "c" (or in the \varnothing 33 guide channel, see fig. 0031), setting pin (B) in position 2 (see fig. 52006100109).
- In "Staggered Sprockets Working Mode" the guide channel must be set to position "d" (or in the \varnothing 19 guide channel, see fig. 0031), setting pin (B) in position 1 (see fig. 52006100109).




**OPERATIONS REQUIRED TO SET UP
"STAGGERED SPROCKETS WORKING MODE"**

- Set parameter 18 "Guide working mode (0-1)" to mode 1; see the "Keyboard Instruction Manual".
- Set the guide channel opening cylinder stroke as follows:
 - open rear guard (C);
 - remove fork (D) and move nose (E) axially;
 - insert the fork in the slot corresponding to the required mode according to the scheme shown in the table;



Guide channel Configuration *		Position of pin B	Slot for Fork D	Setting for staggered channel
57	53	4	--	a
46	43	3	IV	b
33	33	2	III	c
19	19	1	II	d

- Close the sprockets by pressing the  button.

(*)The configuration of the guide channel must be carried out according to the bar feeder tooling and to the lathe type.



INFORMATION:

If shaped bars (i.e. hexagonal or square bars) are loaded, revolving speed should be reduced in order to prevent premature wear and tear of the sprockets.



INFORMATION:

Please contact IEMCA Sales or Service Department if you need a special configuration of guide channel - bar pusher and bar.



INFORMATION

If shaped bars (hexagonal, square bars etc.) are to be machined, make sure that the guide diameter is larger than the diameter circumscribed on the profile, in order to prevent bar scraping against the sprocket edges.



INFORMATION:

In standard working mode parameter 18 "Guide working mode (0-1)" (see the "Keyboard Instruction Manual") must be set to mode 0; fork D can be positioned in any of the slots.




INFORMATION:

When working in "staggered channel" mode, only 3 settings shown in the table are selectable notwithstanding the 4 available guide channels for the smallest channel "d" cannot be staggered to a smaller channel.

5.3.3 Working mode with standard and staggered sprockets

Standard working mode


The two pairs of sprockets have the same rotation and do not move while the bar pusher is moving.



Ideal staggered channels mode


The selected channel is immediately inferior to the diameter of the bar pusher ; the bar pusher opens the passage while moving forward ; by causing the sprockets to rotate and be set to the next guide channel the diameter of which is larger than the selected channel.

The bar diameter larger (Picture 051) or even slightly larger (Fig.041) than the diameter of the selected channel. .



EXAMPLE (SPROCKET $\varnothing 19$ (d) - $\varnothing 33$ (c) - $\varnothing 43$ (b) - $\varnothing 53$ (a)), to machine $\varnothing 36$ bars using a $\varnothing 42$ bar-pusher:

- In "Staggered Sprockets Working Mode" the guide channel must be set to an intermediate position between "c" and "d" (that is to say that the sprocket edges create a channel of approximately $\varnothing 36$, see fig.0031), setting pin (B) to position 1• (see fig.52006100109).

**CAUTION:**


In staggered sprockets mode, do not use collets with slots that could cause accelerated wear of the sprockets IEMCA 600P. type collets.

Table 1. Standard working mode

COMPARATIVE TABLE OF MACHINING DIAMETERS (mm) FOR STANDARD OPERATION MODE									
MODEL	PIN POSITION	C Max Ø	Ø C	Ø B	Ø F	Ø A		POSITION OF THE FORK	PARAMETER 18 GUIDE CHANNEL OPERATION MODE
			Guide channel Ø	Bar pusher Ø	Engagement Ø on Rotating Tip Collet	Round bar Ø (*) RECOMMENDED			
						MIN	MAX		
SIR 52 MS52 P/F	1	53	19	18	11 G6	10	16(18)	/	0
	2		33	32	20 G6	16	29(32)	/	0
	3		43	42	20 G6	29	39(42)	/	0
	4		53	52	20 G6	39	49(52)	/	0

(*) Values of the diameter circumscribing the bar, which may be attained with IEMCA steel collets and SCHLENKER-type coupling (Table 1 summarising IEMCA collets for round bars). For shaped bars, the values must be checked according to the selected collet (Tables 2-3 summarising the collet type UNILOCK).

- A Bar diameter
- B Bar-pusher diameter or rotating tip
- C Guide channel
- F Collet engagement on rotating tip



16_125_1

Table 2. Working mode with staggered sprockets

COMPARATIVE TABLE OF MACHINING DIAMETERS (mm) FOR STANDARD OPERATION MODE (GUIDE 19-33-43-53)									
MODEL	PIN POSITION	C Max Ø	Ø C	Ø B	Ø F	Ø A		POSITION OF THE FORK	PARAMETER 18 GUIDE CHANNEL OPERATION MODE
			Guide channel Ø	Bar pusher Ø	Engagement Ø on Rotating Tip Collet	Round bar Ø (*) RECOMMENDED			
						MIN	MAX		
SIR52 MS52 P/F	1 Tra 1 e 2	52	19 19-33	18	15 G6	15	18 22	II	1
	2 Tra 2 e 3		33 33-43	32	20 G6	16	32 36	III	1
	3 Tra 3 e 4		43 43-53	42	20 G6	30	42 48	IV	1
	4		53	52	20 G6	35	52	-	0

(*) For shaped bars, values must be checked according to the selected collet (Tables 2-3 summarising the IEMCA 600P collet type).

Use of the drilling unit:


- Bar min. Ø20 mm: use drill Ø10 mm.
- Bar Ø21 mm to Ø28 mm: use drill Ø15mm.
- Bar Ø29 mm to Ø52 mm: use drill Ø20mm.



INFORMATION:

For special applications, please contact IEMCA After Sales Department.

- A Bar diameter
- B Bar-pusher diameter or rotating tip
- C Guide channel
- F Collet engagement on rotating tip




Values shown in the table are based on two conditions:

1. According to the instructions of the collet manufacturer, the outer side of the collet must be at least 1 mm thick.
2. Sprockets are on their intermediate position (edges in contact with the bar) forming thus a channel the diameter of which is approximately 1 mm smaller than the guide channel diameter resulting from sprocket standard rotation.

1• = 19/33
2• = 33/43(46)
3• = 43/53(57)

1 = 19
2 = 33
3 = 43(46)
4 = 53(57)



5.4 BAR-PUSHER - PRELIMINARY OPERATIONS AND FITTING

5.4.1 Collets - Selection and Preliminary operations


- A Round bars: see enclosed tables.
- B Hexagonal bars: use a drill with a diameter 1 mm approx. less than the sharp edges diameter (see enclosed tables).
- C Square bars: use a drill with a diameter 1.5 mm approx. less than the sharp edges diameter (see enclosed tables).

Check the introduction force into collet by using a bar remnant. The force value must be $40 \div 60$ kg; in case of exceeding value, shorten the rear polyurethane length of 5 mm at a time.




CAUTION

Collet outside diameter must be at least 0.5 mm smaller than the bar pusher outside diameter.



5.4.2 Bar-pusher - Assembly

- Introduce slightly clutch unit (A) into rod (B) seat, turn up to obtain a small yielding and complete the insertion.
- Insert collet (C) into rod (B) seat, insert pin (D) until the clutch is engaged.








5.4.3 Bar-pusher- Guide tube fitting



DANGER - WARNING:

the following procedure has to be carried out by the responsible skilled technician, who also owns the key of the selector switch allowing this operation to be done.



- Bring selector  switch to position  and open the guard.
- Open sprockets by pressing key .
- Fit the bar-pusher (A) of suitable diameter into seat (B) of the feeding carriage.
- Close sprockets by pressing key .
- Carry out said operation in the other guide tubes.

5.5 BARSTOCK LENGTH - ADJUSTMENT


To determine the remnant length, adjust the end-of-bar device in the following way.

- Loosen the knob (A) on the sensor mounting.
- Use the position indicator (B) to shift the sensor position up to the value corresponding to the length of the workpiece plus the width of the cutting tool.
- Tighten the knob (A).



CAUTION:

To avoid damages to the structures, check block (B) position whenever changing the lathe collet or the bar pusher diameter.



INFORMATION:

The max. length allowed for workpiece + width of the cutting tool is 160 mm, corresponding to position "C". Please contact IEMCA Sales or Service Department in case a longer length is required.

5.6 WORKING PRESSURES - ADJUSTMENTS 

Table 2. Working pressures (bar) table

Bar diameter (mm)	A Dynaminc thrust	B Clamps grip	C Static thrust	D Introduction force
20	40	55	5	27
30	50	60	5	29
40	60	65	5	31
52	70	70	5	33



INFORMATION


Values in the table are indicative only and they apply to round steel bars. Values may change according to the material machined, to the bar profile and to lather specifications (collet opening time, barstock length, etc.).

5.6.1 Dynamic thrust (A)

Table 3. Dynamic thrust (A)

Dynamic thrust pressure (bar)	Theoretical Thrust of the Bar pusher (N)
80	1250
70	1210
60	1140
50	1000
45	900
40	810
35	750
30	700

The dynamic thrust is the force through which the bar-pusher carriage feeds the bar. It works on the feeding station. To adjust it, operate knot (A).



5.6.2 Clamps grip (B)

The clamps grip is the force through which clamps hold the bar during the introduction phase into collet.

To carry out adjustment, operate knob (B).

5.6.3 Clamps introduction force (D)

The force of introduction is the force through which the bar is introduced into the bar-pusher collet and the bar remnant is extracted.

To carry out adjustment, operate knob (D).

5.6.4 Feeding speed (E)

The feeding speed is the speed at which the bar feeds at each lathe opening.



CAUTION:

A too high feeding speed may cause damage to lathe equipment.

A too low feeding speed may cause the collet to close before the complete feed of bar.

To carry out adjustment, operate knob (E).

5.6.5 Best working pressure

The value of the optimal operating pressure of the pumps must be adjusted at 80 bars.

To adjust it, see enclosed documentation:

"Hydraulic System"



5.7 AIR FILTER - ADJUSTMENTS


PRESSURE SWITCH

- The air filter-regulator is equipped with a control pressure switch, set to a pressure of 4.5 bar.
- To adjust the pressure switch proceed as follows:
 - remove the pressure gauge protecting glass;
 - turn the adjusting screw (G) anticlockwise (+) to increase pressure or clockwise (-) to lower it;
 - after this operation, replace the pressure gauge protecting glass.







CAUTION:

should the pressure switch needle point a Pressure=0, do not absolutely turn the adjusting screw (H) clockwise (-), for this will cause pressure switch breakage.




INDEX










6.1	PUSH BUTTON PANEL - CONTROL DESCRIPTION	2
6.2	MAGAZINE PUSH-BUTTON PANEL - CONTROL DESCRIPTION	11
6.3	LUMINOUS INDICATOR - SIGNAL DESCRIPTION	12
6.4	STARTING THE BAR FEEDER	13
6.4.1	Cold start	13
6.4.2	Hot start.....	13
6.5	BARS TO BE MACHINED - CHARACTERISTICS AND PREPARATION	14
6.5.1	BAR STRAIGHTNESS - Measurement	16
6.6	BARSTOCKS - LOADING	18
6.7	PROGRAMMING - PARAMETERS ENTRY 	20
6.8	WORKING DIAMETER CHANGE - OPERATIONS SEQUENCE 	20
6.8.1	Changing the machining diameter without the stock guide tube diameter change	21
6.8.2	Change of the working diameter without changing the guide tube diameter	23
6.8.3	Changing the machining diameter without the stock guide tube diameter change - Quick procedure.....	25
6.8.4	Changing the machining diameter without the stock guide tube diameter change	27
6.9	BAR FEEDER STOP.....	28
6.10	EPROM LOADING PROCEDURE 	29


6.1 PUSH BUTTON PANEL - CONTROL DESCRIPTION

- A Main controls.
- B Controls for manual operation.
- C Display controls and LEDs.
- D Controls for manual operation of drilling machine.


MAIN CONTROLS




- 1 Pilot light, voltage on.
- 2 Reset push-button, alarm.
- 3 Key-operated two-position selector (S7.4)
 - Position : the push-button panel is enabled for the "message display" mode.
 - Position : push-button panel enabled to data entering mode.
- 4 Key-operated two-position selector (S1112)
 - Position : bar feeder enabled to automatic or manual operation.
 - Position : only controls      enabled, with open guards as well.
- 5 Emergency push-button panel to stop bar feeder; the latter can be restarted only after having manually released the push-button (S85).
- 6 Reset button of drilling machine safety control unit.

PROGRAMMING AND MANUAL FUNCTIONS CONTROLS



- F1 Key to open / close guide channels only in the area of bar pusher completely backwards. Press it to control operation, press it again to control return.
- F2 Key to open / close bar pusher locking. Press it to control operation, press it again to control return.
- F3 Key to open / close guide channels. Press it to control operation, press it again to control return.
- F4 Key to open / close clamps. Press it to control operation, press it again to control return.
- F5 Key for bar insertion / extraction. Press it to control operation, press it again to control return.
- F6 Key for bar holder lever rotation upwards / downwards. Press it to control operation, press it again to control return.
- F7 Key for clamp arm rotation towards drum. It controls the device in only one direction. Press push-button till position is reached. If push-button is released in advance, the device comes back to starting position.
- F8 Key for clamp arm rotation outside drum. It controls the device in only one direction.
- F9 Key for lever arm rotation towards drum. It controls the device in only one direction. Press push-button till position is reached. If push-button is released in advance, the device comes back to starting position.



- F10 Key for lever arm rotation outside drum.
It controls the device in only one direction.
- F11 Key for manual bar pusher movement backwards at low speed.
- F12 Key for manual bar pusher movement forwards at average speed.
- F13 Key to select bar feeder manual operation.
- F14 Key to select bar feeder automatic operation.
- F15 Key for bar feeding on selection belts.
SIR 52-MS 52 F only.
- F16 Key for bar return on selection belts.
SIR 52-MS 52 F only.
- F17 Key for lever movement upwards / downwards.
Press it to control operation, press it again to control return.
SIR 52-MS 52 F only.
- F18 Key for selection push-rod movement upwards / downwards.
Press it to control operation, press it again to control return.
SIR 52-MS 52 F only.
- F19 Key to switch on / off inner lighting lamp.
Push it to control switching on, push it again to control switching off.
- F20 Key to recall "MAIN MENU".

DISPLAY CONTROLS AND LEDES


- 1 Key for numerical value 1.
- 2 Key for numerical value 2.
- 3 Key for numerical value 3 and to access the date and hour programming mode
- 4 Key for numerical value 4.
- 5 Key for numerical value 5.
- 6 Key for numerical value 6 and to enter the password entry mode for protected parameters.
- 7 Key for numerical value 7.
- 8 Key for numerical value 8.
- 9 Key for numerical value 9.
- 10 Key for numerical value 0 or to recall selection cursor.
- 11 Key for "minus" or "plus" sign.
- 12 Key for "comma" sign.
- 13 Key for "CLEAR" function:
 - to stop selection function,
 - to return to the value which had been displayed before the non-confirmed modification,
 - to return to the page shown after setting date and time.
- 14 Key for "ENTER" function to confirm entered data.
- 15 Key to recall previous page or to move selection cursor to the left.
- 16 Key to recall following page or to move selection cursor to the right.
- 17 Key to scroll page upwards or to move selection cursor upwards or to increase by one the value in the date and hour programming mode.
- 18 Key to scroll page downwards or to move selection cursor downwards or to decrease by one the value in the date and hour programming mode.
- 19 Red LED:
 - OFF mode - indicates that there is no signal on the display;
 - ON mode - indicates that there is a signal on the display.
- 20 Green LED:
 - BLINK mode - signals that the display does not interact with the PLC correctly;
 - ON mode - signals that the display interacts with the PLC correctly.



21 LED not enabled.

22 Green LED:

OFF mode - signals that the display is not active;

ON mode - signals that the display is active.

23 Green LED:

OFF mode - signals that no key is pressed;

ON mode - signals that any key is pressed.

Red LED:


status BLINK - indicates that the keyboard battery needs to be replaced (refer to Chapter 9 for instructions on how to replace it);

ON state - indicates serious problems in the keyboard.

24 Key not enabled.

25 Display.

CONTROLS FOR MANUAL OPERATION OF DRILLING MACHINE.



F21 Button STEP BY STEP OPERATION

Press F21 to activate Step by Step operation.

After pressing the button, the button led will light up. Press F21 many times to restore drilling machine working cycle. In case F22 Led lights up because of signal failure of microswitch sensors, press both F21 and F22 at the same time to restore drilling machine working cycle.

F22 SENSOR DISABLING BUTTON

When the button led lights up, the drilling machine sensors can be deactivated by pressing this button. (For example, if no bar is present, it is possible to press this button for step-by-step operation).

F23 SPINDLE RETURN BUTTON

By clicking this button when the spindle has not completely left the bar being machined, the spindle returns to the rest position. To carry out the above mentioned operation, the drilling machine working cycle must be over and the machine must be in wait position.

F24 NOT ENABLED BUTTON

F25 RESET 5" Button


To enable the reset button, manual operation mode must be selected.

Press this button during the Step-by-Step operation to stop the process.

Press this button to release buttons F26-F29, in case the corresponding LEDs are on.

F26 LEVER UP/DOWN BUTTON

Press this button to start movement, press again for lever return.


F27 Button CLAMPS OPEN/CLOSE

Press this button to start movement, press again for clamps return.

F28 Button BAR CLAMPING VICE OPEN/CLOSE


Press this button to start movement, press again for vice return.

F29 Button BAR STOP DISAPPEARS

Press this button to start movement, press again for bar stop return.

F30 Button CLAMPS MOVING FORWARD

Press this button to move the bar towards the drilling unit. Release the button and press it again for the return of the drilling unit.



Reset the drilling machine following these instructions:

- 1) The motor must be in wait position, otherwise press the RESET button to move it to wait position.
- 2) Keep pressing button F25 for 5 seconds: all the devices on the drilling machine will be released.
- 3) If a bar is clamped in the vice, the feeding unit will not open and the levers will not come down.
- 4) The motors will stop.
- 5) Press button F30 to move the bar backward after the motor has been driven backward and the bar sensing photocell has been released.
- 6) Press button F25 again to open the rollers and to bring the lever down to rest position.

S38 Button Drilling machine stop/Spindle return

- Press this button to stop drilling machine operation (alarm nr. 60 " Drilling machine cover" will be displayed). Keep pressing the button to let the spindle return to the rest position.
- This position allows spindle or tool maintenance. After maintenance has been completed, press button S32 to reset alarm nr. 60 and restore drilling machine to normal operation.
- If button S32 is pressed as soon as alarm nr. 60 " Drilling machine cover" is displayed the drilling machine is restored immediately to normal operation.

Press this button to stop drilling machine operation without stopping either bar feeder or lathe working cycles.

Press button S38 and then button F25 to restore the position of the devices of the drilling machine and restore operation.


6.2 MAGAZINE PUSH-BUTTON PANEL - CONTROL DESCRIPTION

SIR 52-MS 52 P

- 1 MAGAZINE CONTROL SELECTOR (2 positions)
POSITION 0: the magazine is pre-set for the manual bars loading;
POSITION 1: the magazine is pre-set for the bar feeder automatic function.
- 2 LUMINOUS PILOT LIGHT (orange)
When it blinks means that the magazine is carrying out the loading cycle.
- 3 EMERGENCY PUSH-BUTTON; it stops the feeder. The feeder can be restarted only after the push-button has been manually released.


SIR 52-MS 52 F

- 4 MAGAZINE COMMAND SWITCH (2-position)
POSITION 0: the magazine is pre-set for the manual lowering of belts in order to carry out the loading;
POSITION 1: the magazine is pre-set for the bar feeder automatic function.
- 5 MANUAL LOWERING OF THE MAGAZINE BELTS PUSH-BUTTON
BY PRESSING IT: the belts lower. By keeping the push-button pressed, the belts completely unwind until they disappear into their seats.
BY RELEASING IT: the belts stop.
- 6 EMERGENCY PUSH-BUTTON; it stops the feeder. The feeder can be restarted only after the push-button has been manually released.



6.3 LUMINOUS INDICATOR - SIGNAL DESCRIPTION

- A RED LIGHT;
Steady light; the bar feeder is in manual mode.
- B GREEN LIGHT;
Steady light; the bar feeder is in automatic mode.
Intermittent light; when manual mode is selected, the light indicates that the valve EV317 is closed to allow quick oil warm up (see paragraph 6.5.1).
- C BLUE LIGHT;
Intermittent light; indicates bar change.
- D ORANGE LIGHT;
Intermittent light; the oil filter is dirty and should be cleaned or replaced (see Warning 14 on the display).
- D ORANGE LIGHT;
1) Intermittent light; the oil filter is dirty and should be cleaned or replaced (see Warning 14 on the display).
2) If the drilling machine is working, the light indicates that the spindle tool is subject to wear and should be soon replaced (see Warning 65 on the display).
3) If the magazine is empty, the intermittent light is on and the alarm 11 "NO BAR AVAILABLE" is displayed (see Warning 17).



41_060_0



INFORMATION:

To turn off the light, even when the alarm is active, press RESET (S11.7) .

6.4 STARTING THE BAR FEEDER

There are different procedures to start the bar feeder, depending on the hydraulic oil temperature:

- cold start (paragraph 6.5.1);
- hot start (paragraph 6.5.2).


6.4.1 Cold start

Cold start occurs according to two different procedures.


ADVANCED AUTOMATIC START

Program the advanced automatic start following the procedures described in the "Push-button panel operation and instruction manual", paragraph "Operator's parameters - description and entering".

MANUAL START

- Make sure that all guards are closed and the emergency push-buttons are not pressed.
- Turn the main electric switch to "I".
- Start the lathe.
- Press push-button  to start the bar feeder, keeping it pressed for 15 seconds, until the green light of the luminous indicator temporarily switches on.
This procedure allows valve (EV317) to close; it will remain closed for 45 minutes, thus allowing a faster hydraulic oil heating.

6.4.2 Hot start

- Make sure that all guards are closed and the emergency push-buttons are not pressed.
- Turn the main electric switch to "I".
- Start the lathe.
- Press push-button  to start the bar feeder.

6.5 BARS TO BE MACHINED - CHARACTERISTICS AND PREPARATION



CAUTION:

do not feed bars having different sizes than the manufacturer's prescribed sizes.

Table 1. Maximum bar length

Models	Version	Max. length (mm)	Min. length (mm) (*)
SIR 52-MS52 P SIR 52-MS52 F	33	3300	2500
	38	3800	3000
	43	4300	3000



INFORMATION:

() bars are to be loaded in the middle of the bundle magazine.*

()To load short bars in the magazine bundle, please refer to IEMCA sales and customer services in order to verify the possibility of installing a short bar loading kit.*




INFORMATION:

Bar must not present a straightness defect above 0.5 per 1000.


Please find herewith some advice to optimise the bar feeder performances. Usually barstocks do not need any preliminary operations to be carried out on ends, nevertheless to obtain the best results when loading them, it is advisable to chamfer them.

SOLID BARS


Check that there is not too much rag on bar head, which might hinder insertion in the lathe collet. Check that there is not too much rag on bar rear end, which might hinder insertion in the bar-pusher collet. In any case, to improve operation during this phase, we advise to chamfer the bar as shown in the figure.



If bars with front remnant ejection have to be machined, we advise to chamfer the bar rear end as shown in the figure.




If bars have to be machined having a diameter equal to or only slightly smaller than the bar-pusher diameter, bar rear ends should be machine-turned; diameter "D" should be suitable for the collet size installed in the bar-pusher.



PIPES

If pipes have to be machined, their rear ends should be chamfered as shown in the figure.




6.5.1 BAR STRAIGHTNESS - Measurement

The bar vibrations are partially caused by the condition of the bar itself: in case the bar is not perfectly straight, this can cause vibrations.

Round bars

As stated also in the UNI-10233/2 regulation, the bar straightness can be measured by positioning the bar on two V-supports and control its straightness. In that case, the measurement can be carried out as shown in the figure.

It is necessary to rotate the bar on itself and measure the three indicated sections. In this case the S-max value (difference between maximum and minimum reading on the comparator) should be interpreted as follows:



S max	Quality
< 0,25 mm	Good
0,25 < S max < 0,5 mm	Mediocre
> 0,5 mm	Problematic

In order to obtain a reliable value it is necessary to repeat measurements on the whole bar length by positioning it on a series of supports at a distance of 500 mm from each other and comparing the different values between prisms.



INFORMATION:

Obviously, bar straightness is proportional to the rigidity of the material and to the number of revolutions (RPM) the lathe is operated at. highly The lack of bar straightness highly influences the maximum number of revolutions reachable: the bigger the diameter the greater the influence. The data concerning bar straightness do not absolutely refer to local inflection and/or deformation that the bar shall not absolutely show. Instead, they refer to the bar uniform curvature.



INFORMATION:

For efficient operation of the feeder the use of rolled bar stock is not recommended.


Hexagonal, square and section bars

For non-round bars, insert some bushings on the bar to be controlled.

Position 2 bushings on the 2 V-supports.

In that case, the measurement can be carried out as shown in the figure.

Rotate the bar on itself and carry out the measurement on a bushing external to the two V-supports.



INFORMATION:

The use of polygonal bars (hexagonal bars, square bars, etc.) is allowed but you should keep in mind that this will lead to:

-excessive wear and tear on the guide channel (wear and tear due to the use of round bars is reasonable).

-bar rotation speed reduction (in comparison with round bars).


Excessive wear and tear on the guide channel is due to the shape of bars as well as to material straightness and stiffness.

6.6 BARSTOCKS - LOADING

In accordance with the two different models, loading occurs as follows.

SIR 52- MS 52 P

1 Start the bar feeder

2 The selector  must be positioned on 0. The

luminous pilot light  emits a persistent light, wait until it becomes flickering.

3 Open the case and manually load the magazine plane with bars up to its filling (A).



DANGER - WARNING:


Do not manually lift loads exceeding 15 kg.

4 Close the case.

5 Bars are drawn from the feed chain.

6 When the luminous pilot light emits a flickering light again, operations 3,4 and 5 have to be repeated.

7 Carry out the above mentioned operations up to the complete filling both of the magazine and feed chain (B).


8 When the selector  is positioned on 1, the luminous pilot light is off; hence, the magazine is ready to feed the drum.





During the setting up operations of drum or other device, the selector must be



positioned on 0; should the feeding chain be unloaded, it stops after approx. 35 sec.



SIR 52- MS 52 F

- 1 Start the bar feeder.
- 2 Position the selector  on 0 .
- 3 Press the  push-button to lower belts completely.
- 4 Feed the bars using a bridge crane or a lifting carriage.



INFORMATION

Bars are to be loaded in the middle of the bundle magazine.




CAUTION:


Do not load bars having sizes different from those suggested by the manufacturer.



DANGER - WARNING:

Make sure the lifting device has a suitable capacity.



- 5 Position the  selector on 1; the magazine is ready to feed the drum.














6.7 PROGRAMMING - PARAMETERS ENTRY










The entering of parameters is necessary to program the automatic cycle of the bar feeder, according to the working requirements and to the machine type.
For more detailed instructions, see the "Push-button panel operation and instruction manual".

6.8 WORKING DIAMETER CHANGE - OPERATIONS SEQUENCE





















The operations for the machining diameter change have to be done on the basis of the previous machining and in relation to the following machining.
See "COMPARATIVE TABLE OF THE WORKING DIAMETERS" (paragraph 5.3.).
If the stock guide tube diameter has to be replaced, you need to follow the procedure explained in paragraph 6.8.1; otherwise, follow the procedure explained in paragraph 6.8.2.
The operations for the machining diameter change can also be done following quick procedures explained in paragraphs 6.8.3 and 6.8.4.


6.8.1 Changing the machining diameter without the stock guide tube diameter change

- 1 When all bars in the drum are over, stop the lathe with its collet open (zero point).
- 2 Press key  and press key  to make the bar pusher move backwards up to backward limit stop (S 1011 active).
- 3 Disable the automatic mode of the truck feed.
- 4 Give the lathe the order to make one spindle station rotate and repeat the operations until all spindles are released from residual bars and until all bar pushers are brought to the backward limit stop.
- 5 Stop the bar feeder.
- 6 Open the rear door.
- 7 Remove the coupling screws between the bell of the lathe and the bell of the bar feeder. Release the drum locking lever pressing it downwards and manually pull the drum up to the limit stop.
- 8 Extract sleeves (paragraph 5.9.).
- 9 Disassemble the spindle collets and reassemble the new collets adequate to the new bar profile.
- 10 Assemble the sleeves with the possible reducers of the diameter adequate to the guide stock tube.
- 11 Bring the drum to the working position again, pushing carefully and checking that no obstacle occurs.
- 12 Lock the drum with the proper lever and close the rear door. Reassemble the coupling screws between the bell of the lathe and the bell of the bar feeder.
- 13 Bring magazine control selector switch S 106 to position "0".
- 14 Start the bar feeder and press key .
- 15 Press key  to make the bar feeder move foreword of 200/300 mm.
- 16 Press key  to make the clamp arm turn towards the drum.
- 17 Press key  to bring the bar pusher to the limit stop.
- 18 Press key  to close the truck-bar pusher locking device.
- 19 Press key  to open the guides.
- 20 Press key  to make the clamp arm rotate outside the drum.
- 21 Press key  to close clamps.
- 22 Press key  to extract the remnant.
- 23 Press key  to open the clamps; the remnant falls down.
- 24 Press key  to open the truck-bar pusher locking device.
- 25 Manually open the side guard in the clamp area.
- 26 Remove the bar pusher.
- 27 Adjust the guide stock tube with the desired diameter (paragraph 5.3.).
- 28 Prepare the bar pusher adequate to the guide stock tube and equipped with the bar remnant.
- 29 Position the bar pusher in the clamp arm housing.
- 30 Close the side guard.

- 31 Press key  to close the truck-bar pusher locking device; LED of sensor S4 has to be on. Otherwise, open locking device again, longitudinally move the bar pusher of some millimetres and close locking device again.
- 32 Press key  to open the guides.
- 33 Press key  to rotate the clamp arm towards the drum.
- 34 Press key  to close the guides.
- 35 Press key  to open the truck-bar pusher locking device.
- 36 Press key  to bring the remnant into the lathe collet.
- 37 Press key  to make the clamp arm rotate outside the drum.
- 38 Give the lathe the order to make one spindle station rotate and stop it at zero point. Press key  and repeat from step 15 to step 37.
- 39 Repeat step 38 until all bar pushers are replaced.
- 40 Remove all bars left from the magazine.
- 41 Prepare the new bars (paragraph 6.5.).
- 42 Load bars (paragraph 6.6.).
- 43 Adjust magazine (paragraph 5.1. and 5.2.).
- 44 Bring magazine control selector switch S 106 to position "1".
- 45 Press key .

6.8.2 Change of the working diameter without changing the guide tube diameter










- 1 When all bars in the drum are over, stop the lathe with its collet open (zero point).
- 2 Disable the truck feed in automatic mode.
- 3 Press key  and press key  to make the bar pusher move backwards up to the backward limit stop (S 1011 active).
- 4 Bring magazine control selector switch S 106 to position "0".
- 5 Press key  to make the bar feeder move foreword of 200/300 mm.
- 6 Press key  to make the clamp arm turn towards the drum.
- 7 Press key  to bring the bar pusher to the limit stop.
- 8 Press key  to close the truck-bar pusher locking device.
- 9 Press key  to open the guides.
- 10 Press key  to make the clamp arm rotate outside the drum.
- 11 Press key  to close the clamps.
- 12 Press key  to extract the remnant.
- 13 Press key  to open the clamps; the remnant falls down.
- 14 Press key  to open the truck-bar pusher locking device.
- 15 Manually open the side guard in the clamp area.
- 16 Remove the bar pusher.
- 17 Disassemble the collet and assemble the new collet equipped with the bar remnant.
- 18 Position the bar pusher in the clamp arm housing.
- 19 Close the side guard.
- 20 Press key  to close the truck-bar pusher locking device; LED of sensor S4 has to be on. Otherwise, open locking device again, longitudinally move the bar pusher of some millimetres and close locking device again.
- 21 Press key  to open the guides.
- 22 Press key  to rotate the clamp arm towards the drum.
- 23 Press key  to close the guides.
- 24 Press key  to open the truck-bar pusher locking device.
- 25 Press key  to bring the remnant into the lathe collet.
- 26 Press key  to make the clamp arm rotate outside the drum.
- 27 Give the lathe the order to make one spindle station rotate and stop it at zero point. Press key  and repeat from step 5 to step 26.

- 28 Repeat step 27 until all bar pushers are replaced.
- 29 Remove all bars left from the magazine.
- 30 Prepare the new bars (paragraph 6.5.).
- 31 Load bars (paragraph 6.6.).
- 32 Adjust magazine (paragraph 5.1. and 5.2.).
- 33 Bring magazine control selector switch S 106 to position "1".
- 34 Press key .

6.8.3 Changing the machining diameter without the stock guide tube diameter change - Quick procedure


DANGER - WARNING:

the following procedure has to be carried out by the responsible skilled technician, who also owns the key of the selector switch allowing this operation to be done.

- 1 When all bars in the drum are over, stop the lathe with its collet open (zero point).
- 2 Disable the truck feed in automatic mode.
- 3 Press key  and press key  to make the bar pusher move backwards up to the backward limit stop (S 1011 active).
- 4 Give the lathe the order to make one spindle station rotate and repeat the operations until all spindles are released from residual bars and until all bar pushers are brought to the backward limit stop.
- 5 Stop the bar feeder.
- 6 Open the rear door.
- 7 Remove the coupling screws between the bell of the lathe and the bell of the bar feeder. Release the drum locking lever pressing it downwards and manually pull the drum up to the limit stop.
- 8 Extract sleeves (paragraph 5.9.).
- 9 Disassemble the spindle collets and reassemble the new collets adequate to the new bar profile.
- 10 Assemble the sleeves with the possible reducers having the diameter adequate to the guide stock tube.
- 11 Bring the drum to the working position again, pushing carefully and checking that no obstacle occurs.
- 12 Lock the drum with the proper lever and close the rear door. Reassemble the coupling screws between the bell of the lathe and the bell of the bar feeder.
- 13 Bring magazine control selector switch S 106 to position "0".
- 14 Start the bar feeder and press key .
- 15 Bring selector switch  to position  and open the guard.
- 16 Hold the bar pusher with your hand, press key  and remove the bar pusher.
- 17 Adjust the guide stock tube with the desired diameter (paragraph 5.3.).
- 18 Prepare the bar pusher adequate to the stock guide tube and equipped with the bar remnant.
- 19 Position the bar pusher in the stock guide tube taking care to introduce the flag into the feeding truck and press key .
- 20 Press key  to bring the remnant into the lathe collet.
- 21 Close guard and bring selector switch  to position .



- 22 Give the lathe the order to make one spindle station rotate and stop it at zero point. Press key **F13** **MAN.** and repeat from step 15 to step 21.
- 23 Repeat step 22 until all bar pushers are replaced.
- 24 Remove all bars left from the magazine.
- 25 Prepare the new bars (paragraph 6.5.).
- 26 Load bars (paragraph 6.6.).
- 27 Adjust magazine (paragraph 5.1. and 5.2.).
- 28 Bring magazine control selector switch S 106 to position "1".
- 29 Press key **F14** **AUT.**.







6.8.4 Changing the machining diameter without the stock guide tube diameter change








DANGER - WARNING:

the following procedure has to be carried out by the responsible skilled technician, who also owns the key of the selector switch allowing this operation to be done.

- 1 When all bars in the drum are over, stop the lathe with its collet open (zero point).
- 2 Disable the truck feed in automatic mode.
- 3 Press key  and press key  to make the bar pusher move backwards up to the backward limit stop (S 1011 active).
- 4 Bring magazine control selector switch S 106 to position "0"


- 5 Bring selector switch  to position  and open the guard.
- 6 Hold the bar pusher with your hand, press key  and remove the bar pusher.
- 7 Disassemble the collet and assemble the new collet equipped with the bar remnant.
- 8 Position the bar pusher in the stock guide tube taking care to introduce the flag into the feeding truck and press key .
- 9 Press key  to bring the remnant into the lathe collet.


- 10 Close guard and bring selector switch  to position .
- 11 Give the lathe the order to make one spindle station rotate and stop it at zero point. Press key  and repeat from step 5 to step 10.
- 12 Repeat step 11 until all bar pushers are replaced.
- 13 Remove all bars left from the magazine.
- 14 Prepare the new bars (paragraph 6.5.)
- 15 Load bars (paragraph 6.6.).
- 16 Adjust magazine (paragraph 5.1. and 5.2.).
- 17 Bring magazine control selector switch S 106 to position "1".
- 18 Press key .

6.9 BAR FEEDER STOP

**CAUTION:**


Do not stop the bar feeder through the emergency push-button unless necessary.

- Finish the operations provided for by the working program.
- Stop bar feeder from the lathe.
- Stop the lathe.
- Position the main switch on "0".





6.10 EPROM LOADING PROCEDURE

In case of programme deletion or eeprom replacement, the programme needs to be loaded again by adopting the following procedure.

- 1) CPU selector must be set to RUN.
- 2) Turn the voltage to the PLC off and set the selector to STOP.
- 3) Remove the EPROM.
- 4) Turn the voltage on and wait until the LEDs are on (some may be off, but no LED must be blinking).
- 5) Turn the selector to MRES, wait until the LED STOP slowly blinks twice.
- 6) Turn the selector to STOP, turn it immediately (within 3 secs.) to MRES and release it at once.
- 7) The STOP LED is now blinking faster (2 Hz = MEMORY RESET).
- 8) Wait until the STOP LED light is steady.
- 9) Turn the voltage to the PLC off.
- 10) Insert a new EPROM.
- 11) Turn the voltage on.
- 12) Turn the selector to RUN when the lights are steady (some may be off by no light must be blinking).
- 13) Now turn voltage to INDEX LATHES(voltage to the bar feeder will be automatically turned off) and turn it on after 10 secs. (This step should allow lathe-bar feeder software alignment).



INDEX

7.1	MAINTENANCE - GENERAL INSTRUCTIONS 	2
7.2	MAINTENANCE - SCHEDULED MAINTENANCE TABLE 	3
7.2.1	SIR52-MS52 F Bar stop clutch - Adjustment	4
7.2.2	SIR52-MS52 F translation belts - Tightening	4
7.2.3	SIR52-MS52 F Pins bushings - Lubrication	5
7.2.4	SIR52-MS52 P torque limiter - Adjustment	6
7.2.5	SIR52-MS52 P bar lifting chain - Tightening	7
7.2.6	SIR52-MS52 P bar translation chain - Tightening	7
7.2.7	SIR52-MS52 P motor chain - Tightening	8
7.2.8	Chain feeding belt - Tightening	8
7.2.9	Feeding drum - Bearings end play adjustment	9
7.2.10	Loading levers - Adjustment	9
7.2.11	Clamps device and bar-pusher locking - Alignment check	10
7.2.12	Hydraulic joint - Check	10
7.2.13	Clamps - Sharpening and adjustment	11
7.2.14	Lubricating oil - Level check	11
7.2.15	Lubricating oil - Filters cleaning	12
7.2.16	Lubricating oil - Change	14
7.2.17	Hydraulic oil - Level check	14
7.2.18	Hydraulic oil - Filter maintenance	15
7.2.19	Hydraulic oil - Change	16
7.2.20	Air filter unit - Check	17
7.3	LUBRICATING/HYDRAULIC OIL - COMPARATIVE TABLE 	18
7.4	PREPARING THE BAR FEEDER FOR MAINTENANCE TO THE LATHE 	19

7.1 MAINTENANCE - GENERAL INSTRUCTIONS

Regular cleaning and maintenance are critical to ensure smooth operation and longer machine service life.

It is recommended to regularly and effectively clean the machine, its accessories and work area, which also increases operator's safety.

Do not use petrol or other detergents which might spoil painting, transparent parts, cable sheaths, etc.

To protect the bar feeder when you expect not to use it for long periods of time, disconnect it from mains voltage and from compressed air supply and cover it with a suitable protective sheet.



DANGER - WARNING:

Oxidation may cause damages either to the metallic parts or to electric equipment.

Any protective cover must not be completely sealed at the base and must be provided with air inlet holes, to prevent the humidity inside the cover from condensing due to an air circulation deficiency.

Said condensation might oxidise the metallic parts and damage the electric equipment.

7.2 MAINTENANCE - SCHEDULED MAINTENANCE TABLE 

Table 1. Maintenance - scheduled maintenance.


BAR FEEDER MODEL	BAR FEEDER SECTION	OPERATIONS TO BE CARRIED OUT	HOURS FREQUENCY			
			50	200	1250	2500
SIR52-MS52 F	Bundle	Check the lifting belts wear		•		
		Adjust the bar stop clutch.			•	
	Bars translation	Tighten the translation belts.			•	
		Check the translation belts wear.				• (*)
		Lubricate pins bushings.			•	
SIR52-MS52 P	Bars lifting and translation	Check and adjust the torque limiter whenever necessary.				•
		Check and tighten the bar lifting chain whenever necessary.		•		
		Check and tighten the bar translation chain whenever necessary.			•	
		Check and tighten the motor chain whenever necessary.			•	
SIR52-MS52 P SIR52-MS52 F	Bar loading	Check and whenever necessary replace the bar loading levers rollers.				•
	Carriage feeding	Tighten the belt.		•		
	Guides	Check and replace sprockets whenever necessary.			•	
		Verificare la scorrevolezza tra i rocchetti e le cremagliere		•		
	Clamps device	Check and sharpen clamps whenever necessary.			•	
	Lubricating system	Check the oil level.	•			
		Clean the oil filter.			•	
		Check the delivery pipes.				•
		Change the hydraulic oil.		once a year		
	Hydraulic system	Check the oil level.		•		
		Clean the oil filter.			•	
		Check the oil pipes.				•
		Change the hydraulic oil.		once a year		
Keyboard	Replace the battery		once a year			
PLC	Replace the battery		once a year			

(*) Should the standard belts wear excessively due to oil, chipping or sharp bars, it is advisable to assemble polyurethane belts supplied upon request.

7.2.1 SIR52-MS52 F Bar stop clutch - Adjustment


Should the bar stop clutch fail to work properly, adjust it as follows.

- | | |
|--------------|--|
| Left clutch | Tighten ring nut (A) tightening it by means of the counternut . |
| Right clutch | Loosen the three nuts (B).
Equally tighten the three screws (C) so that disk (D) may progress in parallel with the counter disk.
Tighten the three nuts (B). |




7.2.2 SIR52-MS52 F translation belts - Tightening

- Loosen screw (A).
- Tighten the belt by manually pressing the pulley.
- Tighten screw (A).
- Repeat the operation to tighten the other belts whenever necessary.



7.2.3 SIR52-MS52 F Pins bushings - Lubrication

Lubricate the pins bushings (see areas displayed in bold type).




7.2.4 SIR52-MS52 P torque limiter - Adjustment

The bar lifting device is equipped with a torque limiter which actuates should the device fail to work properly.


To adjust it:

- The magazine must be completely loaded (§. 6.7.) with barstock of the max. diameter.
- Loosen the nuts of sensor (A) in order to remove it from disk (B).
- Disassemble the disk by loosening screw (C).
- Loosen screw (D).
- Completely loosen ring nut (E). When the bar feeder is started, the torque limiter slides.
- Stop the bar feeder and tighten ring nut (E) step by step, making attempts up to the bar lifting device is restored.
- Tighten screw (D).
- Reassemble the disk and the sensor.




7.2.5 SIR52-MS52 P bar lifting chain - Tightening

- Loosen screws (A) and nut (B).
- Tighten screw (C).
- Tighten screws (A) and nut (B).
- Whenever necessary, repeat the operation to tighten the other chains.




7.2.6 SIR52-MS52 P bar translation chain - Tightening

- Loosen ring nut (A).
- Turn the pinion eccentric pin (B).
- Tighten ring nut (A).
- Whenever necessary, repeat the operation in order to tighten all other chains.




7.2.7 SIR52-MS52 P motor chain - Tightening

- Loosen screw (A).
- Tighten the chain by pressing manually pinion (B).
- Tighten screw (A).



7.2.8 Chain feeding belt - Tightening

- Loosen the nut (A).
- Screw the screw (B) to tighten the chain using a torque wrench; tighten to $C = 5 \text{ N/m}$ (about 0,5 Kg/m).
- Tighten nut (A.)
- Whenever necessary, repeat the operation to tighten the other chains.




7.2.9 Feeding drum - Bearings end play adjustment

The feeding drum rotates on bearings (A) and (B) (fig. 9) placed both in the front and rear area of the bar feeder.

Adjust the end play operating bearings (B), which are supplied with eccentric pin.


End play must be of $0.15 \div 0.25$ mm.

Bearings (A) are not equipped with eccentric pin.



7.2.10 Loading levers - Adjustment

BAR FEEDER LEVERS IN PICK-UP POSITION:
Adjust the levers (B) as shown in picture "52006100115" and make sure the capacitive sensor LED lights up.



7.2.11 Clamps device and bar-pusher locking - Alignment check


Check the clamps device (A) axis is aligned with the guide tube axis.

Keep to the following procedure: move the clamp device to the "bar insertion into collet" position

and close the sprockets by pressing key  F3.


Sprockets must close without interfering with the bar pusher inserted into the clamp device.

In case of misalignment, please apply to IEMCA technical assistance department.



7.2.12 Hydraulic joint - Check

In case of troubles to the rotating joint (A) (fig. 12) apply to IEMCA technical assistance department.



7.2.13 Clamps - Sharpening and adjustment

Sharpening

- Untighten screws (A).
- Remove and sharpen clamps according to the sharp edges.
- Reassemble clamps.
- Tighten screws (A).



INFORMATION


If only a single clamp is sharpened, check and centre the other clamps whenever necessary.

Centring adjustment

Adjust the lower clamp position so that, once the clamps are closed, the bar (D) axis is aligned with the bar-pusher axis (E).


To adjust it:

- Loosen screw (A).
- Loosen nut (B).
- Tighten or untighten screw (C).
- Tighten nut (B).
- Tighten screw (A).



7.2.14 Lubricating oil - Level check

- The oil level must be between the minimum level MIN. and maximum level MAX.
- To top up oil, remove cover (A) and fill with lubricating oil type: class (C) CKB 100.






7.2.15 Lubricating oil - Filters cleaning


Filter under the box

- Remove box (A) and cover (B).
- Remove frame (C).
- Remove filter (D) and clean it by means of compressed air.


Suction filter



- Remove the electrical pump (E) with the screws (F).



- Remove the filter (G) with the screws (H).
- Clean the filter (G) with the compressed air.



7.2.16 Lubricating oil - Change

Replacement can be carried out by using an auxiliary pump or by means of the drain plug.

Replacement with an auxiliary pump

- Remove box (A) and cover (B).
- Remove frame (C).
- Remove filter (D).
- Empty the tank by using an auxiliary pump.
- Clean the tank bottom.
- Fill it up with lubricating oil: type class (C) CKB 100. Quantity: 250 l.

Replacement by means of the drain plug

- Disconnect the control unit, see paragraph 4.5.1.
- Uplift the control unit (see paragraph 4.2.) and place it on two stands.
- Unscrew the drain plug and let the oil be drained.
- Remove box (A) and cover (B) (see paragraph 7.2.15).
- Remove frame (C).
- Remove filter (D).
- Clean the tank bottom.
- Fill it up with lubricating oil: type class (C) CKB 100. Quantity: 250 l.



7.2.17 Hydraulic oil - Level check

- See enclosed documentation: "Hydraulic System".

7.2.18 Hydraulic oil - Filter maintenance

- See enclosed documentation: "Hydraulic System".

7.2.19 Hydraulic oil - Change

- See enclosed documentation: "Hydraulic System".


7.2.20 Air filter unit - Check

FILTER A

- Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C). Make sure that cup (B) is not full of condensate. If need be, bleed the condensate by valve (C).

PRESSURE SWITCH

- The lubricator is equipped with a control pressure switch, set to a pressure of 4.5 bars.
- To adjust the pressure switch, proceed as follows:
 - remove the pressure gauge protecting glass;
 - turn the adjusting screw (G) anticlockwise (+) to increase pressure or clockwise (-) to lower it;
 - after this operation, replace the pressure gauge protecting glass.



CAUTION:

should the pressure switch needle point a Pressure=0, do not absolutely turn the adjusting screw (H) clockwise (-), for this will cause pressure switch breakage.

7.3 LUBRICATING/HYDRAULIC OIL - COMPARATIVE TABLE 

Table 2. Lubricating oil


Table 3. Hydraulic oil

ISO/UNI DESIGNATION	BRAND	DENOMINATION	ISO/UNI DESIGNATION	BRAND	DENOMINATION
CLASS C CKB 100	Agip	Acer 100	CLASS C HG 32	Agip	Exidia 32
	Api	Api Cis 100		Api	Api Cis EP-32
	BP	Energol CS 100		BP	Energol GHL 32
	Castrol	Magna 100		Castrol	Magna GC 32
	Chevron	Circulating Oil 100		Chevron	HWS 280 32 cSt
	Elf	Movixa 100		Elf	Hygliss 32
	Esso	Nuto 100		Esso	Febis K 32
	Fina	Solna 100		Fina	Hydran 32
	IP	IP Hermea 100		IP	Bantia HG 32
	Klüber	Crucolan 100		Klüber	Lamora 32
	Mobil	Vectra Oil Heavy		Mobil	Mobil Vacuoline 1405
	Olio FIAT	Daphne LPN 100		Olio FIAT	Daphne Husoli 32 HG/I
	Roloil	Arm V 100		Roloil	LI-EP 32
	Shell	Vitrea 100 Tellus C 100		Shell	Tonna TX 32
	Tamoil	Industrial Oil 100		Tamoil	Tamway oil 32
	Texaco	Omnis 100		Total	Drosera MS 32
	Total	Cortis 100 Azolla ZS 100		Texaco	Way lubricant 32
Q8	Verdi 100				

7.4 PREPARING THE BAR FEEDER FOR MAINTENANCE TO THE LATHE

For easy maintenance of the lathe, it is possible to remove some parts of the bar feeder and to use the device to slide the feeding drum.

Removing the middle leg (A) - SIR 52 F (fig. 23);
See paragraph 4.4.5.



CAUTION:

The central foot removal and following installation must be done when the magazine is empty.

Removing the hydraulic drive unit (B) (fig. 23); see paragraph 4.5.


How to use the Sliding Feeding Drum




CAUTION:

Function to be undertaken with great care, making sure that the bar feeder is stable.


Open the rear guard, lower lever (C) (fig. 24) and move the feeding drum backwards.





The (D) stroke is standard, stroke (E) is oversized and must be used in those installations which require a larger working area (fig. 25).





INDEX


8.1 GENERAL PROBLEMS 2

8.2 BAR MAGAZINE - FAILURES 3

8.3 DEVICE INTRODUCING BARS INTO GUIDES - PROBLEMS 4

8.4 CLAMPS DEVICE - PROBLEMS 5

8.5 GUIDES - PROBLEMS 5

8.6 HYDRAULIC SYSTEM - PROBLEMS 6

8.7 OPERATOR PANEL PARAMETER LIST7

8.1 GENERAL PROBLEMS 

INCONVENIENTS	CAUSE	REMEDY
BAR FEEDER DOES NOT START	Open cases.	Close the cases
	The feeding drum is out of position.	Bring the feeding drum to position and reassemble coupling screws between the bell of the lathe and the bell of the bar feeder.
	Air missing.	Check the air system.
	Emergency devices activated.	Disable the emergency devices.
	Motors thermal switches blown.	Reset the overload relay by means of the relevant push-buttons.
THE BAR FEEDER DOES NOT WORK IN THE AUTOMATIC MODE	Levers are in a loading phase.	Read for any possible defects on the DISPLAY and provide the required conditions for the bar feeder to be started automatically.
	Clamp arm on the guides.	
	Clamps are closed.	
	Guides are open.	

8.2 BAR MAGAZINE - FAILURES 

INCONVENIENTS	CAUSE	REMEDY
SIR52-MS52P THE BARS ARE NOT UPLIFTED BY THE CHAINS	The torque limiter slides.	Calibrate the torque limiter.
SIR52-MS52F BAR LIFTING IS OUT OF BALANCE	One of the belts is loosened or torn.	Replace the belt.
BARS ARE NOT SELECTED	The control cylinders do not work.	Check both the cylinders operation and the pneumatic system.
	The bar detection sensors are not excited.	Make sure that the bar detection signalling levers are exciting the sensors.
	Failure of the selector lifted cam.	Replace the cam.

INCONVENIENTES	CAUSAS	SOLUÇÕES
SIR52-MS52P As barras não são levantadas pelas correntes	O limitador de torque desliza	Ajuste o limitador de torque
SIR52-MS52F A elevação acontece de forma desequilibrada	Uma correia está frouxa ou rasgada	Substitua a correia
As barras não são seleccionadas	Os cilindros de comando não funcionam	Verifique a funcionalidade dos cilindros e do sistema pneumático
	Os sensores de presença da barra não são acionados	Certifique-se de que as alavancas de sinalização de presença da barra acionem o sensor
	Ruptura do excêntrico de elevação do seleccionador	Substitua o excêntrico

8.3 DEVICE INTRODUCING BARS INTO GUIDES - PROBLEMS

ERROR	CAUSE	CURE
BAR DROPS OUTSIDE THE LOWERING ROLLERS	Lever stop in a lower position because they are misaligned	Adjust the loading levers
	Torn rollers	Replace the control levers rollers
ARMS DO NOT LOWER	The cylinder does not work	Check the operation of the levers control cylinder.
	Lever are jammed in a high position.	Check there are no crosswise bars or folded levers
ARMS DO NOT INTRODUCE BARS	The lateral cylinders do not work.	Check the operation of the bar introducing cylinder.
	Lever are misaligned and interfere with the guiding sprockets.	Position the levers in the loading cycle.
CLOSED SPROCKETS PREVENTING THE BAR FEEDING	Jammed sprockets	Clean and check sprockets, making s

8.4 CLAMPS DEVICE - PROBLEMS 

INCONVENIENTS	CAUSE	REMEDY
CLAMPS DO NOT TIGHTEN THE BAR	The cylinder does not work.	Check the hydraulic system operation.
	Failure of a tightening clamp.	Replace the broken clamp.
	Low pressure	Adjust pressure, see paragraph 5.7.2.
THE BAR-PUSHER IS NOT HELD	The holding pneumatic cylinder is jammed.	Release the cylinder as well as the holding levers.
	Failure of the holding rollers.	Replace the broken roller.
BAR-PUSHER AND CARRIAGE DO NOT ENTER THE GUIDE	The clamps unit is misaligned as to the guide axis.	Align the unit (apply to IEMCA technical assistance department).

8.5 GUIDES - PROBLEMS 

ERROR	CAUSE	CURE
Sprockets jam	Racks and sprocket supports are dirty.	Clean the concerned parts.
Sprockets close in the wrong guide	Chips or dirtiness in the spring and in the sprockets control rack.	Clean the concerned parts.
Sprocket open during the bar rotation	Failure of the locking spring.	Replace the spring.
		Make sure the sprockets closing phase occurs correctly.
Bar vibrates excessively thus causing side skids	Sprockets are out of phase	Clean the sprockets closing unit and make sure the closing phase occurs correctly.
	Sprockets are not closed.	

8.6 HYDRAULIC SYSTEM - PROBLEMS

ERROR	CAUSE	CURE
NOISY PUMPS	Insufficient or non-existent pump suction.	Clean the suction filter; make sure no throttling or damage occurred in the suction line.
	Pump sucks air from the suction line.	Tighten the suction line unions.
	Pump sucks air because the tank oil level is too low.	Top up the oil
	The working pressure is too high.	Decrease the working pressure
	Wrong type of oil.	Change it with a recommended oil
	The pump is worn out.	Repair or replace the pump
SYSTEM PRESSURE MISSING	Oil level is too low	Top up oil
	Insufficient or non-existent pump suction.	Clean the suction filter; make sure no throttling or damage occurred in the suction line.
	Pump sucks air from the suction line	Tighten the suction line unions
	Wrong type of oil	Change it with a recommended oil
	Failure of the pump.	Repair the pump
AIR IN THE SYSTEM AND/OR FOAM IN THE OIL	Oil level is too low	Top up oil.
	Leakage in the suction line.	Tighten the unions.
	Excessive resistance in the suction line.	Clean the filter
	Wrong type of oil.	Change it with a recommended oil

8.7 OPERATOR PANEL PARAMETER LIST

Message Nr.	Message description	Message type
1	AUTOMATIC CYCLE	SIGNAL
2	2 BAR FEEDER NOT RUNNING	SIGNAL
3	MANUAL CYCLE	SIGNAL
4	4 BAR LOAD DOOR OPEN	ERROR
5	5 AXIAL DISPLACEMENT NOT BLOCKED	ERROR
6	6 AIR NOT PRESENT	ERROR
7	7 BAR PUSHER POSITION WRONG	SIGNAL
8	8 CLAMP ARM	SIGNAL
9	9 BAR PUSHER BLOCKED	SIGNAL
10	10 BAR LOADING LEVER NOT IN POSITION	SIGNAL
11	11 NOT SYNCHRONIZED CLAMPS	SIGNAL
12	12 CLAMPS CLOSED	SIGNAL
13	13 GUIDE CHANNELS OPEN	SIGNAL
14	14 CHANGE DIRTY OIL FILTER	WARNING
15	15 CHANGE CLOGGED OIL FILTER	ERROR
16	16 GUIDE CHANNEL ADJ. POSITION SENSOR	SIGNAL
17	17 NO BAR LEFT	WARNING
18	18 ENCODER ERROR	FATAL ERROR
19	19 SENSOR FOR PART. OPEN GUIDE CHANNEL	ERROR
20	20 SENSOR FOR OPEN GUIDE CHANNEL	ERROR
21	21 NO REMNANT	FATAL ERROR
22	22 NO REMNANT EJECTION	FATAL ERROR
23	23 BAR PUSHER BLOCKED	ERROR
24	24 REMNANT ...	SIGNAL
25	25 MAGAZINE FAILURE	ERROR
26	26 BAR INTR. INTO THE COLLET WRONG	FATAL ERROR
27	27 ENCODER POSITION	ERROR
















28	28 AUT. IMPULSE PHASE	SIGNAL
29	29 FLAG NOT SYNCHRNIZED	FATAL ERROR
30	30...	SIGNAL
31	31...	SIGNAL
32	32 CHECK MAGAZINE OVERLOAD SWITCHES	ERROR
33	33 CHECK BAR FEEDER OVERLOAD SWITCHES	ERROR
34	34 EMERGENCY BUTTON PRESSED	FATAL ERROR
35	35 CLOSED GUIDE CHANNELS	SIGNAL
36	36 BLOCK BAR PUSHER	SIGNAL
37	37 GO TO ZERO POSITION	SIGNAL
38	38 MOVE BAR PUSHER FORWARD	SIGNAL
39	39 OPEN GUIDE CHANNEL OR FEED BAR P.	SIGNAL
40	40 CLOSE COVER	FATAL ERROR
41	41 LATHE DOORS SAFETY ACTIVATED	SIGNAL
42	42 MANUAL MODE BLOCKED - NO COLLET OPEN	SIGNAL
43	43 SAFETY DISAB. SWITCH ACTIVATED	SIGNAL
44	44 NO GUIDE CHANNEL LUBRICATION	ERROR
45	45 FAILURE DURING BAR CHANGE	FATAL ERROR
46	46...	WARNING
47	47...	WARNING
48	48 LOBSTER LIFTING FAILED	FATAL ERROR
49	49 BAR PUSHER SENSOR BACK	FATAL ERROR
50	50 CHECK SENSORS S4.7-S5.0-S5.1-S5.2	FATAL ERROR
51	51 SENSOR FOR CLOSED GUIDE CHANNELS	FATAL ERROR
52	52 TIME-OUT ERROR - STOP FROM LATHE FAILED	FATAL ERROR
53	53 BAR PUSHER ENGAGEMENT FAILED	FATAL ERROR
54	54 ...	
55	55 DRILLING UNIT OUT OF POSITION	SIGNAL

56	56 NO MACHINING PROCESS	SIGNAL
57	57 HEADSTOCK MOT. INVERTER PROTECTED	ERROR
58	58 SPINDLE MOTOR INVERTER PROTECTED	ERROR
59	59 PULL BAR BACKWARDS	SIGNAL
60	60 DRILLING UNIT COVER	SIGNAL
61	61 READ FAILURE S1.6	ERROR
62	62 READ FAILURE S1.1	SIGNAL
63	63 BAR SHIFT	ERROR
64	64 LUBRICATING ERROR	ERROR
65	65 WORN-OUT TOOL	WARNING
66	66 REPLACE TOOL	ERROR
67	67 READ FAILURE S0.6	ERROR
68	68 READ FAILURE S0.7/1.1/0.6	ERROR
69	69 READ FAILURE S1.0	ERROR
70	70 READ FAILURE S1.1	ERROR
71	71 READ FAILURE S1.2	ERROR
72	72 READ FAILURE S1.3 (BAR STOP)	ERROR
73	73 READ FAILURE S1.4	ERROR
74	74 READ FAILURE S1.5	ERROR

Explanation of messages:

Warning rank	Meaning
SIGNAL	A signal is deactivated as soon as the cause is removed.
WARNING	A warning is still active after the cause has been removed. Press RESET to deactivate it.
ERROR	When an error occurs, the bar feeder is stopped as soon as it receives a STOP signal from the lathe. To deactivate the error, the bar feeder must receive a RESET signal.
FATAL ERROR	When a fatal error occurs, the bar feeder is stopped. A RESET signal is necessary to deactivate the error. If the drilling machine is working, its working cycle must be completed before the bar feeder is stopped.

INDEX


9.1	GUIDING SPROCKETS - REPLACEMENT 	2
9.2	LOADING LEVERS ROLLERS - REPLACEMENT 	3
9.3	SIR MS32 F LIFTING BELTS - REPLACEMENT 	3
9.4	SIR MS32 F TRANSLATION BELTS - REPLACEMENT 	5
9.5	CAPACITIVE SENSOR - REPLACEMENT 	6
9.6	GUIDE CONTROL SENSORS - REPLACEMENT 	6
9.7	BAR PUSHER BACKWARD LIMIT STOP - REPLACEMENT 	7
9.8	ENCODER - REPLACEMENT 	8
9.9	SHORT FEED POSITIONING CYLINDER - REPLACEMENT 	8
9.10	DRUM HATCH CYLINDER - REPLACEMENT 	9
9.11	BAR FEEDING DEVICE CYLINDERS - REPLACEMENT 	10
9.12	BAR-PUSHER GRIP CYLINDER - REPLACEMENT 	11
9.13	KEYBOARD BATTERY - REPLACEMENT 	12
9.14	PLC BATTERY - REPLACEMENT 	13
9.15	RECOMMENDED SPARE-PARTS - LIST 	14

9.1 GUIDING SPROCKETS - REPLACEMENT

-
- Set the guide channel to its smallest diameter.
- Remove washers and retaining rings.
- Remove the sprockets.
- Install the new sprockets: be sure the pins corresponding to the smallest diameter are aligned to the pins on the bracket.
- Insert washers and retaining rings.


9.2 LOADING LEVERS ROLLERS - REPLACEMENT

- Cut roller (A) and remove it.
- Assemble a new roller.
- Repeat the operation to replace the other rollers whenever necessary.



9.3 SIR MS32 F LIFTING BELTS - REPLACEMENT

- Empty the bar magazine.
- By turning the relevant shaft, uncover plate (A) and disassemble it.
- Disassemble the broken belt and assemble a new belt.
- Repeat the above mentioned operations to replace other belts whenever necessary.



Belt stop signal check

Once one or more belts have been replaced, check and if necessary adjust the position of the cams controlling the belts lowering and lifting.

- Lower belts completely.
- Cam (B) shall be at the low limit switch.
- Bring belts in the upper position.
- The cam (C) must be up in its end of stroke position.
- The cam (B) must cover sensor (E).




CAUTION:

Should upper belts be too tight, the relevant supports may bend.

Otherwise, a loosening of upper belts prevents some bars from reaching the selection device.

Legend


- A Belt locking plate (see figure in previous page).
- B Cam
- C Cam
- D Lower end-of-travel transducer
- E Upper end-of-travel transducer
- F Upper end-of-travel transducer



16_099_0

9.4 SIR MS32 F TRANSLATION BELTS - REPLACEMENT

- Loosen screw (A).
- Remove the spring pins from joints (B) and shift them along the shaft, so that the belt may be removed.
- Assemble a new belt.
- Replace joints and introduce the spring pins.
- Tighten the belt (see paragraph 7.2.2).
- Repeat the above mentioned operations to replace the other belts whenever necessary.




INFORMATION:

Upon request, a special polyurethane belt particularly resistant to oil, chipping and cutting bars, may be supplied (see the spare parts catalogue 9.15.).

9.5 CAPACITIVE SENSOR - REPLACEMENT

- Replace the capacitive sensor.
- Position a 4 mm \varnothing bar on the lifted loading levers.
- Adjust the sensitivity of the sensor by setting it at the minimum value.
- Gradually increase the sensibility until the luminous led (A) switches on.
- Said led must switch off when the bar is removed.



9.6 GUIDE CONTROL SENSORS - REPLACEMENT


Guide closing sensors

- Replace the sensors (A).
- Adjust their position on the diameter \varnothing (B) of the rod, not on diameter \varnothing (C).




CAUTION:

If the position of the sensors were adjusted on diameter \varnothing (C), they would be cut during rod extension.




Guide opening sensors


- Replace the sensor (D). Adjust its position so that it may detect the presence of collar (E).
- Replace sensor (F). Adjust its position so that it may detect the presence of washer (G).


Guide pre-opening sensor

- This sensor is operated when the equipment is working in the "Staggered Sprockets Operation Mode".
- Replace sensor (H). Adjust its position so that it may detect the presence of groove (L).



9.7 BAR PUSHER BACKWARD LIMIT STOP - REPLACEMENT 

- Replace sensor (A).
- Adjust its position, which must be at 0.7 mm from the end of the truck (B).




9.8 ENCODER - REPLACEMENT

- Disassemble the encoder unit from the bar feeder by unscrewing screws (A).
- Loosen headless screw (B).
- Disassemble the encoder by loosening screws (C) and rotating it clockwise by a few degrees.
- Assemble the new encoder by performing the same operations the other way round.




9.9 SHORT FEED POSITIONING CYLINDER - REPLACEMENT

- Replace cylinder (A).
- The centre of the short feed positioning stop (B) must be on the feeding axis.




9.10 DRUM HATCH CYLINDER - REPLACEMENT

- Replace cylinder (A).
- When the cylinder is at its limit switch (internal rod), the hatch shall be in a vertical position parallel to the loading levers. As far as adjustment is concerned, screw or unscrew the articulated head (B).
- The sensor located on the cylinder should mark the closure of the door even if the cylinder is not in the end of stroke position.




9.11 BAR FEEDING DEVICE CYLINDERS - REPLACEMENT 

- Replace cylinders (B).




- The cylinders stroke must be adjusted so that the bar feeding occurs on the feeding axis.
- Adjust through ring nut (C).
- Further adjustments should be performed on slots (D) located on the lever.



9.12 BAR-PUSHER GRIP CYLINDER - REPLACEMENT 

- Remove the clamps device case.
- Replace cylinder (A).
- The cylinder stroke must be adjusted so that rollers (B), when at standstill, are upright with the feeding axis.
- To carry out adjustment, untighten nuts (C), screw or unscrew threaded spacer (D). Tighten nuts (C).
- The sensor located on the cylinder should send the signal when the rollers are in the rest configuration.



9.13 KEYBOARD BATTERY - REPLACEMENT


The battery should be replaced every year or, in any case, when the battery warning light 23[sir_tasto 23] sends a red flashing signal.



INFORMATION

If the battery is not replaced, the date and time will disappear from the display.

- Cut off the bar feeder supply.
- Unscrew the key-board's panel (A).
- With a screwdriver, unscrew (but not completely) the 4 angle screws (B) of the double back box (C). Remove the double back box by keeping it parallel to the surface to which it was fastened.
- Remove the battery (D) from its compartment. Insert the new battery (type: lithium 3-volt CR 2430)



DANGER - WARNING:

Battery explosion danger if inserted with reversed polarity.


- Fix the double housing (C) to the panel again and tighten the 4 screws (B).
- Connect the bar feeder and check that the battery charge is signalled.

9.14 PLC BATTERY - REPLACEMENT 

Replace the battery every year.


INFORMATION

If the battery is not replaced, the "PLC/CNC software" data will be deleted.


INFORMATION

When replacing the battery, make sure that the bar feeder is live. Warning: if the battery is replaced with the bar feeder off, I.E. with PLC not live, the bar feeder parameters will be cleared from the PLC memory and will have to be immediately restored.

- Open the cubicle.
- Uplift the small door (A) and remove battery (B) from its housing by disconnecting the socket.
- Fit the new battery (type: lithium 3.6-volt 1/2 AA): be careful to fit the connector correctly.
- Close door (A).

9.15 RECOMMENDED SPARE-PARTS - LIST

Table 1. Recommended spare-parts.

Ref.No.	Description	Features	Pcs.
31240017	Encoder		1
680310720	Upper guide ch. 19-33-43-53		48
680310730	Lower guide ch. 19-33-43-53		48
680310090	Washer		96
680380220	Bar Puhser Truck		1
680380490	Chain MS52 L=33		1
680380150	Chain MS52 L=38		1
680390010	Rack		10
680389026	Bar Pusher Quick Coupling		6
680380390	Upper Chain Guide		6
680380400	Lower Chain Guide		6
680380350	Chain deviator		6
680380500	Motor Pinion		1
680320720	Loading Roller		8
41311062	UFI Cartridge		1
41311025	Fam Filter		1
41311026	Fam Filter		1
612071731	Pressure Switch P=1 bar		1
612071751	Pressure Switch P=1,2 bar		1
612071741	Pressure Switch P=0.7 bar		1
072009282	Bundle Lifting Belt		4
24371543	Bundle Shifting Belt		4
001033100	Bar Stroke Limiter Clutch Plate		2
32210004	SIEMENS Capacitive Sensor		1
680130060	Rack Shifting Chain		1
685030990	Rack Lifting Chain***		1
41142008	Coil EDH		1

(*) On demand we can supply a special polyurethane belt (DESMOPAN 385) offering high resistance to oils, scratches and sharp bars.

To be continued...

Ref. No.	Description	Features	Pcs.
41142016	Coil MD		2
41142002	Valve PPRC		1
41142018	Valve VR		1
41142007	Ev EDH		1
41142005	Ev EDH		1
41142004	Ev EDH		1
41142003	Ev EDH		1
41142023	Valve PPRC		1
41142019	Valve RPC		1
612061691	Plug		1
34320013	Connector		1
32210012	Finec Bero M12 Inductive Sensor		1
32210401	Finec Bero M8 Inductive Sensor		1
31210051	Limit Switch IFM NA		1
31210052	Limit Switch IFM NC		1
32215004	Sensor IFM		1
680350250	Clamp		3
D60151801	Revolving Tip SIR D=18	DELIVERED WITH EVERY BAR FEEDER	6
D67101841	Bar Pusher SIR 18 - XL		6
D60153201	Revolving Tip Sir D=32		6
D67103241	Bar Pusher SIR 32 - XL		6
D60154201	Revolving Tip SIR D=42		6
D67104241	Bar Pusher SIR 42 - XL		6
D60155101	Revolving Tip SIR D=52		6
D67105241	Bar Pusher SIR 52 - XL		6
D60154501	Revolving Tip SIR D=45		6
D67104541	Bar Pusher SIR 45 - XL		6
D60155601	Revolving Tip SIR D=56		6
D67105641	Bar Pusher SIR 56 - XL		6
23320004	Linear Slide guide		2
685011250	Oil Tank Gasket	TO BE REPLACED PERIODICALLY (every six months)	2
31210105	Schunk Sensor		1
685011100	Camping Unit		3
685011320	Spacer		6
31214540	Balluff Sensor		1
685010080	Bushing		1

INDEX

10.1	AIM OF THE PRODUCT	2
10.2	GENERAL DESCRIPTION OF DRILLING MACHINE	2
10.2.1	MAIN ELEMENTS.....	2
10.2.2	WORKING CYCLE - GENERAL DESCRIPTION	6
10.2.3	APPLICATIONS OF DRILLING MACHINE	9
10.3	INSTRUCTIONS FOR THE USER	10
10.3.1	DESCRIPTION OF CONTROL DEVICES.....	10
10.3.2	USE AND ADJUSTMENT.....	14

10.1 AIM OF THE PRODUCT

Thanks to the use of a drilling machine it is possible to drill the end of a bar automatically before it is loaded in the bar feeder drum.

The end of the bar being drilled, it is possible to hold the bar by means of a pipe gripper and to use a bar pusher the diameter of which is as large as the bar diameter, or even smaller; in case the diameter of the bar pusher is smaller than the diameter of the bar, the spindle reduction tubes should fit the diameter of the bar and not the diameter of the bar pusher.

The bar can be thus precisely fed; oscillations and vibrations caused by rotating bars, which could cause damages during workpiece machining, can be dampened.


10.2 GENERAL DESCRIPTION OF DRILLING MACHINE

10.2.1 MAIN ELEMENTS


The drilling machine consists of four main elements:

- The drilling unit, located on the upper rear side of the bar feeder (visible through the door M): this unit performs facing operations and grips the bar while drilling it.
- The feeding unit, located on the upper middle part of the bar feeder (visible through the upper inspection window on the operator side and accessible from the upper rear magazine door): this unit feeds the bar forward for drilling and facing operations and draws it back to be loaded in the bar feeder drum.
- The chip removal unit, located in the rear side of the bar feeder, to convey chips shaved away as bar are machined.
- The lubrication unit, integrated on the rear door of the bar feeder.


The drilling machine is also provided with an hydraulic drive unit, which is located on the rear side of the bar feeder, as well as with a wiring panel enclosed in the bar feeder wiring box.



- (A) SPINDLE: motor drive moving the drilling unit (main machining movement).
- (B) FEEDING MOTOR: spindle motor drive performing the secondary machining movement.
- (C) GRIPPER: element holding the bar during facing operation.
- (D) FLAG: element detecting the correct position of a bar in the gripper.
- (E) CHUCKS: gripping system drawing the bar during its axial displacement towards the drilling unit and during its backward stroke.
- (F) ENCODER: detection system for bar forward and backward strokes determining bar displacement during facing operation.



- (G) CHIP BOX: box containing metal chips.
- (H) CONVEYOR PLATE: element conveying the metal chips to the chip box.
- (I) LEVER ADJUSTMENT UNIT: lever adjustment system for the regulation of the levers lifting the bar until it is aligned to the drilling unit.
- (L) LUBRICATION: cooling and lubricating system for spindle tool.
- (M) ACCESS DOOR: access door to reach the spindle tool, provided with an inspection window for bar machining control and with a scale for workpiece displacement control.




- (N) DRILLING MACHINE EMERGENCY BUTTON: emergency button to stop drilling machine operation.
- (O) INSPECTION WINDOW FOR LEVER ADJUSTMENT: window for the control of lever displacement adjustment.

10.2.2 WORKING CYCLE - GENERAL DESCRIPTION


A new undrilled bar is placed on the loading levers. Sensor S 5.3 is active and S 5.4 is off.




The bar is lifted until it is aligned to the drilling unit. The solenoid valve Y124.2 is energized until activation of S1.0 sensor.




The feeding unit locks the bar. The solenoid valve Y124.3 is energized until sensor S1.1 is shut off.




The feeding unit moves the bar to the locking gripper. The solenoid valve Y124.4 is energized.




The bar reaches the drilling position indicated by the flag. The solenoid valve Y124.4 is disabled upon disabling of S1.3 sensor.




The collet closes and holds the bar. The solenoid valve Y124.6 is energized.




The feeding unit jaws open and release the bar. The solenoid valve Y124.3 is disabled upon activation of sensor S 1.1, the flag disappears, the solenoid valve Y124.7 is activated until activation of sensor S1.4 and disabling of S1.3.




The spindle will now start rotating. PLC A125.4 and A125.5 outputs are enabled. A125.0 activates hole lubrication.




The spindle will now approach the bar.
A125.1. output is enabled.




The drilling unit moves forwards to perform drilling operation until sensor S1.5 is activated. Hole lubrication is stopped, A125.0 is disabled.




When drilling is complete, the drilling unit goes back. A125.1, A125.2, A125.4 and A125.5 outputs are enabled.




As soon as it reaches position zero, the drilling unit stops.




The spindle stops on position zero. Sensor S1.6 is enabled.




The feeding unit grips the bar again. The solenoid valve Y124.3 is energized until S1.1 sensor is disabled. The collet opens and disables solenoid valve Y124.6.




The feeding system performs the backstroke. The bar is pulled out of the gripper as the feeling unit is drawn back while the encoder is controlling the unit backstroke. The solenoid valve Y124.4 is disabled and sensor S06 is activated.




The feeding system releases the bar. The solenoid valve Y124.3 is deenergized upon activation of S1.1 sensor.



The flag returns to rest position. The electrovalve Y124.7 is disabled as soon as the sensor S1.3 is enabled and sensor S1.4 is off.




The lifting levers return to wait position before loading the bar into the bar feeder drum (Sensor S1.0 is disabled).



If the photocell S1.2 is off the electrovalve Y125.7 is energized.

Adjustment...

This message is displayed when the drilling machine is moving in manual mode.



10.2.3 APPLICATIONS OF DRILLING MACHINE

A drilling machine can drill bars from Ø 20mm (using a Ø 15drilling tool) up to Ø52 (using a Ø15 or a Ø20 drilling tool). By means of a suitable drilling tool and of accurately set drilling parameters, it is possible to drill metal bars the hardness of which can reach 250 HB. The hole diameter should in no way be smaller than 10 mm so as to allow the tube gripper to hold the bar correctly, and should not be larger than 20 mm otherwise the spindle nominal power would be exceeded during machine operation 3000 rpm..



DANGER-WARNING

The drilling device is not suitable for the preparation of inflammable material bars.



CAUTION

The customer will need to install a suction system with continuous suction and a minimum capacity of 36 m³/h.

Air must be filtered for oil separation before being reintroduced in the environment.



ATTENTION!

For a correct use of the lubrication system, the drilling tool and the tool holder should be provided with an axial opening for the nebulized lubricant. Should the operation area not be properly lubricated, the tool lifetime as well as the lubrication system seals cannot be ensured and the hole could not be properly carried out.

For a correct operation, make sure the hole is coaxial to the bar. It is necessary that the bar end is a little chamfered (the bar end surface should be larger than the hole to be drilled) and perpendicular to the bar axis. The bar drilling unit has been built so as to prepare symmetrical bars, in case of bars with a not-circular section (hexagonal or square types), contact the IEMCA service centre to set correctly the device. For what not included here, refer to the limits indicated in the bar feeder instructions.




DANGER-WARNING

It is also important to check at regular intervals that the spindle guide system has no backlash which would not ensure a correct drilling position.


10.3 INSTRUCTIONS FOR THE USER


10.3.1 DESCRIPTION OF CONTROL DEVICES



The drilling machine control devices are on the right side of the operator's panel.

The bar feeder emergency buttons (located on the operator's panel and inside the wiring box) may stop the operation of the bar feeder as well as of the lathe and of the drilling machine; pressing emergency button N on the contrary, which is located next to the drilling unit, it is possible to stop the drilling machine operation and the loading levers only, allowing the drilling machine to be drawn back.




F21 Button STEP BY STEP OPERATION

Press F21 to activate Step by Step operation.

After pressing the button, the button led will light up. Press F21 to restore drilling machine working cycle. In case F22 lights up because of signal failure of microswitch sensors, press both F21 and F22 at the same time to restore drilling machine working cycle.

F22 Button SENSOR DEACTIVATION


When the button led lights up, the drilling machine sensors can be deactivated by pressing this button (For example, if no bar is present, it is possible to press this button for step by step operation).

F23 Button SPINDLE RETURN

By clicking this button when the spindle has not completely left the bar being machined, the spindle returns to the rest position.

To carry out the above mentioned operation, the drilling machine working cycle must be over, could also be displayed or keep button F25 pressed.

Keeping button F23 pressed, it is possible to reach the retracted position to replace the spindle tip, the inserts and the gripper.



F24 Button NOT ACTIVATED

F25 RESET 5" Button

To activate the RESET button, manual operation mode must be selected.
Press this button during Step by Step operation to stop the process.
Press this button to release buttons F26÷F29 in case the LEDs are activated.

F26 Button LEVER UP/DOWN

Press this button to start movement, press again for lever return.

F27 Button CLAMPS OPEN/CLOSE

Press this button to start movement, press again for clamps return.

F28 Button BAR CLAMPING VICE OPEN/CLOSE

Press this button to start movement, press again for vice return.

F29 Button BAR STOP DISAPPEARS

Press this button to start movement, press again for bar stop return.

F30 Button CLAMPS MOVING FORWARD

Press this button to move the bar towards the drilling unit. Release the button and press it again for the return of the drilling unit.

Reset the drilling machine following these instructions:

- 1) The drilling unit must be in wait position, otherwise press the RESET button to move it to wait position.
- 2) Keep pressing button F25 for 5 seconds: all the devices on the drilling machine will be released.
- 3) If a bar is closed in the clamp, the levers will not come down.
- 4) The motors of the drilling unit will stop.
- 5) Press button F27 and then F30 to move the bar backward, after the motor has been driven backward and the bar detecting photocell has been released.
- 6) Press button F25 again to open the chucks of the feeding unit and to move down the loading levers to the rest position.

S38 Button Drilling machine stop/Spindle return

- Press this button to restore the drilling machine to normal operation (alarm nr. 60 " Drilling machine cover" will be displayed). Keep pressing the button to let the spindle return to the rest position "0 position". Pressing button F23 it is possible to reach the retracted position.
- This position allows spindle or tool maintenance. After maintenance has been completed, press button S32 to reset alarm nr. 60 and restore drilling machine to normal operation.
- If button S32 is pressed as soon as alarm nr. 60 " Drilling machine cover" is displayed the drilling machine is restored immediately to normal operation.
Press this button to stop drilling machine operation without stopping either bar feeder or lathe working cycles.

Press button S38 and then button F30 to restore the position of the devices of the drilling machine and restore operation.

10.3.2 USE AND ADJUSTMENT

The automatic operation mode of the drilling machine is activated when parameter 16 is set to 1 from the operator's panel.

If parameter 16 is set to 0, no bar facing cycle will be performed on the bar feeder.




INFORMATION

Before starting the bar facing cycle on the bar feeder, the following adjustment should be carried out when bar feeder and lathe are not working and the drilling unit is in retracted position ("home position" or zero point).

- 1) By means of a hand-puller or a pneumatic puller, ass a Hainbuch gripper (bar clamping system) to the drilling unit; the size of the gripper should be 65 and should fit the bar diameter (gripper code is Hainbuch SK65BZ##, where ## indicate the bar diameter in mm).




- 2) Locate the tool protection cover against the machine cover to remove it.




- 3) Remove the drilling tool (if available).



- 4) Loosen the screws on the drilling machine cover, remove the cover and the tool protection cover.



- 5) Remove the screw (A) referred to the barstop block.
- 6) Turn the barstop (B).




- 7) Use the special puller to remove or replace the Hainbuch gripper.



- 8) Add a spindle tip on the spindle, making sure it is suitable to the material to be drilled. The diameter of the spindle tip should be at least 5mm smaller than the bar diameter.

Install the spindle tip on one ABS 50 KOMET holder.

The spindle tip on the holder should be protruding 115mm from the spindle shaft end (see picture).



Please use the following sequence to drill:

a) Hole D=20 mm: insert drill Komet Trigon V30-92000 ABS50


For difficult drilling works we recommend: Extension KOMET ABS 50-V50 A20 00550 + insert drill KOMET KUB TRIGON V30-31500 or KOMET KUB QUATTRON U10-71501.


INFORMATION:


b) to perform the above mentioned step it is necessary to adjust sensors S1.5, S1.6 and S125.7 (to be done under IEMCA approval only).

b) Hole D=15 mm: Extension KOMET ABS 50-V50 A20 + insert drill KOMET KUB TRIGON V30-31500 or KOMET KUB QUATTRON U10-71501.

- 9) Adjust the upward movement of the loading levers according to the bar diameter to be loaded, by means of the hand grip on the lever rod, which can be reached through the front door of the bar feeder drum and is visible through the main inspection window.



- 10) Shims should be added under the feeding unit rubber chucks, according to the diameter of the bar to be loaded hereunder indicated:
- for bars from $\varnothing 20$ mm up to $\varnothing 32$ mm add two shims under each chuck,
 - for bars from $\varnothing 32$ mm up to $\varnothing 42$ mm add only one shim under each chuck and replace the others into their housing,
 - for bars from $\varnothing 42$ mm up to $\varnothing 52$ mm, no shim is needed (replace them into their housing).



- 11) Install the screw (A) in the hole corresponding to the diameter of the point used to bore (\emptyset -20mm; \emptyset -15mm; \emptyset -10mm).


**INFORMATION:**

Manufacturing calibration of the pressure switch referred to the barstop:

- Empty Air pressure from 1,8 to 2,2 bar;
- Change over Pressure 3 bar.

For possible pressure switch control or calibration

To control the pressure switch, please contact Iemca Service.



- 12) Bar pushers should be provided with pipe grippers suitable for the holes to be drilled.
- 13) On the operator's panel, set correct cutting speed and feeding parameters according to the diameter of the hole and to the type of material or choose one of the parameter lists that are available on the system, only in case the required conditions (i.e. Spindle tip diameter, bar material) correspond to the conditions on one of the available parameter lists. For any further information concerning how to enter an available parameter list or how to set new operation parameters, please see chapter ... or the keyboard instruction manual...

**ATTENTION!**

Any work must be carried out by qualified technicians and/or persons who will follow all safety guidelines in respect of the existing norms.

Before starting drilling machine operation, check the oil level inside the oil tank.

Lubrication oils must have the following features:

Oil viscosity at 40°C = 47mm²/sec

Oil density at 20°C = 0,922 g/mm³

Flammable point over 265°C



CAUTION - PRECAUTION:


We recommend the following lubrication oil: SETOL ST-SH.

For any further information, please see the lubrication system manual that has been delivered with your bar feeder.




52_31_21_12

Oil topping up:
remove the plug (A) and fill the oil tank to the top.




Place the chip collector under the chip conveyor system "C".



11.1 GUIDE CHANNELS AND BAR PUSHER - TABLE

The choice of guide channels and bar pusher must be made according to the diameter of the barstock. The bar feeder is usually supplied with a bar pusher whose diameter is equal to the maximum bar passage of the lathe. In certain cases, to be able to work in the best possible conditions, it may also be necessary to use a bar pusher with smaller diameter.



- A Guide channel
- B Bar pusher
- C Revolving tip
- D Collet
- E Bar


CAUTION:

the field of application of collets for machining specific bar diameters in the different guide channels are indicated in the table. When this diameter is lower than the diameter of the guidechannel, there can be vibrations or working problems in the barloader. It is useful to consider the possibility to reduce the speed rotation of the bar or to change the diameter of the guide channel to optimize the application. Therefore, in order to optimise operation, the bar rotation speed should be reduced or the guide channel diameter should be changed.


Diameters Comparative table during the standard working mode.

Bar diameter – $\varnothing A$ (mm)		Maximum tube diameter (*)– $\varnothing A$ (mm)	Guide channel diameter – $\varnothing B$ (mm)	Bar pusher diameter– $\varnothing C$ (mm)
Min	Max			
10	15	18	19	18
15	28	32	33	32
25	38	42	43	42
25	40	45	46	45
35	48	52	53	52
35	50	55	57	56

() Also valid for prepared bars and normal barstock with front ejection of bar remnant.*

11.2 REVOLVING TIP - TABLE

The choice of the revolving tip depends on the diameter of the guide channel, that of the bar pusher and the collet coupling version.




- A Guide channel
- B Bar pusher
- C Revolving tip
- D Collet
- E Bar

Guide channel diameter $\varnothing B$ (mm)	Bar pusher diameter $\varnothing C$ (mm)	Collet version – D (type of coupling)	Revolving tip diameter $\varnothing GR$ (mm)	Revolving tip code	See section
19	18	With pin (SCHL)	18	D60151801	
33	32	With pin (SCHL)	32	D60153201	
43	42	With pin (SCHL)	42	D60154201	
46	45	With pin (SCHL)	45	D60154501	
53	52	With pin (SCHL)	52	D60155201	
57	56	With pin (SCHL)	56	D60155601	

11.3 Revolving Tips \varnothing GR 18÷56 - Table

- For collet with pin coupling (SCHL)




- A Collet
- B See section
- C See section 001 than 602P
- D Collet for tube
- E Revolving tip





\varnothing GR (mm)	Revolving tip code	\varnothing F (mm)	\varnothing B (mm)	GP (mm)	C (mm)	A2 (mm)	SP1 (mm)
18	D60151801	11	18.5	127	M15x1 sx	18.5	6
32	D60153201	20	32.5	169.5	M28x1 sx	37.5	8
42	D60154201	20	42.5	169.5	M30x1 sx	37.5	8
45	D60154501	20	45.5	169.5	M30x1 sx	37.5	8
52	D60155201	20	52.5	215.5	M45x1 sx	31	8
56	D60155601	20	56.5	215.5	M50x1.5 sx	31	8



12.1 CONVERSION TABLES 001



HEXAGONAL BARS (unit of measurement "millimetres") - Table

Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.




	 $Y = Z \times 1,154$	$\varnothing A$		 $Y = Z \times 1,154$	$\varnothing A$
mm	mm	mm	mm	mm	mm
1.5	1.73	1.7	28	32.33	32
2	2.31	2.2	29	33.48	33.2
2.5	2.89	2.8	30	34.64	34.5
3	3.48	3.25	31	35.79	35.5
3.5	4.04	3.8	32	36.95	36.8
4	4.61	4.5	33	38.10	37.8
4.5	5.19	5	34	39.25	39
5	5.77	5.5	35	40.41	40.2
5.5	6.35	6.2	36	41.56	41.3
6	6.92	6.8	38	43.87	43.5
6.5	7.50	7.3	39	45.03	44.8
7	8.08	7.8	40	46.18	46
7.5	8.66	8.5	41	47.34	47
8	9.23	9	42	48.49	48.2
9	10.39	10.2	43	49.65	49.5
10	11.54	11.3	44	50.80	50.5
11	12.70	12.5	45	51.96	51.8
12	13.85	13.5	46	53.11	52.8
13	15.02	14.8	48	55.42	55
14	16.16	16	50	57.73	57.5
15	17.32	17.2	52	60.04	59.5
16	18.47	18.3	55	63.50	63
17	19.62	19.5	57	65.78	65.25
18	20.78	20.6	60	69.24	68.75
19	21.93	21.8	62	71.55	71
20	23.09	22.8	65	75	74.5
21	24.24	24	67	77.3	76.75
22	25.40	25.2	70	80.78	80.25





	 Y=Zx1,154	ØA
mm	mm	mm
23	26.55	26.2
24	27.71	27.5
25	28.86	28.5
26	30.02	29.8
27	31.17	31

	 Y=Zx1,154	ØA
mm	mm	mm
72	83.08	82.5
75	86.55	86
80	92.32	91.75
85	98.1	97.5

SQUARE BARS (unit of measurement "millimetres") - Table


Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.





	 $Y = Z \times 1,414$	$\varnothing A$		 $Y = Z \times 1,414$	$\varnothing A$
mm	mm	mm	mm	mm	mm
1	1.41	1.3	20	28.28	27.5
1.5	2.12	2	22	31.10	30.5
2	2.82	2.7	23	32.52	32
2.5	3.53	3.4	24	33.93	33
3	4.24	4	25	35.35	34.5
4	5.65	5.5	26	36.76	36
4.5	6.36	6.2	27	38.17	37.5
5	7.07	6.8	28	39.59	38.5
5.5	7.77	7.5	30	42.42	41.5
6	8.48	8.3	32	45.24	44.5
6.5	9.19	9	34	48.07	47
7	9.89	9.7	35	49.49	48.5
8	11.31	11	36	50.90	50
8.5	12.01	11.8	37	52.31	51.5
9	12.72	12.5	38	53.73	52.5
10	14.14	13.8	39	55.15	54.5
10.5	14.84	14.5	40	56.56	55.5
11	15.55	15	41	57.97	57
12	16.97	16.5	42	59.38	58.5
12.5	17.67	17	43	60.08	59
13	18.38	18	44	62.21	61
14	19.79	19.5	45	63.63	62.5
15	21.21	20.8	46	65.04	64
16	22.62	22	50	70.7	69.5
17	24.04	23.5	55	77.77	76.75
18	25.52	25	60	84.84	83.75
19	26.86	26	65	91.91	91

HEXAGONAL BARS (unit of measurement "inches") - Table

Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.







	$\varnothing A$	
	inches	mm
1/8	3.5	9/64
3/16	5.25	13/64
1/4	7	9/32
5/16	8.75	11/32
3/8	10.75	27/64
7/16	12.5	31/64
1/2	14.25	9/16
9/16	16.25	41/64
5/8	18	45/64
11/16	19.75	25/32
3/4	21.75	55/64
13/16	23.5	59/64
7/8	25.25	63/64
15/16	27.25	1"5/64
1"	29	1"9/64
1"1/16	30.75	1"13/64
1"1/8	32.5	1"9/32
1"3/16	34.25	1"11/32
1"1/4	36.25	1"27/64
1"5/16	38	1"1/2

	$\varnothing A$	
	inches	mm
1"3/8	39.75	1"9/16
1"7/16	41.75	1"41/64
1"1/2	43.5	1"23/32
1"9/16	46.5	1"53/64
1"5/8	47.25	1"55/64
1"11/16	49	1"15/16
1"3/4	50.75	2"
1"13/16	52.75	2"5/64
1"7/8	54.5	2"9/64
1"15/16	56.25	2"7/32
2"	58	2"9/32
2"1/16	59.75	2"11/32
2"1/8	61.5	2"27/64
2"3/16	63.5	2"1/2
2"1/4	65.25	2"37/64
2"1/2	72.5	2"55/64
2"3/4	79.75	3"9/64
3"	87	3"27/64
3"1/4	94.25	3"23/32

ROUND BARS (unit of measurement "inches") - Table

Before selecting the steel collet, define the internal diameter $\varnothing A$ by consulting the table below.



	$\varnothing A$		$\varnothing A$		$\varnothing A$
inches	mm	inches	mm	inches	mm
1/32	0.8	17/32	13.5	1"1/8	28.5
3/64	1.2	35/64	14	1"3/16	30.25
1/16	1.6	9/16	14.25	1"1/4	31.75
5/64	2	37/64	14.75	1"5/16	33.25
3/32	2.4	19/32	15	1"3/8	35
7/64	2.8	39/64	15.5	1"7/16	36.25
1/8	3.2	5/8	16	1"1/2	38
9/64	3.6	41/64	16.25	1"9/16	39.75
5/32	4	21/32	16.75	1"5/8	41.25
11/64	4.4	43/64	17	1"11/16	43
3/16	4.8	11/16	17.5	1"3/4	44.5
13/64	5.2	45/64	18	1"13/16	46
7/32	5.6	23/32	18.25	1"7/8	47.75
15/64	6	47/64	18.75	1"15/16	49.25
1/4	6.4	3/4	19	2"	50.75
17/64	6.8	49/64	19.5	2"1/16	52.5
9/32	7.2	25/32	19.75	2"1/8	54
19/64	7.6	51/64	20.25	2"3/16	55.5
5/16	8	13/16	20.75	2"1/4	57.25
21/64	8.4	53/64	21	2"5/16	58.75
11/32	8.8	27/32	21.5	2"3/8	60.5
23/64	9.1	55/64	21.75	2"7/16	62
3/8	9.6	7/8	22.25	2"1/2	63.5
25/64	10	57/64	22.75	2"9/16	65
13/32	10.4	29/32	23	2"5/8	66.75
27/64	10.8	59/64	23.5	2"11/16	68.25
7/16	11.25	15/16	24	2"3/4	70
29/64	11.5	61/64	24.25	2"13/16	71.5
15/32	12	31/32	24.75	2"7/8	73
31/64	12.5	63/64	25	2"15/16	74.75
1/2	12.75	1	25.5	3"	76.25
33/64	13.25	1"1/16	27		

CONVERSION TABLE Inches/Millimetres

Inch fraction		Inch fraction			
		1	2	3	4
		Millimetres			
0	0	0	25,400 0	50,800 0	76,200 0
1/64	0,015 625	0,396 9	25,796 9	51,196 9	76,596 9
1/32	0,031 25	0,793 8	26,193 8	51,593 8	76,993 8
3/64	0,046 875	1,190 6	26,590 6	51,990 6	77,390 6
1/16	0,062 5	1,587 5	26,987 5	52,387 5	77,787 5
5/64	0,078 125	1,984 4	27,384 4	52,784 4	78,184 4
3/32	0,093 75	2,381 2	27,781 2	53,181 2	78,581 2
7/64	0,109 375	2,778 1	28,178 1	53,578 1	78,978 1
1/8	0,125	3,175 0	28,575 0	53,985 0	79,375 0
9/64	0,140 625	3,571 9	28,971 9	54,371 9	79,771,9
5/32	0,156 25	3,968 8	29,368 8	54,768 8	80,168 8
11/64	0,171 875	4,365 6	29,765 6	55,165 6	80,565 6
3/16	0,187 5	4,762 5	30,162 5	55,562 5	80,962 5
13/64	0,203 125	5,159 4	30,559 4	55,959 4	81,359 4
7/32	0,218 75	5,556 2	30,956 2	56,356 2	81,756 2
15/64	0,234 375	5,953 1	31,353 1	56,753 1	82,153 1
1/4	0,25	6,350 0	31,750 0	57,150 0	82,550 0
17/64	0,265 625	6,746 9	32,146 9	57,546 9	82,946 9
9/32	0,281 25	7,143 8	32,543 8	57,943 8	83,343 8
19/64	0,296 875	7,540 6	32,940 6	58,340 6	83,740 6
5/16	0,312 5	7,937 5	33,337 5	58,737 5	84,137 5
21/64	0,328 125	8,334 4	33,734 4	59,134 4	84,534 4
11/32	0,343 75	8,731 2	34,131 2	59,531 2	84,931 2
23/64	0,359 375	9,128 1	34,528 1	59,928 1	85,328 1
3/8	0,375	9,525 0	34,925 0	60,325 0	85,725 0
25/64	0,390 625	9,921 9	35,321 9	60,721 9	86,121 9
13/32	0,406 25	10,318 8	35,718 8	61,118 8	86,518 8
27/64	0,421 875	10,715 6	36,115 6	61,515 6	86,915 6
7/16	0,437 5	11,112 5	36,512 5	61,912 5	87,312 5
29/64	0,453 125	11,509 4	36,909 4	62,309 4	87,709 4
15/32	0,468 75	11,906 2	37,306 2	62,706 2	88,106 2
31/64	0,484 375	12,303 1	37,703 1	63,103 1	88,503 1
1/2	0,5	12,700 0	38,100 0	63,500 0	88,900 0
33/64	0,515 625	13,096 9	38,496 9	63,896 9	89,296 9
17/32	0,531 25	13,493 8	38,893 8	64,293 8	89,693 8
35/64	0,546 875	13,890 6	39,290 6	64,690 6	90,090 6
9/16	0,562 5	14,287 5	39,687 5	65,087 5	90,487 5
37/64	0,578 125	14,684 4	40,084 4	65,484 4	90,884 4
19/32	0,593 75	15,081 2	40,481 2	65,881 2	91,281 2
39/64	0,609 375	15,478 1	40,878 1	66,278 1	91,678 1
5/8	0,625	15,875 0	41,275 0	66,675 0	92,075 0
41/64	0,640 625	16,271 9	41,671 9	67,071 9	92,471 9
21/32	0,656 25	16,668 8	42,068 8	67,468 8	92,868 8
43/64	0,671 875	17,065 6	42,465 6	67,865 6	93,265 6

Inch fraction		Inch fraction			
		1	2	3	4
		Millimetres			
11/16	0,687 5	17,462 5	42,862 5	68,262 5	93,662 5
45/64	0,703 125	17,859 4	43,259 4	68,659 4	94,059 4
23/32	0,718 75	18,256 2	43,656 2	69,056 2	94,456 2
47/64	0,734 375	18,653 1	44,053 1	69,453 1	94,853 1
3/4	0,75	19,050 0	44,450 0	69,850 0	95,250 0
49/64	0,765 625	19,446 9	44,846 9	70,246 9	95,646 9
25/32	0,781 25	19,843 8	45,243 8	70,643 8	96,043 8
51/64	0,796 875	20,240 6	45,640 6	71,040 6	96,440 6
13/16	0,812 5	20,637 5	46,037 5	71,437 5	96,837 5
53/64	0,828 125	21,034 4	46,434 4	71,834 4	97,234 4
27/32	0,843 75	21,431 2	46,831 2	72,231 2	97,631 2
55/64	0,859 375	21,828 1	47,228 1	72,628 1	98,028 1
7/8	0,875	22,225 0	47,625 0	73,025 0	98,425 0
57/64	0,890 625	22,621 9	48,021 9	73,421 9	98,821 9
29/32	0,906 25	23,018 8	48,418 8	73,818 8	99,218 8
59/64	0,921 875	23,415 6	48,815 6	74,215 6	99,615 6
15/16	0,937 5	23,812 5	49,212 5	74,612 5	100,012 5
61/64	0,953 125	24,209 4	49,609 4	75,009 4	100,409 4
31/32	0,968 75	24,606 2	50,006 2	75,406 2	100,806 2
63/64	0,984 375	25,003 1	50,403 1	75,803 1	101,203 1

12.2 COLLETS FOR BARS 602P

COLLETS FOR BARS - Table



CAUTION:


the external diameter of the collet must be at least 0.5 mm less than the external diameter of the bar pusher.

Note for consultation

The codes on the grey ground are indicating the "EMPLOYED SECTOR" to prefer.

Note for ordering

- Collets with codes in bold characters are available from stock.
- Please contact IEMCA service to use the collets with codes in Italics. The delivery times for this kind of collets are longer.



- A Collet
- B Bar diameter
- C Example:
 - 3 mm = 030
 - 3.5 mm = 035
 - 12.5 mm = 125
 - 12.75 mm = 127
- D Family to which it belongs

øA		øF Ø7 G6	øF Ø8 G6	øF Ø11 G6	øF Ø20 G6	
<i>mm</i>	<i>inches</i>	øD 10	øD 12	øD 15	øD 25	
3		602P10030	602P12030			
3.1		602P10031	602P12031			
3.2	1/8"	602P10032	602P12032			
3.3		602P10033	602P12033			
3.4		602P10034	602P12034			
3.5		602P10035	602P12035			
3.6	9/64"	602P10036	602P12036			
3.7		602P10037	602P12037			
3.8		602P10038	602P12038			
3.9		602P10039	602P12039			
4	5/32"	602P10040	602P12040	<i>602P15040</i>		
4.1		602P10041	602P12041	<i>602P15041</i>		
4.2		602P10042	602P12042	<i>602P15042</i>		
4.3		602P10043	602P12043	<i>602P15043</i>	<i>602P25043</i>	
4.4	11/64"	602P10044	602P12044	<i>602P15044</i>		
4.5		602P10045	602P12045	<i>602P15045</i>		
4.6		602P10046	602P12046	<i>602P15046</i>		
4.7		602P10047	602P12047	<i>602P15047</i>		
4.8	3/16"	602P10048	602P12048	<i>602P15048</i>		
4.9		602P10049	602P12049	<i>602P15049</i>		
5		602P10050	602P12050	602P15050	<i>602P25050</i>	
5.1		602P10051	602P12051	602P15051		
5.2	13/64"	602P10052	602P12052	602P15052		

øA		øF Ø7 G6	øF Ø8 G6	øF Ø11 G6	øF Ø11 G6
<i>mm</i>	<i>inches</i>	øD 10	øD 12	øD 15	øD 18
5.3		602P10053	602P12053	602P15053	
5.4		602P10054	602P12054	602P15054	
5.5		602P10055	602P12055	602P15055	
5.6	7/32"	602P10056	602P12056	602P15056	
5.7		602P10057	602P12057	602P15057	
5.8		602P10058	602P12058	602P15058	
5.9		602P10059	602P12059	602P15059	
6	15/64"	602P10060	602P12060	602P15060	
6.1		602P10061	602P12061	602P15061	
6.2		602P10062	602P12062	602P15062	
6.3		602P10063	602P12063	602P15063	
6.4	1/4"	602P10064	602P12064	602P15064	
6.5		602P10065	602P12065	602P15065	
6.6		602P10066	602P12066	602P15066	
6.7		602P10067	602P12067	602P15067	
6.8	17/64"	602P10068	602P12068	602P15068	
6.9		602P10069	602P12069	602P15069	
7		602P10070	602P12070	602P15070	
7.1		602P10071	602P12071	602P15071	
7.2	9/32"	602P10072	602P12072	602P15072	
7.3		602P10073	602P12073	602P15073	
7.4		602P10074	602P12074	602P15074	
7.5		602P10075	602P12075	602P15075	
7.6	19/64"	602P10076	602P12076	602P15076	
7.7		602P10077	602P12077	602P15077	
7.8		602P10078	602P12078	602P15078	
7.9		602P10079	602P12079	602P15079	
8	5/16"	602P10080	602P12080	602P15080	602P18080
8.1			602P12081	602P15081	
8.2			602P12082	602P15082	
8.3			602P12083	602P15083	
8.4	21/64"		602P12084	602P15084	
8.5			602P12085	602P15085	
8.6			602P12086	602P15086	
8.7			602P12087	602P15087	
8.8	11/32"		602P12088	602P15088	
8.9			602P12089	602P15089	
9			602P12090	602P15090	602P18090
9.1	23/64"		602P12091	602P15091	602P18091
9.2			602P12092	602P15092	602P18092

øA		øF Ø14 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 20	øD 25	øD 32
5.3				
5.4				
5.5				
5.6	7/32"			
5.7				
5.8				
5.9				
6	15/64"	<i>602P20060</i>	<i>602P25060</i>	602P32060
6.1		<i>602P20061</i>	<i>602P25061</i>	
6.2		<i>602P20062</i>	<i>602P25062</i>	
6.3		<i>602P20063</i>	<i>602P25063</i>	
6.4	1/4"	<i>602P20064</i>	<i>602P25064</i>	
6.5		<i>602P20065</i>	<i>602P25065</i>	602P32065
6.6		<i>602P20066</i>	<i>602P25066</i>	
6.7		<i>602P20067</i>	<i>602P25067</i>	
6.8	17/64"	<i>602P20068</i>	<i>602P25068</i>	
6.9		<i>602P20069</i>	<i>602P25069</i>	
7		<i>602P20070</i>	<i>602P25070</i>	602P32070
7.1		<i>602P20071</i>	<i>602P25071</i>	
7.2	9/32"	<i>602P20072</i>	<i>602P25072</i>	
7.3		<i>602P20073</i>	<i>602P25073</i>	
7.4		<i>602P20074</i>	<i>602P25074</i>	
7.5		<i>602P20075</i>	<i>602P25075</i>	602P32075
7.6	19/64"	<i>602P20076</i>	<i>602P25076</i>	
7.7		<i>602P20077</i>	<i>602P25077</i>	
7.8		<i>602P20078</i>	<i>602P25078</i>	
7.9		<i>602P20079</i>	<i>602P25079</i>	
8	5/16"	602P20080	602P25080	602P32080
8.1		602P20081	602P25081	
8.2		602P20082	602P25082	
8.3		602P20083	602P25083	
8.4	21/64"	602P20084	602P25084	
8.5		602P20085	602P25085	602P32085
8.6		602P20086	602P25086	
8.7		602P20087	602P25087	
8.8	11/32"	602P20088	602P25088	
8.9		602P20089	602P25089	
9		602P20090	602P25090	602P32090
9.1	23/64"	602P20091	602P25091	
9.2		602P20092	602P25092	

øA		øF Ø8 G6	øF Ø11 G6	øF Ø11 G6	øF Ø11 G6
<i>mm</i>	<i>inches</i>	øD 12	øD 15	øD 16	øD 18
9.3		602P12093	602P15093		602P18093
9.4		602P12094	602P15094		602P18094
9.5		602P12095	602P15095		602P18095
9.6	3/8"	602P12096	602P15096		602P18096
9.7		602P12097	602P15097		602P18097
9.8		602P12098	602P15098		602P18098
9.9		602P12099	602P15099		602P18099
10	25/64"	602P12100	602P15100		602P18100
10.1			602P15101		602P18101
10.2			602P15102		602P18102
10.3			602P15103		602P18103
10.4	13/32"		602P15104		602P18104
10.5			602P15105		602P18105
10.6			602P15106		602P18106
10.7			602P15107		602P18107
10.8	27/64"		602P15108		602P18108
10.9			602P15109		602P18109
11			<i>602P15110</i>	602P16110	602P18110
11.1					602P18111
11.2					602P18112
11.25	7/16"		<i>602P15112</i>	602P16112	
11.3					602P18113
11.4					602P18114
11.5	29/64"		<i>602P15115</i>	602P16115	602P18115
11.6					602P18116
11.7					602P18117
11.75			<i>602P15117</i>	602P16117	
11.8					602P18118
11.9					602P18119
12	15/32"		<i>602P15120</i>	602P16120	
12.25			<i>602P15122</i>	602P16122	
12.5	31/64"		<i>602P15125</i>	602P16125	<i>602P18125</i>
12.75	1/2"		<i>602P15127</i>	602P16127	<i>602P18127</i>
13			<i>602P15130</i>	<i>602P16130</i>	602P18130
13.25	33/64"			<i>602P16132</i>	602P18132
13.5	17/32"			<i>602P16135</i>	602P18135
13.75				<i>602P16137</i>	602P18137

øA		øF Ø8 G6	øF Ø11 G6	øF Ø11 G6	øF Ø11 G6
<i>mm</i>	<i>inches</i>	øD 12	øD 15	øD 16	øD 18
14	35/64"			602P16140	602P18140
14.25	9/16"				602P18142
14.5					602P18145
14.75	37/64"				602P18147
15	19/32"				602P18150
15.25					602P18152
15.5	39/64"				602P18155
15.75					602P18157

øA		øF Ø14 G6	øF Ø14 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 20	øD 23	øD 25	øD 32
9.3		602P20093		602P25093	
9.4		602P20094		602P25094	
9.5		602P20095		602P25095	602P32095
9.6	3/8"	602P20096		602P25096	
9.7		602P20097		602P25097	
9.8		602P20098		602P25098	
9.9		602P20099		602P25099	
10	25/64"	602P20100		602P25100	602P32100
10.1		602P20101		602P25101	
10.2		602P20102		602P25102	
10.3		602P20103		602P25103	
10.4	13/32"	602P20104		602P25104	
10.5		602P20105		602P25105	602P32105
10.6		602P20106		602P25106	
10.7		602P20107		602P25107	
10.8	27/64"	602P20108		602P25108	
10.9		602P20109		602P25109	
11		602P20110		602P25110	602P32110
11.1					
11.2					
11.25	7/16"	602P20112		602P25112	
11.3					
11.4					
11.5	29/64"	602P20115		602P25115	602P32115
11.6					
11.7					
11.75		602P20117		602P25117	
11.8					
11.9					
12	15/32"	602P20120		602P25120	602P32120
12.25		602P20122		602P25122	
12.5	31/64"	602P20125		602P25125	602P32125
12.75	1/2"	602P20127		602P25127	
13		602P20130		602P25130	602P32130
13.25	33/64"	602P20132		602P25132	
13.5	17/32"	602P20135		602P25135	602P32135
13.75		602P20137		602P25137	

øA		øF Ø14 G6	øF Ø14 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 20	øD 23	øD 25	øD 32
14	35/64"	602P20140	<i>602P23140</i>	602P25140	602P32140
14.25	9/16"	602P20142	<i>602P23142</i>	602P25142	
14.5		602P20145	<i>602P23145</i>	602P25145	602P32145
14.75	37/64"	602P20147	<i>602P23147</i>	602P25147	
15	19/32"	602P20150	<i>602P23150</i>	602P25150	602P32150
15.25		602P20152	<i>602P23152</i>	602P25152	
15.5	39/64"	602P20155	<i>602P23155</i>	602P25155	602P32155
15.75		602P20157	<i>602P23157</i>	602P25157	

øA		øF Ø11 G6	øF Ø14 G6	øF Ø14 G6	øF Ø14 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 18	øD 20	øD 21	øD 23	øD 25	øD 27	øD 32
16	5/8"	602P18160	602P20160		<i>602P23160</i>	602P25160		602P32160
16.25	41/64"		602P20162		<i>602P23162</i>	602P25162		
16.5			<i>602P20165</i>	602P21165	602P23165	602P25165		602P32165
16.75	21/32"		<i>602P20167</i>	602P21167	602P23167	602P25167		
17	43/64"		<i>602P20170</i>	602P21170	602P23170	602P25170		602P32170
17.25			<i>602P20172</i>	602P21172	602P23172	602P25172		
17.5	11/16"		<i>602P20175</i>	602P21175	602P23175	602P25175		602P32175
17.75			<i>602P20177</i>	602P21177	602P23177	602P25177		
18	45/64"		<i>602P20180</i>	602P21180	602P23180	602P25180		602P32180
18.25	23/32"			602P21182	602P23182	602P25182		
18.5				602P21185	602P23185	602P25185		602P32185
18.75	47/64"			602P21187	602P23187	602P25187		
19	3/4"			602P21190	602P23190	602P25190		602P32190
19.25					602P23192	602P25192		
19.5	49/64"				602P23195	602P25195		602P32195
19.75	25/32"				602P23197	602P25197		
20					602P23200	602P25200		602P32200
20.25	51/64"				602P23202	602P25202		
20.5					602P23205	602P25205		602P32205
20.75	13/16"				602P23207	602P25207		
21	53/64"				602P23210	<i>602P25210</i>	602P27210	602P32210
21.25						<i>602P25212</i>	602P27212	
21.5	27/32"					<i>602P25215</i>	602P27215	602P32215
21.75	55/64"					<i>602P25217</i>	602P27217	

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 25	øD 27	øD 29	øD 32	øD 35	øD 36
22		602P25220	602P27220		602P32220		
22.25	7/8"	602P25222	602P27222				
22.5		602P25225	602P27225		602P32225		
22.75	57/64"	602P25227	602P27227	602P29227			
23	29/32"	602P25230	602P27230	602P29230	602P32230		
23.25			602P27232	602P29232			
23.5	59/64"		602P27235	602P29235	602P32235		
23.75			602P27237	602P29237			
24	15/16"		602P27240	602P29240	602P32240		
24.25	61/64"		602P27242	602P29242			
24.5			602P27245	602P29245			
24.75	31/32"		602P27247	602P29247			
25	63/64"		602P27250	602P29250	602P32250		
25.25			602P27252	602P29252	602P32252		
25.4			602P27254				
25.5	1"		602P27255	602P29255	602P32255		
25.75				602P29257	602P32257		
26				602P29260	602P32260		602P36260
26.25				602P29262	602P32262		602P36262
26.5				602P29265	602P32265		602P36265
26.75				602P29267	602P32267		602P36267
27	1" 1/16			602P29270	602P32270	602P35270	602P36270
27.25					602P32272	602P35272	602P36272
27.5					602P32275	602P35275	602P36275
27.75					602P32277	602P35277	602P36277
28					602P32280	602P35280	602P36280
28.25					602P32282	602P35282	602P36282
28.5	1" 1/8				602P32285	602P35285	602P36285
28.75					602P32287	602P35287	602P36287

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	øF Ø20 G6
<i>mm</i>	<i>inches</i>	øD 32	øD 34	øD 35	øD 36	øD 39	øD 42	øD 45
29		602P32290		602P35290	602P36290			
29.25		602P32292		602P35292	602P36292			
29.5		602P32295		602P35295	602P36295			
29.75		602P32297		602P35297	602P36297			
30		602P32300		602P35300	602P36300			
30.25	1" 3/16			602P35302	602P36302			
30.5				602P35305	602P36305			
30.75				602P35307	602P36307			
31				602P35310	602P36310		602P42310	
31.25				602P35312	602P36312		602P42312	
31.5			602P34315	602P35315	602P36315		602P42315	
31.75	1" 1/4			602P35317	602P36317		602P42317	
32				602P35320	602P36320	602P39320	602P42320	
32.25					602P36322		602P42322	
32.5					602P36325		602P42325	
32.75					602P36327		602P42327	
33					602P36330		602P42330	602P45330
33.25	1" 5/16				602P36332		602P42332	602P45332
33.5					602P36335		602P42335	602P45335
33.75					602P36337		602P42337	602P45337
34					602P36340		602P42340	602P45340
34.25							602P42342	602P45342
34.5							602P42345	602P45345
34.75						602P39350	602P42347	602P45347
35	1" 3/8						602P42350	602P45350
35.25							602P42352	602P45352
35.5							602P42355	602P45355
35.75							602P42357	602P45375
36						602P39360	602P42360	602P45360
36.25	1" 7/16						602P42362	602P45362
36.5							602P42365	602P45365
36.75							602P42367	602P45367
37						602P39370	602P42370	602P45370
37.25							602P42372	602P45372
37.5							602P42375	602P45375
37.75							602P42377	602P45377

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	SIR 52		
					øD 42	øD 45	
<i>mm</i>	<i>inches</i>						
38		602P42380	602P45380				
38.25		602P42382	602P45382				
38.5		602P42385	602P45385				
38.75		602P42387	602P45387				
39		602P42390	602P45390				
39.25		602P42392	602P45392				
39.5		602P42395	602P45395				
39.75		602P42397	602P45397	602P51397			
40		602P42400	602P45400	602P51400			
40.25			602P45402	602P51402			
40.5			602P45405	602P51405			
40.75			602P45407	602P51407			
41			602P45410	602P51410			
41.25			602P45412	602P51412			
41.5			602P45415	602P51415			
41.75			602P45417	602P51417			
42			602P45420	602P51420			
42.25				602P51422			
42.5				602P51425			
42.75				602P51427			
43	1" 11/16			602P51430			
43.25				602P51432			
43.5				602P51435			
43.75				602P51437			
44				602P51440	602P52440		
44.25				602P51442			
44.5				602P51445	602P52445		
44.75				602P51447			
45				602P51450			
45.25				602P51452			
45.5				602P51455			
45.75				602P51457			
46				602P51460	602P52460		
46.25				602P51462			
46.5				602P51465			
46.75				602P51467			
47				602P51470	602P52470	602P56470	

øA		øF Ø20 G6	øF Ø20 G6	øF Ø20 G6	SIR 52		
					øF Ø20 G6	øF Ø20 G6	
<i>mm</i>	<i>inches</i>	øD 42	øD 45	øD 51	øD 52	øD 56	
48					602P52480	602P56480	
49					602P52490	602P56490	
50						602P56500	
51						602P56510	
52						602P56520	


12.3 "UNILOCK" COLLETS FOR BARS 601P

"UNILOCK" COLLETS FOR SQUARE BARS - Table



INFORMATION:

for defining the internal diameter $\varnothing A$ do not consult "001 - Conversion Tables" document, but directly consult the table below.



- A Collet
- B Bar diameter
- C Example:
 3 mm = 030
 3.5 mm = 035
 12.5 mm = 125
 12.75 mm = 127
- D Family to which it belongs

S	E E=Sx1.414	øA +0.1 0	øF M5x0.5	øF Ø8 G6	øF Ø11 G6	øF Ø14 G6	øF Ø20 G6
<i>mm</i>	<i>mm</i>	<i>mm</i>	øD 7.5	øD 12	øD 18	øD 21	øD 25
3	4.24	3.8	601P08038				
4	5.65	5.1		601P12051			
5	7.07	6.6		601P12066			
6	8.48	8		601P12080	601P18080		
7	9.90	9.2			601P18092	601P21092	
8	11.31	10.3			601P18103	601P21103	
9	12.73	11.7			601P18117	601P21117	
10	14.14	13.1			601P18131	601P21131	601P25131
11	15.55	14.5				601P21145	601P25145
12	16.97	15				601P21150	601P25150

S	E E=Sx1.414	øA +0.1 0	øF M5x0.5	øF Ø8 G6	øF Ø11 G6	øF Ø14 G6
<i>mm</i>	<i>mm</i>	<i>mm</i>	øD 25	øD 29	øD 32	øD 36
13	18.38	17.4	601P25174			
14	19.80	18.8	601P25188			
15	21.21	20.2	601P25202			
16	22.62	21.6		601P29216		
17	24.04	23		601P29230		
18	25.45	24.5			601P32245	
19	26.87	25.9			601P32259	
20	28.28	27.3			601P32273	
21	29.69	28.7				601P36287
22	31.11	30.1				601P36301
23	32.52	31.5				601P36315

“UNILOCK” COLLETS FOR HEXAGONAL BARS - Table



INFORMATION:

for defining the internal diameter $\varnothing A$ do not consult “001 - Conversion Tables” document, but directly consult the table below.


Note for consultation

The codes on the grey ground are indicating the "EMPLOYED SECTOR" to prefer.

Note for ordering

- Collets with codes in bold characters are available from stock.
- Please contact IEMCA service to use the collets with codes in Italics. The delivery times for this kind of collets are longer.

Code structure



- A Collet
- B Bar diameter
- C Example:
 3 mm = 030
 3.5 mm = 035
 12.5 mm = 125
 12.75 mm = 127
- D Family to which it belongs

S		E E=Sx1.154	øA +0.1 0	øF M5x0.5	øF Ø8 G6	øF Ø11 G6	øF Ø14 G6	øF Ø20 G6
3		3.46	3.1	601P08031				
	1/8"	3.66	3.3	601P08033				
4		4.62	4.1	601P08041				
	3/16"	5.5	5		601P12050			
5		5.77	5.2		601P12052			
6		6.92	6.2		601P12062	601P18062		
	1/4"	7.33	6.6		601P12066	<i>601P18066</i>		
7		8.08	7.3		<i>601P12073</i>	601P18073		
	5/16"	9.16	8.3			601P18083	601P21083	
8		9.23	8.4			601P18084	601P21084	
8.5		9.82	9					601P25090
9		10.39	9.5			601P18095	601P21095	
	3/8"	10.99	10			601P18100	601P21100	
10		11.54	10.6			601P18106	601P21106	
10.5		12.13	11.1			601P18111		
11		12.7	11.7			601P18117	601P21117	
	7/16"	12.82	11.8			601P18118	601P21118	
12		13.85	12.8			601P18128	601P21128	601P25128
	1/2"	14.65	13.7			601P18137		
13		15.01	13.9			601P18139		

S		E E=Sx1.154	øA +0.1 0	øF 14 G6	øF 20 G6	øF 20 G6
<i>mm</i>	<i>inches</i>	<i>mm</i>	<i>mm</i>	øD 21	øD 25	øD 29
	1/2"	14.65	13.7	601P21137	601P25137	
13		15	14	601P21140	601P25140	
14		16.16	15.2	601P21152	601P25152	
	9/16"	16.49	15.5	601P21155	601P25155	
15		17.31	16.3	601P21163	601P25163	
	5/8"	18.32	17.3		601P25173	
16		18.46	17.5		601P25175	
17		19.62	18.6		601P25186	<i>601P29186</i>
	11/16"	20.15	19.2		601P25192	<i>601P29192</i>
18		20.77	19.8		601P25198	<i>601P29198</i>
19	3/4"	21.93	21		601P25210	601P29210
20		23.08	22.1			601P29221
	13/16"	23.81	22.8			601P29228
21		24.24	23.2			601P29232
22		25.39	24.4			601P29244
	7/8"	25.65	24.7			601P29247
23		26.54	25.5			
	15/16"	27.48	26.5			
24		27.7	26.7			
	31/32"	28.41	27.3			
25		28.85	27.9			
	1"	29.31	28.3			
26		30	29			
	1" 1/16	31.14	30.2			
28		32.31	31.3			
	1" 1/8	33	32			

S		E E=Sx1.154	øA +0.1 0	øF 20 G6	øF 20 G6	øF 20 G6
<i>mm</i>	<i>inches</i>	<i>mm</i>	<i>mm</i>	øD 32	øD 36	øD 40
	1/2"	14.65	13.7			
13		15	14			
14		16.16	15.2			
	9/16"	16.49	15.5			
15		17.31	16.3			
	5/8"	18.32	17.3			
16		18.46	17.5			
17		19.62	18.6			
	11/16"	20.15	19.2			
18		20.77	19.8			
19	3/4"	21.93	21			
20		23.08	22.1	601P32221		
	13/16"	23.81	22.8			
21		24.24	23.2	601P32232	601P36232	
22		25.39	24.4	601P32244	601P36244	
	7/8"	25.65	24.7	601P32247		
23		26.54	25.5	601P32255		
	15/16"	27.48	26.5	601P32265	601P36265	
24		27.7	26.7	601P32267	601P36267	
	31/32"	28.41	27.3	601P32273		
25		28.85	27.9	601P32279	601P36279	
	1"	29.31	28.3		601P36283	
26		30	29		601P36290	
	1" 1/16	31.14	30.2		601P36302	601P40302
28		32.31	31.3		601P36313	
	1" 1/8	33	32		601P36320	

12.4 COLLETS FOR TUBES 603P

COLLETS FOR TUBES - Table




CAUTION:

the external diameter of the collet must be at least 0.5 mm less than the external diameter of the bar pusher.



INFORMATION:

The 603P collets..... fitted with a Schlenker coupling, allowing the assembly on the rotating unit, are designed with an oversized length. Therefore, the 1st feeding value of the bar pusher carriage shall be increased of 7,5 mm. with respect to the standard value.



- A Bar diameter
- B Example:
5 mm = 060
10 mm = 100
12.5 mm = 125
- C Family to which it belongs

øA		øF ø8 G6	øF ø11 G6	øF ø11 G6	øF ø14 G6	øF ø20 G6	øF ø20 G6	
<i>mm</i>	<i>inches</i>	øD 12	øD 15	øD 18	øD 20	øD 25	øD 27	
5		603P12050	603P15050					
5.5		603P12055	603P15055					
6	15/64"	603P12060	603P15060		603P20060			
6.5		603P12065	603P15065		603P20065			
7		603P12070	603P15070		603P20070			
7.5		603P12075	603P15075		603P20075			
8	5/16"	603P12080	603P15080		603P20080			
8.5		603P12085	603P15085		603P20085			
9		603P12090	603P15090		603P20090			
9.5		603P12095	603P15095		603P20095			
10	25/64"		603P15100	603P18100	603P20100	603P25100		
10.5			603P15105		603P20105	603P25105		
11			603P15110		603P20110	603P25110		

øA		øF ø8 G6	øF ø11 G6	øF ø14 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6
<i>mm</i>	<i>inches</i>	øD 12	øD 15-16	øD 20	øD 25	øD 27	øD 32	øD 35
11.5			603P15115	603P20115	603P25115			
12			603P15120	603P20120	603P25120			
12.5	31/64"		603P15125	603P20125	603P25125			
13			603P15130	603P20130	603P25130			
13.5			603P16135	603P20135	603P25135			
14			603P16140	603P20140	603P25140			
14.5				603P20145	603P25145			
15				603P20150	603P25150		603P32150	
15.5				603P20155	603P25155			
16	5/8"			603P20160	603P25160		603P32160	
16.5				603P20165	603P25165		603P32165	
17				603P20170	603P25170		603P32170	
17.5	11/16"			603P20175	603P25175		603P32175	
18	45/64"			603P20180	603P25180		603P32180	
18.5					603P25185		603P32185	
19	3/4"				603P25190		603P32190	
19.5					603P25195		603P32195	
20					603P25200		603P32200	
20.5					603P25205		603P32205	
21					603P25210		603P32210	
21.5					<i>603P25215</i>	603P27215	603P32215	
22					<i>603P25220</i>	603P27220	603P32220	
22.5					<i>603P25225</i>	603P27225	603P32225	

øA		øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6
<i>mm</i>	<i>inches</i>	øD 25	øD 27	øD 29	øD 32	øD 35	øD 42	øD 49
23		603P25230	603P27230		603P32230	603P35230	603P42230	
23.5			603P27235		603P32235			
24			603P27240		603P32240	603P35240	603P42240	
24.5			603P27245		603P32245		603P42245	
25			603P27250		603P32250		603P42250	
25.5	1"			603P29255	603P32255			
26				603P29260	603P32260		603P42260	
26.5				603P29265	603P32265			
27				603P29270	603P32270		603P42270	
27.5					603P32275			
28					603P32280		603P42280	
28.5	1"1/8				603P32285			
29					603P32290	603P35290	403P42290	
29.5					603P32295			
30					603P32300	603P35300	603P42300	603P49300
30.5								603P49305
31						603P35310	603P42310	603P49310
31.5								603P49315
32						603P35320	603P42320	603P49320
32.5								603P49325
33						603P35330	603P42330	603P49330
33.5								603P49335

øA		øF ø20 G6	øF ø20 G6	øF ø20 G6	øF ø20 G6		
<i>mm</i>	<i>inches</i>	øD 40	øD 42	øD 44-45	øD 49		
34		603P40340	603P42340		603P49340		
34.5					603P49345		
35	1"3/8	603P40350	603P42350		603P49350		
35.5					603P49355		
36		603P40360	603P42360		603P49360		
36.5					603P49365		
37		603P40370	603P42370		603P49370		
37.5					603P49375		
38	1"1/2		603P42380		603P49380		
38.5					603P49385		
39			603P42390		603P49390		
39.5				603P44395	603P49395		
40			<i>603P42400</i>	603P44400	603P49400		
40.5				603P44405	603P49405		
41				603P44410	603P49410		
41.5				603P44415	603P49415		
42				603P45420	603P49420		
42.5				603P45425	603P49425		
43	1"11/16				603P49430		
43.5					603P49435		
44					603P49440		
44.5	1"3/4				603P49445		
45					603P49450		

INDEX

13.1	LIST OF AFTER-SALES CENTERS.....	2
------	----------------------------------	---

13.1 LIST OF AFTER-SALES CENTERS
AUSTRALIA - NEW ZEALAND

GIMCO – Giuliani Iemca Machinery Co. Ltd.	301-1, Dongsing Rd., Dali City, Taichung County, 412, Taiwan	Phone +886-4-2406-6970 Telefax + 886-4-2406-6943 E-mail: gimco@gimco.com.tw Website: www.gimco.com.tw
---	--	--

BRAZIL

IGM DO BRASIL LTDA.	rua Melo Palheta 165 CEP 05002030 Sao Paulo - Brasil	Phone +55 11 3801 3763 Telefax +55 11 3801 3563 Email: igmdobrasil@uol.com.br
---------------------	--	---

CHINA (PRC)

Bi-tech (Suzhou) Co. Ltd.	Wu Fang Road, Wu Jiang City, JiangSu Province - PRC	Phone +86 512 8155 6988 Telefax +86 512 8155 6986 E-mail: bi-tech@vip.163.com
---------------------------	--	---

CZECH REPUBLIC - SLOVAK REPUBLIC

ALBA PRECISION	Skorkovského 79 636 00 Brno	Phone +420 548 226 400 Telefax +420 548 532 689 E-mail: albabrno@sky.cz Website: www.albaprecision.cz
----------------	--------------------------------	--

DENMARK – NORWAY - SWEDEN

KENSON Component AB	Borgens Gata, 6 44139 Alingsaas	Phone ++46 322 637890 Telefax ++46 322 633367 E-mail: info@kenson.se Website: www.kenson.se
---------------------	------------------------------------	--

FINLAND

INDUSTRIAL TRADING HELSINKY OY	Klovinportti 5 02180 ESPOO - Finland	Phone +358 9 45592305 Telefax +358 9 455 92 306 E-mail: matti.valakari@iki.fi Website: www.ith.fi
--------------------------------	---	--

FRANCE

IEMCA France	145, rue Louis Armand ZI Des Grands Pres F- 74300 CLUSES	Phone ++33 450 896960 Telefax ++33 450 896135 E-mail: iemca@iemca.fr Website: www.iemca.fr
--------------	--	---

GERMANY (West - Nord)

Hoßfeld GmbH	Königsberger Straße 10 D-58511 Lüdenscheid	Phone ++49 02351 80521 Telefax ++49 02351 860442 Email : HossfeldgmbH@t-online.de
--------------	---	---

GERMANY (East)

IG GmbH	Motorstrasse 4 D - 70499 Stuttgart	Phone ++49 711 139991-0 Fax ++49 711 139991-25 E-mail: info@iggmbh.de
---------	---------------------------------------	---

GERMANY (South)

Reimo LOBERS	Rebgartenweg 5/1 D-79576 Weil am Rhein	Phone ++49 7621 69551 Telefax ++49 7621 69491 Email : mail@lobers.de
--------------	---	--

ITALY

IEMCA S.p.A.	Via Granarolo, 167 I-48018 Faenza (RA)	Phone 0546 / 698208 Telefax 0546 / 698290 Email : iemca@igmi.it Website: www.iemca.com
--------------	---	---

JAPAN

IGM Nippon K.K.	Tokyo-to, Edogawa-Ku, Nakakasai 7-31-15 Shimizu Bld 1th floor. Zip code 134-0083	Phone ++81 3 5605 8016 Telefax ++81 3 5605 8066 E-mail: h.murakami@ignippon.co.jp
-----------------	--	---

KOREA

U-HAN TRADING CO. LTD.	1111 Kumsan Building 17-1, Yoido-Dong Yeongdeungpo-Ku SEOUL, Korea	Phone ++82 2 782 2454 Fax ++82 2 780 1880 E-mail: uhanco@unitel.co.kr Website: www.uhantrading.com
------------------------	---	---

POLAND

Andrzej Gryko

ul Włodarzewska 57F/23
02-384 WarszawaPhone +48 22 8231790
Fax +48 22 8231690
E-mail a.gryko@acn.waw.pl**SPAIN**SISTECO Máquinas-Herramienta,
S.L.Pagatza Parke Industrial, 7A Saila
20690 Elgeta (Gipuzkoa)Phone 943-788058
Fax 943-768100
E-mail: empresa@sisteco.net**SWITZERLAND (Canton Ticino)**

IEMCA S.p.A.

Via Granarolo, 167
I-48018 Faenza (RA)Phone 0546 / 698208
Telefax 0546 / 698290
Email : iemca@igmi.it
Website: www.iemca.com**SWITZERLAND (French speaking area)**

IEMCA France

145, rue Louis Armand
ZI Des Grands Pres
F- 74300 CLUSESPhone ++33 450 896960
Telefax ++33 450 896135
E-mail: iemca@iemca.fr
Website: www.iemca.fr**SWITZERLAND (German speaking area)**

Reimo LOBERS

Rebgartenweg 5/1
D-79576 Weil am RheinPhone ++49 7621 69551
Telefax ++49 7621 69491
Email : mail@lobers.de**TAIWAN – SINGAPORE – MALAYSIA - PHILIPPINES:**GIMCO – Giuliani Iemca Machinery
Co. Ltd.301-1, Dongsing Rd.,
Dali City, Taichung County, 412,
TaiwanPhone +886-4-2406-6970
Telefax + 886-4-2406-6943
E-mail: gimco@gimco.com.tw
Website: www.gimco.com.tw**THAILAND**GEM - General Engineering
Machinery Co.1/781 M. 17, Phahonyothin Rd,
Kukot-Lamlukka, Phatumthanee 12130
ThailandPhone +66-2-993-8548/9
Fax +66 2 993 8010
E-mail: sisara@hotmail.com**UNITED KINGDOM**

Kitagawa Europe Ltd.

Unit 1, The Headlands
Downton, Salisbury
Wiltshire SP5 4JJPhone ++44 1725 514000
Telefax ++44 1725 514001
E-mail: jtownsend@kitagawaeurope.com
Website: www.kitagawaeurope.com**USA – CANADA - MEXICO**

Bucci Industries USA Inc.

9332 Forsyth Park Drive
Charlotte NC 28273 - USAPhone ++1 704 583 8341
Telefax ++1 704 583 8486
E-mail: info@bucci-industries.us

